

This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines

Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + Refrain from automated querying Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search


Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at http://books.google.com/



Library of the University of Wisconsin



•



500 PLAIN ANSWERS TO DIRECT QUESTIONS

ON

STEAM, HOT WATER, VAPOR and VACUUM HEATING

THE SCIENCE AND PRACTICE OF HEATING EXPLAINED IN A SERIES OF PLAIN QUESTIONS AND ANSWERS, WITH TABLES, RULES AND GENERAL INFORMATION, FORMING A COMPLETE TEXT BOOK AND MANUAL. A HELP TO THE APPRENTICE AND JOURNEYMAN STEAM FITTER IN PREPARING FOR EXAMINATION. A REFERENCE BOOK FOR MASTER STEAM FITTERS, ARCHITECTS AND HEATING CONTRACTORS.

BY

ALFRED G. KING

Author of "Practical Steam and Hot Water Heating," "Practical Heating Illustrated," etc.



PROFUSELY ILLUSTRATED

NEW YORK
THE NORMAN W. HENLEY PUBLISHING COMPANY
132 NASSAU STREET
1915

COPTRIGHT 1915

В

THE NORMAN W. HENLEY PUBLISHING CO.

194527 MAY 14 1915 SXP -K58 F 6935462

PREFACE

The rapid advancement in methods of heating and ventilation compel the progressive steam fitter to read and study constantly in order to keep abreast of the times and in touch with the latest improvements. Systems of heating are now in almost common use which were unheard of three, five or ten years ago.

Text books and manuals on the subject of heating written a few years ago are no longer up-to-date and are now of benefit to the steam fitter only as books of reference, descriptive of the history of heating up to the time of their publication, and giving rules, tables and formulas for reference.

This work—in the form of brief questions and answers—is intended as a guide and text book for the younger, inexperienced fitter, and as a reference book for all fitters. All long and tedious discussions and descriptions formerly considered so important have been eliminated, and the theory and laws of heat and the various old and modern methods and appliances used for heating and ventilating are treated in a brief and concise manner. A sufficient number of illustrations, rules and tables are included to make the book complete for handy and ready reference.

A. G. King.

February, 1915.

. .

CONTENTS

1	Page
The Theory and Laws of Heat	11
Methods of Heating	13
Chimneys and Fuels	15
Boilers for Heating	23
Boiler Trimmings and Settings	25
Radiation	31
Steam Heating	42
Boiler, Radiator and Pipe Connections for Steam Heating	52
Hot Water Heating	72
The Two-pipe Gravity System of Hot Water Heating	75
The Circuit System of Hot Water Heating	81
The Overhead System of Hot Water Heating	84
Boiler Radiator and Pipe Connections for Gravity Systems of Hot	
Water Heating	88
Accelerated Hot Water Heating	96
Expansion Tank Connections	109
Domestic Hot Water Heating	116
Valves and Air Valves	120
Vacuum, Vapor and Vacuo-vapor Heating	133
Mechanical Systems of Vacuum Heating	141
Non-mechanical Vacuum Systems	148
Vapor Systems	160
Atmospheric and Modulating Systems	177
Heating Greenhouses	180
Information Rules and Tables	186

.

LIST OF ILLUSTRATIONS


			Page
Figure	1	Plan of a square flue	
44	2	Illustrating proper height of chimney	
"	3	Smoke ascends a flue spirally	
44	4	Effective area of long, narrow flue	
44	5	Effective area of contracted flue	. 19
44	6	Effect of soot in offset of flue	. 20
44	7	Pop safety valve	. 25
44	8	Steam gauge	. 26
44	9	Water column and gauge	. 27
44	10	Old style damper regulator	. 28
44	11	Method of attaching damper chains	. 29
44	12	A box coil	. 31
44	13	A corner coil	
44	14	A "Harp" or miter coil	
44	15	A return bend or "Trombone" coil	
44	16	A direct-indirect radiator	
44	17	An indirect radiator	
44	18	Proper location of indirect radiator	
46	19	Method of boxing an indirect radiator	
44	20	The One-pipe method of Steam Heating	
44	21	The Relief System of Steam Heating	
44	22	The One-pipe Circuit System of Steam Heating	
44	23	The Divided-circuit System of Steam Heating	
**	24	The Two-pipe Method of Steam Heating	
**	25	The Overhead or "Mills" System of Steam Heating	
**	26	Method of bleeding a main when raised to a higher level	
44	27	A reducing tee tapped eccentric	
••	28	A 90 degree connection	
4.	29	A 45 degree connection	
• 4	30	Effect of using a tee "bull-head"	
44	31	Condensation returning through a 90 degree connection	
••	32	Condensation returning through a 45 degree connection.	
••	33	Method of dripping a riser	
••	34		
••	35	A swing joint	
• •	36	A double swing joint	
		Methods of connecting steam radiators, one-pipe	
		Methods of connecting steam radiators, two-pipe	
••		Methods of connecting steam radiators, two-pipe	
••		,	
••	38	Method of connecting steam radiators, overhead system	
	39	Method of establishing a false water-line	
.,	40	Showing difference of 14" in water line	
	41	A swing joint at bottom of riser	
••	42	Method of anchoring a riser	68

LIST OF ILLUSTRATIONS

			'age
Figure	43	Riser supported on floor plate	69
٠.,	44	Showing steam header on boiler—Elevation	70
44	45	Showing steam header on boiler—Plan	70
44	46	Return header on boiler	71
44	47	Method of crossing I beam with main	71
44	48	The Two-pipe Gravity System of Hot Water Heating	76
44	49	Branch taken from side of main	77
44	50	Branch taken from main with 45 degree connection	77
**	51	Double elbow used to divide main	78
44	52	Method of connecting hot water risers	78
44	53	Method of connecting hot water risers	79
**	54	The Eureka fitting	82
44	55	The Phelps Single Main Tee.	83
"	56	The Overhead System of Hot Water Heating	85
**	57	•	86
	58	Method of connecting branch for overhead system	- 88
44		The O S fitting	
**	59	O S fittings used on drop supply risers	89
44	60	Radiator connected at bottom of both ends	90
44	61	Radiator connected at top and bottom of opposite ends.	91
	62	Radiator connected top and bottom of same end	92
	63	Radiator connected for overhead system	93
44	64	Sectional view of Honeywell Generator	97
44	65	Generator connected to system in basement	98
44	66	Generator in full operation	99
44	67	The Milwaukee Heat Generator	100
44	68	The Phelps Heat Retainer	101
44	69	The Belknap Generator	102
4.6	70	The B Heat Intensifier	103
**	71	Method of branching from main	105
**	72	The Honeywell Tank Circulator	107
44	73	Expansion tank connection—no circulation	109
44	74	Expansion tank connection—circulation to tank	110
44	75	Expansion tank connection—circulation in tank	111
44	76	Expansion tank connection—vertical for overhead system.	113
44	77	Expansion tank connection—horizontal for overhead system	
44	78	Domestic hot water supply—vertical boiler	117
**	79	Domestic hot water supply—horizontal boiler	118
• •	80	Domestic hot water supply—steam coil in boiler	
**	81	Globe valve	
44	82	Globe valve on horizontal pipe—imperfect drainage	
**	83	Gate valve	122
• •	84	Angle valve	
44	85	Check valves.	123
+4	86	Gate valve with yoke	
44	87	Steam radiator valve	
44	88	Common hot water radiator valve	
**	89	Packless hot water radiator valve	
**	90	Honeywell Unique radiator valve	
• •	91	Unique valve open—sectional view	
• •	91	Unique valve closed—sectional view	
	34	Omque varie closeu—sectional view	7.00

LIST OF ILLUSTRATIONS

Figure 93 Simplex hot water radiator valve 131 " 94 Wood wheel air valve 131 " 95 Hot water key air valve 131 " 96 Webster motor valve on riser 141 " 97 Paul Exhauster—low pressure 142 " 98 Paul Exhauster—high pressure 143 " 99 Paul system—regular high pressure 144 " 100 Paul system—regular high pressure 144 " 101 Trane-Vacuum Mercury Seal System 149 " 102 Trane-Paul Air Valve 150 " 103 K-M-C Vertical checks—vertical tank 151 " 104 K-M-C Vertical checks—vertical tank 151 " 105 Retainer valve—K-M-C system 153 " 106 Method of connecting relief valve—Gorton system 154 " 107 Impulse valve—Gorton system 156 " 108 Automatic relief valve—Gorton system 156 " 109 Dunham air trap 157 " 110 Connections to boiler and tank—Dunham system 158 " 111 Pu				age
95	.,	93	Simplex hot water radiator valve	131
101 Webster motor valve on riser 131	**	94	Wood wheel air valve	131
97 Paul Exhauster—low pressure	**	95	Hot water key air valve	131
98 Paul Exhauster—low pressure	44	96	Webster motor valve on riser	141
99 Paul system—down feed exhaust	4.6	97	Paul Exhauster—low pressure	142
100	• •	98	Paul Exhauster—high pressure	143
100 Fath system—regular light pressure 149	44	99	Paul system—down feed exhaust	144
102	• •	100	Paul system—regular high pressure	145
102 Frane-Path Rif Valve 150 103 K-M-C Vertical checks—vertical tank 151 104 K-M-C Vertical checks—horizontal tank 152 105 Retainer valve—K-M-C system 153 106 Method of connecting relief valve—Gorton system 154 107 Impulse valve—Gorton system 155 108 Automatic relief valve—Gorton system 156 109 Dunham air trap 157 110 Connections to boiler and tank—Dunham system 158 111 Pump and condenser—Bishop-Babcock-Becker system 161 112 Quintuple valve—Broomell system 162 113 Union elbow—Broomell system 163 114 Receiver and regulator—Broomell system 164 115 Broomell receiver and regulator connected to system 165 116 Receiver—Trane Vapor system 166 117 Showing installation of Trane Vapor system 167 118 Regulator, non-overflowing vent and traps—Vapor Regulator Co 168 119 Method of installing atmospheric system—Vapor Regulator Co 169 120 Ejector and condenser—Moline system 171 121 Method of installing Moline system 172 122 Baffler—Kriebel system 173 123 Controller—Kriebel system 174 124 Circulation through radiator—Kriebel system 175 126 Method of piping a greenhouse 183	••	101	Trane Vacuum Mercury Seal System	149
"104 K-M-C Vertical checks—horizontal tank 152 "105 Retainer valve—K-M-C system 153 "106 Method of connecting relief valve—Gorton system 154 "107 Impulse valve—Gorton system 155 "108 Automatic relief valve—Gorton system 156 "109 Dunham air trap 157 "110 Connections to boiler and tank—Dunham system 158 "111 Pump and condenser—Bishop-Babcock-Becker system 161 "112 Quintuple valve—Broomell system 162 "113 Union elbow—Broomell system 163 "114 Receiver and regulator—Broomell system 164 "115 Broomell receiver and regulator connected to system 165 "116 Receiver—Trane Vapor system 166 "117 Showing installation of Trane Vapor system 167 "118 Regulator, non-overflowing vent and traps—Vapor Regulator Co. 168 "119 Method of installing atmospheric system—Vapor Regulator Co. 169 "120 Ejector and condenser—Moline system 171 "121 Method of installing Moline system 172 <t< td=""><td>4.6</td><td>102</td><td>Trane-Paul Air Valve</td><td>150</td></t<>	4.6	102	Trane-Paul Air Valve	150
105	"	103	K-M-C Vertical checks—vertical tank	151
106	**	104	K-M-C Vertical checks—horizontal tank	152
106 Method of connecting relief valve—Gorton system 154 107 Impulse valve—Gorton system 155 108 Automatic relief valve—Gorton system 156 109 Dunham air trap 157 110 Connections to boiler and tank—Dunham system 158 111 Pump and condenser—Bishop-Babcock-Becker system 161 112 Quintuple valve—Broomell system 162 113 Union elbow—Broomell system 163 114 Receiver and regulator—Broomell system 164 115 Broomell receiver and regulator connected to system 165 116 Receiver—Trane Vapor system 166 117 Showing installation of Trane Vapor system 167 118 Regulator, non-overflowing vent and traps—Vapor Regulator Co 168 119 Method of installing atmospheric system—Vapor Regulator Co 169 120 Ejector and condenser—Moline system 171 121 Method of installing Moline system 172 122 Baffler—Kriebel system 173 123 Controller—Kriebel system 174 124 Circulation through radiator—Kriebel system 174 125 Installation of Kriebel system 175 126 Method of piping a greenhouse 183	**	105	Retainer valve—K-M-C system	153
108	4.6	106	Method of connecting relief valve—Gorton system	154
109	44	107	Impulse valve—Gorton system	155
110 Connections to boiler and tank—Dunham system 158 111 Pump and condenser—Bishop-Babcock-Becker system 161 112 Quintuple valve—Broomell system 162 113 Union elbow—Broomell system 163 114 Receiver and regulator—Broomell system 164 115 Broomell receiver and regulator connected to system 165 116 Receiver—Trane Vapor system 166 117 Showing installation of Trane Vapor system 167 118 Regulator, non-overflowing vent and traps—Vapor Regulator Co 168 119 Method of installing atmospheric system—Vapor Regulator Co 169 120 Ejector and condenser—Moline system 171 121 Method of installing Moline system 172 122 Baffler—Kriebel system 173 123 Controller—Kriebel system 174 124 Circulation through radiator—Kriebel system 175 125 Method of piping a greenhouse 183	44	108	Automatic relief valve—Gorton system	156
"111 Pump and condenser—Bishop-Babcock-Becker system 161 "112 Quintuple valve—Broomell system 162 "113 Union elbow—Broomell system 163 "114 Receiver and regulator—Broomell system 164 "115 Broomell receiver and regulator connected to system 165 "116 Receiver—Trane Vapor system 166 "117 Showing installation of Trane Vapor system 167 "118 Regulator, non-overflowing vent and traps—Vapor Regulator Co 168 "119 Method of installing atmospheric system—Vapor Regulator Co 169 "120 Ejector and condenser—Moline system 171 "121 Method of installing Moline system 172 "122 Baffler—Kriebel system 173 "123 Controller—Kriebel system 174 "124 Circulation through radiator—Kriebel system 174 "125 Installation of Kriebel system 175 "126 Method of piping a greenhouse 183	44	109	Dunham air trap	157
"111 Pump and condenser—Bishop-Babcock-Becker system 161 "112 Quintuple valve—Broomell system 162 "113 Union elbow—Broomell system 163 "114 Receiver and regulator—Broomell system 164 "115 Broomell receiver and regulator connected to system 165 "116 Receiver—Trane Vapor system 166 "117 Showing installation of Trane Vapor system 167 "118 Regulator, non-overflowing vent and traps—Vapor Regulator Co 168 "119 Method of installing atmospheric system—Vapor Regulator Co 169 "120 Ejector and condenser—Moline system 171 "121 Method of installing Moline system 172 "122 Baffler—Kriebel system 173 "123 Controller—Kriebel system 174 "124 Circulation through radiator—Kriebel system 174 "125 Installation of Kriebel system 175 "126 Method of piping a greenhouse 183	44	110	Connections to boiler and tank—Dunham system	158
"112 Quintuple valve—Broomell system 162 "113 Union elbow—Broomell system 163 "114 Receiver and regulator—Broomell system 164 "115 Broomell receiver and regulator connected to system 165 "116 Receiver—Trane Vapor system 166 "117 Showing installation of Trane Vapor system 167 "118 Regulator, non-overflowing vent and traps—Vapor Regulator Co 168 "119 Method of installing atmospheric system—Vapor Regulator Co 169 "120 Ejector and condenser—Moline system 171 "121 Method of installing Moline system 172 "122 Baffler—Kriebel system 173 "123 Controller—Kriebel system 174 "124 Circulation through radiator—Kriebel system 174 "125 Installation of Kriebel system 175 "126 Method of piping a greenhouse 183	**	111		
113 Union ellow—Broomen system	• 6	112		162
114 Receiver and regulator—Broomer system. 105 "115 Broomell receiver and regulator connected to system. 165 "116 Receiver—Trane Vapor system. 166 "117 Showing installation of Trane Vapor system. 167 "118 Regulator, non-overflowing vent and traps—Vapor Regulator Co. 168 "119 Method of installing atmospheric system—Vapor Regulator Co. 169 "120 Ejector and condenser—Moline system. 171 "121 Method of installing Moline system. 172 "122 Baffler—Kriebel system. 173 "123 Controller—Kriebel system. 174 "124 Circulation through radiator—Kriebel system. 174 "125 Installation of Kriebel system. 175 "126 Method of piping a greenhouse. 183	44	113	Union elbow—Broomell system	163
113 Broomen receiver and regulator connected to system	44	114	Receiver and regulator—Broomell system	164
110 Receiver—Irane Vapor system. 100 "117 Showing installation of Trane Vapor system. 167 "118 Regulator, non-overflowing vent and traps—Vapor Regulator Co. 168 "119 Method of installing atmospheric system—Vapor Regulator Co. 169 "120 Ejector and condenser—Moline system. 171 "121 Method of installing Moline system. 172 "122 Baffler—Kriebel system. 173 "123 Controller—Kriebel system. 174 "124 Circulation through radiator—Kriebel system. 174 "125 Installation of Kriebel system. 175 "126 Method of piping a greenhouse. 183	44	115	Broomell receiver and regulator connected to system	165
117 Showing installation of Trane Vapor system 107 118 Regulator, non-overflowing vent and traps—Vapor Regulator Co. 168 119 Method of installing atmospheric system—Vapor Regulator Co. 169 120 Ejector and condenser—Moline system 171 121 Method of installing Moline system 172 122 Baffler—Kriebel system 173 123 Controller—Kriebel system 174 124 Circulation through radiator—Kriebel system 174 125 Installation of Kriebel system 175 126 Method of piping a greenhouse 183	4.6	116	Receiver—Trane Vapor system	166
"118 Regulator, non-overflowing vent and traps—Vapor Regulator Co	44	117	Showing installation of Trane Vapor system	167
lator Co. 168 " 119 Method of installing atmospheric system—Vapor Regulator Co. 169 " 120 Ejector and condenser—Moline system 171 " 121 Method of installing Moline system 172 " 122 Baffler—Kriebel system 173 " 123 Controller—Kriebel system 174 " 124 Circulation through radiator—Kriebel system 174 " 125 Installation of Kriebel system 175 " 126 Method of piping a greenhouse 183	i.	118	. •	
" 119 Method of installing atmospheric system—Vapor Regulator Co. 169 " 120 Ejector and condenser—Moline system 171 " 121 Method of installing Moline system 172 " 122 Baffler—Kriebel system 173 " 123 Controller—Kriebel system 174 " 124 Circulation through radiator—Kriebel system 174 " 125 Installation of Kriebel system 175 " 126 Method of piping a greenhouse 183				168
lator Co. 169 120 Ejector and condenser—Moline system. 171 121 Method of installing Moline system. 172 122 Baffler—Kriebel system. 173 123 Controller—Kriebel system. 174 124 Circulation through radiator—Kriebel system. 174 125 Installation of Kriebel system. 175 126 Method of piping a greenhouse. 183	44	119		
" 120 Ejector and condenser—Moline system 171 " 121 Method of installing Moline system 172 " 122 Baffler—Kriebel system 173 " 123 Controller—Kriebel system 174 " 124 Circulation through radiator—Kriebel system 174 " 125 Installation of Kriebel system 175 " 126 Method of piping a greenhouse 183				169
" 121 Method of installing Moline system. 172 " 122 Baffler—Kriebel system. 173 " 123 Controller—Kriebel system. 174 " 124 Circulation through radiator—Kriebel system. 174 " 125 Installation of Kriebel system. 175 " 126 Method of piping a greenhouse. 183	44	120		
" 122 Baffler—Kriebel system 173 " 123 Controller—Kriebel system 174 " 124 Circulation through radiator—Kriebel system 174 " 125 Installation of Kriebel system 175 " 126 Method of piping a greenhouse 183		121		
" 123 Controller—Kriebel system 174 " 124 Circulation through radiator—Kriebel system 174 " 125 Installation of Kriebel system 175 " 126 Method of piping a greenhouse 183	**	122		
" 124 Circulation through radiator—Kriebel system	44	123		
" 125 Installation of Kriebel system	44			
" 126 Method of piping a greenhouse	**	125		
The second of th	• •		•	
	**		1.00	



THE THEORY AND LAWS OF HEAT.

1. Q. What is heat?

- A. Heat is a form of energy or motion produced by friction. All matter is made up of small rapidly vibrating particles or molecules. The faster these particles vibrate the more heat is produced and the more the body is expanded. This expansion is often carried to such an extent as to transform the body into another state.
- 2. Q. Give an example of a change in the form of a body due to heat.
 - A. The formation of steam from water.
 - 3. Q. How is heat measured?
- A. By the effect it produces. As heat is not a substance it cannot be measured by the foot or bushel, nor can it be weighed by the pound. It is calculated by the effect it produces upon another body to which it is transferred.
 - 4. Q. How is heat transferred from one body to another?
 - A. By conduction, convection and by radiation.
- 5. Q. Give examples of heat transferred by each of these methods.
- A. The heat from a hot iron is transferred to another piece of iron by contact with it, as when one end is placed in the fire the opposite end becomes warm. This is transference by conduction. Water heated at the boiler and delivered to a radiator by means of currents makes the radiator hot. This is heating by convection. An object located near a stove or radiator is made warm by the heat diffused and transferred to it by the stove or radiator. This is heat transference by radiation.
- 6. Q. How is the effect of heat transferred from one body to another measured?
 - A. By the Heat Unit.
 - 7. Q. What is a Heat Unit?
- A. A heat unit is a scale for measuring the effect of heat, and all heating calculations are based on and measured by the heat unit. There are three standards of measure: British, French and German.
- 8. Q. Which of these measures is in general use in this country?
 - A. That which is known among heating men and engineers

as the British Thermal Unit (B. T. U.). This is the unit employed in all American and British practice.

- Q. What is the measure of a British Thermal Unit?
- A. A British Thermal Unit (B. T. U.) is the amount of heat required to raise one pound of water from 32 degrees to 33 degrees on the Fahrenheit scale. This amount is measurable and always the same, as would be one inch for length or one pound for weight.
 - 10. Q. What is meant by the Fahrenheit scale?
- A. Fahrenheit was a German who in 1724 invented the thermometer and scale which are used in the United States and Great Britain and British Colonies; the scale ranging from Zero (0) to 212 degrees, the boiling point, 32 degrees being the freezing point.
- II. Q. What is the mechanical equivalent of heat or the mechanical effect produced by its application?
- A. One unit of heat is capable of raising 772 pounds weight one foot high. This is termed "foot pounds." J. P. Jule, while experimenting (1838), determined or discovered a definite relationship between heat and work.
- 12. Q. What is meant by equalizing heat between two bodies?
- A. When a difference in temperature exists between two bodies, solid or liquid, that come in contact with each other it is a law of heat that their temperature will become equalized. There is always a tendency for heat to flow from a hotter to a colder body.
 - 13. Q. Give an example of the operation of this law?
- A. Pour a gallon of water having a temperature of 50 degrees into a vessel containing a gallon of water having a temperature of 100 degrees and the resultant temperature of their combined bulk will be 75 degrees. Further, if the air surrounding the vessel is 60 degrees the water in it will cool until the temperatures of the air and water are equalized.

METHODS OF HEATING.

- 1. Q. What methods are employed or what types of heating apparatus are used for warming buildings?
- A. Open fires, stoves, hot air furnaces, steam, hot water, vacuum and vapor heating apparatus.
- 2. Q. How do the various systems compare or rank in cost of installation?
- A. They rank (in the matter of first cost) very nearly in the order named. Of the more modern methods hot air is the cheapest. A steam heating apparatus costs about double that of a good furnace installation. The ordinary hot water apparatus about one-third more than steam, and vacuum and vapor heating costs from one-quarter to one-half more than steam, depending upon the type of system installed.
- 3. Q. How does each system rank in comparative running expense or cost for fuel?
- A. Approximately a building requiring twelve tons of coal to warm it with hot air (with cold air supply) can be warmed by direct steam with nine tons of coal, by hot water with eight tons, and by a vacuum or vapor apparatus with eight or slightly less than eight tons of coal.
- 4. Q. What is the average life of each system and the cost for repairs during this period?
- A. The average life of a furnace is from ten to twelve years with approximately twenty-five per cent. of its first cost expended for repairs. The average life of a steam boiler and system is from twenty to twenty-five years with perhaps ten to twelve per cent. of the original cost expended for repairs. The average life of a hot water job is twenty-five or thirty years with a possible expenditure of ten per cent. of its first cost for repairs.

As to the life of a vacuum or vapor job there is little available data, but there seems to be no reason why such an installation should not have a length of life equal to that of a steam or hot water apparatus.

- 5. O. What is considered to be the best system of heating?
- A. The best system to install depends upon so many conditions that it is hardly possible to give an intelligent answer to the question.

Many houses and small buildings can be heated very satisfactorily with a furnace, and with the addition of a mechanically driven fan hot air heating is very satisfactory for buildings of larger size.

A steam heating apparatus is quick in action and in the results obtained, and there is no building but what can be heated successfully with steam if the apparatus is properly installed. It is particularly adapted for use in variable climates.

Hot water gives a very mild and even heat with little attention, and is particularly adapted for residence heating or for use in steadily cold or uniform climates.

Vapor and vacuum are considered quick and efficient for use in any climate.

It may be well to add that special methods of installation and special appliances increase the utility of any of the systems named.

CHIMNEYS AND FUELS.

- r. Q. Having selected the type of heating apparatus to be installed, what is the next important step to be taken in order that the apparatus shall prove successful and economical in operation?
 - A. The provision of a good chimney of proper size.
- 2. Q. What are the essential features of a good chimney flue?
 - A. A round, or as nearly a square flue as circumstances will





Fig. 1.—Plan of a Square Flue.

permit (Fig. 1), tile lined or well pointed; built straight up without offsets to a point well above the highest point of the roof. (Fig. 2). The chimney should have no other smoke-pipe opening than the one used for the heating apparatus.

- 3. Q. Why should a chimney be built round or square?
- A. The smoke ascends a chimney spirally (Fig. 3); therefore there is no circulation in the corners of a square flue nor in the ends of a long narrow flue (Fig. 4).
- 4. Q. Why should a chimney flue be lined with tile or well pointed?
 - A. Friction of the ascending column of smoke and gases due to



CHIMNEYS AND FUELS

particles of mortar overhanging in the flue is bad for the draft and reduces the capacity of the chimney, and for this reason the inside should be carefully smoothed or lined with tile. It is estimated that a 100 foot tile lined chimney will have fifty per cent. more capacity than an ordinary brick flue of the same height.

- 5. Q. What two principal factors has a chimney flue?
- A. Area and height. Area for capacity and height for velocity. A chimney must be able to pass sufficient air to properly burn the fuel and carry off the smoke and products of combustion.




Fig. 3.—Smoke Ascends a Flue Spirally.

- 5. Q. What is the easiest method of increasing the draft in a flue already built?
- A. Increasing its height increases the velocity and consequently adds to the effectiveness of the flue.
 - 7. Q. How is the required area of a chimney determined?
- A. By the area of the grate of the boiler or heater which it serves.
- 8. Q. What shall be the area of a chimney flue as compared with the area of the grate of the heater?

From one-eighth to one-tenth of the grate area. For the ordinary heating apparatus the chimney should not be smaller than 8 x 12 inches.

	SIZES OF CHIMNEL FEOES.								
Cubic Feet. Contents of Building.	Square Feet Direct Steam Radiation.	Square Feet Hot Water Radiation.	Round Tile or Iron Inside. Inches.	Square or Rectangu- lar—Tile or Brick. Inches.					
10,000- 20,000	250 to 450	300 to 800	8	8 x 8					
20,000- 45,000	450 to 700	800 to 1200	10	8 x 12					
45,000- 75,000	700 to 1,200	1,200 to 2,200	12	12 x 12					
75,000-140,000	1,200 to 2,400	2,200 to 3,600		12 x 16					
140,000-200,000	2,400 to 3,500	3,600 to 5,200		16 x 16					
200,000-350,000	3,500 to 5,000	5,200 to 8,000	18	16 x 20					

SIZES OF CHIMNEY FLUES.

No chimney flue should be less than 8 x 8 inches square or 8 inches round, and a flue 8 x 12 inches will give better service.




Fig. 4.—Effective Area of Long, Narrow Flue.

- g. Q. What are some of the most frequent causes of trouble or failure on the part of the flue to operate properly?
- A. Insufficient area or height, smoke pipe pushed into the chimney too far, the chimney being contracted or enlarged at some point, (Fig. 5), two or more smoke pipes entering the same flue, poor shape or construction, and too abrupt offsets or clogging with soot. (Fig. 6).
 - 10. O. What is combustion?

- A. Combustion is a chemical action which produces heat.
- 11. Q. In burning coal, coke, gas, or other fuel what is necessary to produce combustion?

CHIMNEYS AND FUELS

- A. The mixing of oxygen with the fuel. The gas (carbureted hydrogen) and the carbon of the fuel must each be supplied with the necessary amount of oxygen and be kept at the required temperature to produce the chemical action necessary for perfect combustion.
- 12. Q. How is the combustion of fuel in a heating apparatus calculated?




Fig. 5.—Effective Area of Contracted Flue.

- A. By the pounds of fuel consumed per square foot of grate per hour.
- 13. Q. What is the average rate of combustion in a low pressure steam boiler or house heating apparatus of modern type?
- A. It varies from three to five or six pounds of coal per square foot of grate per hour depending upon the size and character of the apparatus and the condition of the chimney flue.
 - 14. Q. What size of coal is the easiest to burn, and why?

- A. Large size, for the reason that it does not pack tightly and the large air spaces between the lumps of coal allow the air to pass through it freely and mix readily with the gases in the combustion chamber of the heater.
- 15. Q. Why is the use of a smaller size of coal deemed, advisable?
- A. It packs closer on the grate and acts as a check on the air passing through it. The air passing in smaller quantities is more




Fig. 6.—Effect of Soot in Offset of Flue.

readily heated and in mixing with the gases produces more perfect combustion.

- 16. Q. What kind of coal is generally used for a heating apparatus, and why?
- A. Hard or anthracite coal because it burns at a slower rate of combustion; therefore lasts longer and is also cleaner to handle and use.
 - 17. Q. Why is hard coal cleaner and better than soft coal?
 - A. Hard coal contains only a very small percentage of volatile

CHIMNEYS AND FUELS

matter (gas)—usually seven or eight per cent.—and from eighty-five to ninety per cent. of carbon, while the better grades of soft coal contain from twenty to thirty-five per cent. of gaseous matter and impurities to from sixty to seventy-five per cent. of carbon. With the slow combustion required in ordinary heating apparatus the small amount of oxygen admitted is not sufficient to burn the gases in the soft coal without considerable smoking.

COMPOSITION OF COAL.

Kinds.	Volatile	Matt	er (Gas)		Fixe	d Ca	rbon.	
Anthracite	7	per	cent.	85	to	90	per	cent.
Semi-Bituminous	18	~ ,,	,,	75	to	80	- ,,	"
Bituminous	24	"	"	70	to	72	,,	"
Semi-Gas	30	"	,,	60	to	65	,,	"
Coking	33	"	"	58	to	60	"	,,
Gas	. 37	"	"	55	to	58	,,	,,
Combustible Matter	∫Vola	tile	Mattarbon	er ((Co	Ga oke	s))		
Non-Combustible Matter.	∫Moi	stur	e (Wa efuse)	iter)		•		
Impurities	{	Smo	Sulph oke) rites (•	•		٠.

- 18. Q. What attention should be given the boiler to provide for perfect combustion of the fuel?
- A. Keep a good clean fire. Do not pack the coal tightly and keep the fire clear of ashes and clinkers. Slow and regular combustion is a preventative of clinkers.
- 19. Q. How should the fire be checked or combustion be retarded?
- A. By closing tightly the draft door admitting air under the grate and checking the draft in the chimney by closing the damper, and if further checking is necessary by opening the check damper in the smoke-hood at the top of the boiler. Do not at any time open the firing door as by so doing the cold air will pass over the heating surfaces and chill the water in the boiler.
- 20. Q. How frequently should fuel be added for proper or economical firing?
- A. Once every eight hours for severe weather, once every twelve hours for moderate cold weather, and once every twentyfour hours for mild weather.

- 21. Q. What should be the amount of fuel required for a low pressure steam or hot water boiler?
- A. A very fair estimate is one ton of anthracite coal per radiator per heating year (six months) allowing 50 square feet of radiation for a steam radiator or 75 square feet for a hot water radiator.
 - 22. Q. What exceptions should be made to this rule?
- A. The addition of improved modern specialties to a heating plant such as accelerating devices for hot water and vapor and vacuum devices for steam will increase the efficiency of a heating apparatus, and reduce the amount of fuel required. Poor methods of firing, carelessness of attention, and certain conditions of draft and chimney construction will increase the amount of fuel required.

BOILERS FOR HEATING.

- 1. Q. What types of boilers are commonly used for heating?
- A. Cast iron sectional boilers, either round or square, having vertical or horizontal sections, and round steel or wrought iron boilers for small installations, and fire-box, tubular or water-tube boilers for large installations.
 - 2. Q. Which type of boiler is most generally used?
 - A. The cast iron boiler either round or square.
- 3. Q. Why is cast iron preferred to wrought iron or steel in boiler construction?
- A. Cast iron is considered to be less susceptible to rust than wrought iron or steel and therefore is thought to be the better material for a heating boiler that is idle or out of service a good portion of the year.
- 4. Q. Why will wrought iron or steel rust more quickly than cast iron?
- A. Cast iron is simply melted ore with most of the impurities removed which is moulded into the various castings of which the boiler is composed. It is porous and not likely to rust. The finer iron is worked the more the pores are removed and the greater will be its tendency to rust.
 - 5. Q. What two factors are necessary in boiler construction?
 - A. Heating surface and grate surface.
 - 6. Q. What is meant by heating surface?
- A. The heating surface of a boiler is of two kinds, direct surface and flue surface. Direct surface is that portion of the boiler above and surrounding the fire against which the direct heat from the fire strikes or against which the direct heat waves from the fuel impinge. Indirect or flue surface is that which receives the heat from the burning gases in their exit from the combustion chamber into the smoke flue.
 - 7. Q. What is meant by grate surface?
- A. The grate surface of a boiler is the cradle or surface that holds or supports the fuel and is proportioned according to the amount of heating surface contained in the boiler and to the radiating surface (square feet of radiation) necessary for a building.
- 8. Q. How can the amount of grate surface required in a boiler be determined on a heat unit basis?
 - A. Determine the loss in heat units per hour for the entire

building. Dividing this sum by an amount equalling 60 per cent. of the heat value of the coal to be used for fuel (if a good quality of anthracite containing 14,500 B. T. U. per pound — $14,500 \times .60 = 8,700$) gives the weight of fuel to be burned per hour. Divide this result by 3 or 4 for small boilers or 5, 6 or 7 for larger boilers (these divisors representing the rate of combustion per hour) and the result will be the grate surface required.

- 9. Q. How are fire-box, tubular, and water-tube boilers rated?
 - A. By their horse-power.
 - 10. O. What is meant by the term "horse-power"?
- A. A horse-power (H. P.) is the amount of work required to raise 33,000 pounds one foot high per minute, which is equivalent to 42.5 heat units per minute and which represents the energy developed by evaporating 2,665 pounds of water into steam.
- 11. Q. How is the horse-power of a tubular boiler calculated?
- A. Each 15 square feet of heating surface is considered equivalent to one horse-power.
 - 12. Q. How are cast iron boilers rated?
- A. Their rating should be based on the amount of coal consumed per square foot of grate surface and their efficiency. The character of construction to a large degree determines the efficiency. Boilers which have a large prime or direct heating surface in proportion to the size of grate are more efficient than boilers with a large amount of indirect surface.
- 13. Q. Why is a boiler with a large proportion of direct heating surface most efficient?
- A. Direct surface is more efficient than indirect or flue surface, the proportion being about three to one. There should be only sufficient flue surface to assist in consuming the gases and extract the heat from the products of combustion before they leave the boiler.
- 14. Q. How is the radiating capacity of a heating boiler usually rated and listed by manufacturers?
- A. By the square feet of direct radiation (gross), steam or hot water which a boiler of any certain size will supply for an eight hour period of firing.
 - 15. Q. What is meant by "gross" amount of direct radiation?
- A. Boiler power or capacity is calculated at the boiler outlet, therefore provision must be made for all piping as well as radiators. (Various kinds of radiating surfaces, direct, semi-direct and indirect, are discussed elsewhere in this book.)

BOILER TRIMMINGS AND SETTING.

- 1. Q. What trimmings are used on a steam boiler used for heating?
- A. A safety valve of the weighted or pop (spring) variety, a low pressure steam gauge, a water column with water glass and try-cocks, a damper regulator and a draw-off cock.




Fig. 7.—Pop Safety Valve.

- 2. Q. Where should the safety valve be located and for what purpose is it used?
- A. The safety valve (Fig. 7) should be located at the top of the boiler and it is used to relieve excessive pressure of steam when the pressure has accumulated to a point considered dangerous.
- 3. Q. What is the maximum pressure commonly allowed on low pressure boilers?
- A. From eight to fifteen pounds, depending upon the size and character of the boiler.

- 4. Q. At what point on the boiler is the steam gauge located and what is its purpose?
- A. The steam gauge (Fig. 8) should be located above the boiler and should be connected to it, or to the pipe connection to the water column, by a siphon. Its purpose is to register the pressure in pounds per square inch of the steam within the boiler.
- 5. Q. What is the water column (and gauge), where is it located, and for what purpose is it used?
- A. The water column (Fig. 9) is a hollow cylindrical casting having a water glass extending nearly its entire length. It is also tapped for and provided with two or three try-cocks. It is located at the side of the boiler at such a height that the glass




Fig. 8.—Steam Gauge.

will be about half full when the boiler is filled with water to the normal water-line. The top of the water column is connected to the steam chamber of the boiler and the bottom of it to the water space of the boiler, and its purpose is to show in the glass the height of the water in the boiler.

- 6. Q. Why is the water column connected to the boiler as above described?
- A. In order that the steam pressure will be the same on the water in the glass as it is upon the water in the boiler so that the water-line will show its true height in the glass when steam is carried at various pressures on the boiler.
 - 7. O. What is meant by a damper regulator?
 - A. A damper regulator (Fig. 10) is a device connected to the

BOILER TRIMMINGS AND SETTING

steam space of the boiler which regulates the draft and check doors of the boiler, and is operated by the pressure of steam carried.

- 8. Q. How is a common form of damper regulator made and how does it operate?
- A. Two castings in shape similar to an old-fashioned soup plate are bolted together at the rim with a rubber diaphragm




Fig. 9.—Water Column and Gauge.

between them. A plunger, resting on the rubber, protrudes through an opening in the center of one of the castings. This device is connected to the steam chamber of the boiler by a nipple or short piece of pipe in such a manner that the pressure of steam against the under side of the rubber will force it against and raise the plunger (which is on the upper side of the device). Connected to a lip of the casting and resting across the plunger is a long iron rod from the ends of which chains connect with the damper doors. As steam raises the plunger the rod tilts and operates the damper

doors of the boiler, the extent of this operation being governed by movable weights placed on the rod; these weights are adjusted according to the requirements of the work.

- 9. Q. How should the chains be connected from damper rod to draft doors?
- A. In such a manner that when both draft and check doors are closed the damper rod will be level horizontally.

Note by Fig. 11 that weight C on the rod B is set away from the regulator and holds open the draft door E. A very little pressure of steam against the diaphragm of the regulator will raise the rod to a level position, closing the draft door E as shown by the second position. Should this not check the fire sufficiently and the pressure continue to accumulate against the diaphragm it will





Fig. 10.—Old Style Damper Regulator.

raise the rod until it opens the check door F as shown by the third position. The diaphragm regulator is shown at A, the smoke hood at D and G represents the smoke pipe.

10. Q. What is a draw-off cock?

A. A water cock or valve having a full size free opening through it which is placed at an extreme low point of the boiler for the purpose of draining the water and sediment from it. If properly constructed the cock should have a pipe thread at one end for screwing into an opening of the boiler and a hose thread at the opposite end for attaching a hose.

- 11. Q. What trimmings are necessary for a fire-box or tubular boiler used for heating?
- A. If used for low pressure heating the trimmings are substantially the same as are required for a cast iron boiler.
 - 12. O. What setting is used for cast iron boilers?



A. The old method of setting cast iron boilers, particularly those of large size, was to enclose them by walls of common brick and by lining with fire brick any part of the setting which came in contact with the fire. At this date nearly all cast iron boilers have a portable setting. The sections are bolted together and the exterior surface (excepting doors and front plate castings) are covered with plastic magnesia or asbestos cement.

MATERIAL	EVD	DDICK	WODE	OF WIIDIII	A D	DAILEDS

Boilers — Single Setting.	Common Brick.	Fire Brick	Sand Bushels.	Cement Barrels.	Fire Clay Pounds.	Lime Barrels.
30" x 8'	5,200	320	42	5	192	2
30" x 10"	5,800	320	46	$5\frac{1}{2}$	192	$2\frac{1}{4}$
36" x 8'	6,200	480	50	6°	288	$2i\frac{\pi}{2}$
36" x 9'	6,600	480	53	$6\frac{1}{2}$	288	$2\frac{3}{4}$
$36'' \times 10'$	7,000	480	56	7	288	3
36" x 12"	7.800	480	62	8	288	$3\frac{1}{4}$
$42'' \times 10'$	10,000	720	80	10	432	4
42" x 12"	10,800	720	86	11	432	41/4
42" x 14"	11,600	720	92	$11\frac{3}{4}$	432	41/2
42" x 16"	12,400	720	99	$12\frac{1}{2}$	432	5
$48'' \times 10'$	12,500	980	100	$12^{\frac{1}{2}}$	590	$5\frac{1}{4}$
48" x 12"	13,200	980	108	$13\frac{1}{2}$	590	$5\frac{1}{2}$
48" x 14"	14,200	980	. 116	1413	590	$5\frac{3}{4}$
48" x 16"	15,200	980	124	$15^{\frac{1}{2}}_{2}^{\frac{7}{2}}$	590	6
54" x 12'	13,800	1,150	108	$13\frac{3}{4}$	690	$5\frac{1}{2}$
54" x 14"	14,900	1,150	117	15	690	6
54" x 16'	16,000	1,150	126	16	690	$6\frac{1}{4}$
60" x 10"	13,500	1,280	108	$13\frac{1}{2}$	768	$5\frac{1}{2}$
60" x 12"	14,800	1,280	118	$14\frac{3}{4}$	768	6
60" x 14"	16,100	1,280	128	16	768	$6\frac{1}{2}$
60" x 16"	17,400	1,280	140	$17\frac{1}{2}$	768	7
60" x 18"	18,700	1,280	148	$18\frac{3}{4}$	768	7^{1}_{2}
66" x 16"	19,700	1,400	157	$19\frac{3}{4}$	840	8
$66'' \times 18'$	21,000	1,400	168	21	840	812
72" x 16"	20,800	1,550	166	$20\frac{3}{4}$	930	$81/_{2}$
72" x 18'	22,000	1,550	175	22	930	9

13. Q. What setting is used for tubular or fire-box boilers?

A. Tubular or fire-box boilers are set in brick work. The outer and end walls should be constructed of best hard burned brick laid in cement and lime mortar. The fire-box lining should be made of best fire brick laid on flat in thin clay mortar with close joints and occasional header courses. The bridge wall should be faced (at least partially) with fire brick. The ash pits and a small space in front of the boiler should be paved with common brick laid on edge.

30

RADIATION.

- 1. Q. What is meant by the term "Radiation" or "Radiating Surfaces"?
- A. As applied to heating, radiation means some form of hollow metal surface through which steam or hot water is circulated and which, by contact with the air surrounding it (this air being very much cooler), cools the steam or water, imparting its heat units to the air of the room to be warmed.
- 2. Q. Of what material is the usual type of radiator constructed?
 - A. Cast iron or wrought iron. The early type of radiators




Fig. 12.—A Box Coil.

were made of wrought iron tubes screwed into a cast iron base. The manufacture of this type of radiator has been almost, if not entirely, discontinued. A stack of piping termed a "box coil" was also largely used in the early days of steam heating. Fig. 12. This was sometimes encased with ornamental cast iron panels or scroll work and covered with an iron or marble top. Radiating surfaces made of wrought iron as at present employed are usually designated as pipe coils. The radiators commonly used are cast iron made up of sections nippled together. Radiators with loops made of sheet steel are also used to some extent.

3. Q. For what class of heating are pipe coils generally employed?

A. As radiating surface for warming factory buildings, green-houses or conservatories, garages and other buildings where the appearance of a pipe coil is not objectionable.

4. Q. What styles of pipe coils are in general use?

A. Corner coils, "harp" or mitre coils, and return-bend or "trombone" coils.

5. Q. What is a corner coil?

A. A corner coil, as its name implies, is one which is located at and turns a corner of a room, the elbows used on the piping




Fig. 13.—A Corner Coil.

at the corner providing for the expansion and contraction of the pipes. Manifolds or branch-tees are usually employed in building this style of coil. Fig. 13.

6. Q. What is a "harp" or mitre coil?

A. A coil built with a mitre and shaped like the letter L, the short end of the mitre being placed vertically when the coil is hung in position. The mitre is used in order that the elbows will provide for expansion and contraction. Fig. 14.

7. O. What is a return-bend coil?

A. A return bend coil is a coil constructed with return bends

RADIATION

to allow for the expansion and contraction and its construction allows a continuous flow of the steam or hot water through a single pipe. Fig. 15.

- 8. Q. In building or making up a manifold coil what fittings are used?
- A. The neatest method is to employ right and left elbows at the mitre. Common elbows may be used and the pipes joined to the manifold with long screws or lock or jam nuts.
- 9. Q. Which type of radiator is the best for general use—cast or wrought iron?




Fig. 14.—A "Harp" or Mitre Coil.

- A. There is not much difference. Wrought iron radiators are, if anything, more efficient, but are hardly as desirable as cast iron radiators owing to the fact that cast iron radiators are made up of loops or sections of several heights and widths, and a variety of shapes and sizes may be had to fit any desired space.
- 10. Q. How many types or kinds of radiating surface are in use?
- A. Three; the several types of radiators are known as direct, semi-direct or direct-indirect and direct radiation.
 - 11. Q. What is a direct radiator?
 - A. Direct radiators are so called because they are located in

the room to be warmed and give off their heat directly to the air within the room.

12. Q. Describe a direct-indirect or semi-direct radiator.

A. Direct-indirect or semi-direct radiators are so arranged that they will warm fresh air conveyed from outside the building through a duct or opening through the wall to a boxing forming the base of the radiator, the air being warmed by passing upward over the surface of the radiator as it enters the room. The duct and base are provided with dampers so that the fresh air inlet may be closed and when closed the radiator can be used as a direct radiator. Fig. 16.




Fig. 15.—A Return Bend or "Trombone" Coil.

13. Q. Describe an indirect radiator and the indirect method of heating.

A. Indirect radiators are located outside of the room to be heated and warm the room indirectly by warming a supply of air which is then introduced into the room through a duct and register. They are commonly located below the room to be heated although they may be located adjacent to it. The radiator is encased in a boxing and a cold air supply from outside the building connects with the boxing. Fig. 17.

14. Q. At what point in a room should a direct radiator be located?

A. Along the most exposed and coldest wall of the room or under a window on this side of the room.

15. Q. Why should the radiator be placed on the cold side rather than on an inner wall of the room?

A. When located in this position the radiator will condense

RADIATION

more steam or cool the hot water more and therefore give off more heat to the surrounding air than when located along an inner wall or in a warmer position. The radiator along an exposed wall draws the cold air to it, warms and expands the air, causing




Fig. 16.—A Direct-Indirect Radiator.

it to rise, and thus creating a circulation or turning of the air within the room. If placed on an inner wall the radiator will draw the colder air across the floor of the room and thus cause uncomfortable and dangerous drafts.

16. Q. What should be the location of a direct-indirect radiator?

A. The same as a direct radiator. For the same reasons and further that it is necessary to provide for an inlet through the outer wall for the fresh air supply to the radiator.

17. Q. At what point should an indirect radiator be located?

A. The radiator itself should be located near to the register, and the location of the register in a room should be in the inside wall or in the floor near the inside wall, or exactly the reverse of the location for a direct radiator.




Fig. 17.—An Indirect Radiator.

18. Q. What is meant by the word "stack" as applied to indirect radiation?

A. Several sections of an indirect radiator when bolted and nippled together, or assembled, are frequently referred to as a "stack" or an "indirect stack."

19. Q. How is a stack of indirect radiation placed in position for service?

A. It should be hung or suspended from the ceiling of the basement on suitable hangers and covered with a casing made of galvanized iron or beaded boards lined with tin. The stack should be hung in such a position that when encased there will be an air space of from eight to ten inches in height above the radiator, and from six to eight inches below it, and the casing should fit

RADIATION

tightly around the sides in order that the air will pass between the sections and not around them. The cold air should enter at the bottom of one end of the casing, and the hot air should be taken from the top of the opposite end. Fig. 19.

20. Q. What air supply is necessary for an indirect radiator?

A. As a rule it is well to be generous in the size of air ducts,




Fig. 18.—Proper Location of Indirect Radiator.

both cold and hot, for use with indirect radiation, as each duct should be provided with a damper which may be utilized to reduce the air supply. It is a hard matter to increase the efficiency of too small an air duct.

From 1 to 1½ square inches of area to each square foot of radiation for the hot air duct, according to the size of the radiator, is a good rule to employ, and the area of the cold air duct should be

2/3 to 3/4 of the area of the hot air flue. When the radiator serves an upper floor the area of the hot air duct may be decreased from 20 to 25 per cent. and the area of the cold air duct may be slightly increased.

SIZES OF AIR DUCTS AND REGISTERS FOR INDIRECT HEATING.

		ir Duct Stack.	Warm Air Duct		Reg				
8q.Ft. of Rad'n.	For First Floors Square Inches.	For Upper Floors Square Inches.	For First Floors Square Inches.	For Upper Floors Square Inches.	For First Floor Inches.	For Upper Floors Inches.	Radiator Tappings. Inches.		
40	40	35	60	40	10 x 12	8 x 10	1 x 3/4		
50	50	40	75	50	10 x 12	8 x 10	1 x 3/4		
60	60	45	90	60	10 x 14	8 x 12	1½ x 1		
70	70	50	105	70	12 x 15	10 x 12	1½ x 1		
80	80	60	120	80	12 x 15	10 x 12	1½ x 1		
90	90	70	135	90	12 x 19	10 x 14	1½ x 1¼		
100	100	75	150	100	12 x 19	12 x 15	11/2 x 11/2		
120	110	90	170	110	16 x 16	12 x 15	11/2 x 11/2		
140	120	105	190	120	16 x 18	12 x 18	2 x 132		
160	130	120	210	130	16 x 20	12 x 20	2 x 1½		

- 21. Q. What should be the size of the registers for indirect heating?
- A. The effective register area should be about 25 per cent. greater than the area of the hot air flue connecting with it.
- 22. Q. What factors determine the amount of radiating surface necessary for a building?
 - A. The cooling surfaces of the building.
 - 23. O. What are the cooling surfaces of a building?
- A. The cubic feet of air in the same (cubical contents), the outside or exposed wall surfaces, and the glass surface (windows and outside doors), outside doors being considered as glass surface.
- 24. Q. How is the right amount of radiation determined for each room in the building?
- A. There are a number of good rules for this purpose, any one of which is reasonably accurate when used with judgment and when the various phases of building construction, location and exposure are considered.

One of the more simple rules is called the Mills rule or the rule 2-20-200; that is, for steam heating allow one square foot of radiation for each 2 square feet of glass, one for each 20 square feet of exposed wall surface, and one for each 200 cubic feet of contents.

RADIATION

For hot water heating add 60 per cent. to the amount required for steam.

Figure separately for each room and tabulate the result to show the total radiation required.

For example, consider a room 12'×16' in size having a ceiling 10' high, the 16' side of the room an outside wall and two windows




Fig. 19.-Method of Boxing an Indirect Radiator.

```
3' \times 6'.

12 \times 16 \times 10 = 1920 cubic feet of contents.

16 \times 10 = 160 square feet of exposed wall.

3 \times 6 \times 2 = 36 square feet of glass.

1920 \div 200 = 10 feet for cubical contents.

160 \div 20 = 8 feet for exposed wall.

36 \div 2 = 18 feet for glass.
```

Total 36 feet for steam. 36 + 21 (60 per cent.) = 57 feet for hot water.

25. Q. What condition other than size and amount of wall and glass governs the estimating of all radiation?

A. The location of the rooms to be warmed; whether located on the north or exposed side of the building or on the south or warm side of the same.

26. Q. How are these conditions covered when estimating?

A. For rooms on the north or exposed side of the building add 10 per cent. to the amount obtained by the rule, and for rooms on the south or warm side of the building deduct 10 per cent. When locating the radiation in a large room such as a church or public auditorium exposed on all sides, approximately 10 per cent. more radiation should be placed on the north side than on the south side.

27. Q. What rooms in a residence require special consideration when estimating radiation?

A. The halls, dining room and bath room.

28. Q. What special treatment is necessary for each of these rooms?

A. When estimating radiation for the hall, both lower and upper halls should be considered together and the total radiation required should be placed in the lower hall unless the upper hall is very much exposed and isolated from the lower hall. The dining room should be warmed particularly well, as being the first of the living rooms to be occupied in the morning it should be quickly warmed, thus requiring plenty of radiation.

The bath room should have from 25 to 30 per cent. more radiation than the amount obtained by rule, as all bath rooms should be particularly well warmed.

29. Q. How is the amount of radiation required for direct-indirect heating ascertained?

A. By adding 25 per cent. for steam, or 35 per cent. for hot water, to the amount of direct radiation obtained by rule.

30. Q. How is indirect radiation computed?

A. By adding 50 per cent. for steam, or 75 per cent. for hot water, to the amount of direct radiation required.

31. Q. What amount of radiation is required for vapor heating?

A. Approximately 15 per cent. more than is necessary for steam. A very good rule for computing radiation for a vapor system is to multiply the cubical contents by $1\frac{1}{2}$, the exposed wall surface by 25 and the glass surface by 75, add the results together and divide the total by 200.

RADIATION

For example, consider a corner room $12' \times 15'$ in size having a ceiling 10' high, one outside door (with transom) $3' \times 8'$ and one window $4' \times 6'$.

 $12 \times 15 \times 10 = 1800$ cubic feet of contents.

 $12 + 15 \times 10 = 270$ square feet of exposed wall.

 $3 \times 8 + 4 \times 6 = 48$ square feet of glass.

 $1,800 \times 1\frac{1}{2} = 2,700$

 $270 \times 25 = 6,850$

 $48 \times 75 = 3,600$

13,150

 $13,150 \div 200 = 65$ square feet radiation for vapor.

- 32. Q. What conditions require the addition of the various percentages for hot water or vapor heating to the amount required for steam?
- A. Radiation required is based upon the maintenance of 70 degrees inside temperature with the thermometer at zero outside, and radiation for steam heating based upon a pressure of 2 pounds or a temperature of 219 degrees hot water upon a temperature of 180 degrees and vapor upon a temperature of 212 degrees (atmospheric pressure) or a few ounces above atmospheric pressure.

STEAM HEATING.

- 1. Q. How many systems of steam heating are in general use?
- A. Strictly speaking there are but two—high pressure and low pressure; although there are several modifications or methods of installing each system.
- 2. Q. Which system is most frequently used when installed for heating purposes only?
 - A. The low pressure gravity return system.
- 3. Q. What methods may be employed in installing this system?
- A. The one-pipe or the two-pipe method, employing a wet or dry return. The one-pipe method may be installed as a circuit system, or as a divided circuit system, or a relief system without returns. The two-pipe system may be installed according to the regular method by which both flow and return mains are run in basement, or by the overhead method with the mains run overhead and the returns only in the basement. The overhead method might properly be called a combination of the one-pipe and two-pipe systems.
- 4. Q. Why are these methods designated as low pressure gravity return systems?
- A. Because of the fact that in the installation of each system the piping is so arranged that the water of condensation from the radiators returns to the boiler by gravity.
 - 5. Q. What is meant by low pressure steam?
- A. Steam at a pressure of from one to five pounds is ordinarily considered as being low pressure although this pressure is often increased to eight or ten pounds on a low pressure apparatus.
- 6. Q. What is meant by high pressure steam as used for heating apparatus?
- A. The ordinary acceptance of the term is the heating of buildings from high pressure or tubular boilers which are themselves used for power or for purposes other than supplying steam to the heating apparatus. The pressure may be 30, 40, 50, 100 pounds, or more.
- 7. Q. Is it customary to use steam at high pressure in a heating apparatus?

STEAM HEATING

- A. No. The steam pressure is ordinarily reduced by placing a pressure reducing valve on the steam line, reducing it to a nominal pressure in the heating apparatus.
- 8. Q. What form of heating from high pressure boilers is used to a great extent?





Fig. 20.—The One-Pipe Method of Steam Heating.

- A. Exhaust heating.
- 9. Q. What is meant by exhaust heating?
- A. Steam is supplied at high pressure to an engine, pump or other mechanical appliance requiring steam for power. The steam after accomplishing its work in the cylinders escapes through

an exhaust pipe and but a very small percentage of its heating value (possibly from 5 to 7 per cent.) has been utilized by the engine or pump, and instead of allowing this steam to escape to the atmosphere it is turned into the heating apparatus.

- 10. Q. For what other purpose is the exhaust steam commonly used?
- A. To heat the boiler feed water. It is passed through an apparatus called a feed water heater which heats the water required for boiler feed purposes.
- II. Q. About how much of the value of the steam is required to heat the feed water for the boiler?
- A. Approximately 15 per cent. It is estimated that after passing through the cylinders of the engine or pump and the feed water heater there is still from 60 to 80 per cent. of its value left for heating purposes, the amount depending upon the character of the engine or pump employed.
 - 12. Q. What is the one-pipe method of circulating steam?
- A. The one-pipe method is that which has only a single pipe connection to each radiator, the branch or feed pipe being arranged to act as both flow and return, and a single main pipe conveys the steam to the radiator and returns the condensation to the boiler. Fig. 20.
- 13. Q. How should the supply branch be connected to the radiator?
- A. Always at the bottom of one end of the radiator, employing but one valve in making the connection.
- 14. Q. How is the main flow pipe run on a single pipe system?
- A. The main (or mains—there may be more than one) is usually taken from the top of the boiler to a point within a few inches of the ceiling above, from which point it pitches downward to the end of the line, the pitch being from one-half to one inch in each ten feet of length.
- 15. Q. Can the main be installed so as to pitch upward from the boiler if circumstances so require it?
- A. Yes, provided it is dripped or relieved at the low point in order not to form a trap for the return water of condensation.
 - 16. O. What is a relief system?
- A. A system on which all mains or flow pipes pitch upward from the boiler, each being provided with a drip or relief pipe at a point near the boiler through which all condensation is returned

STEAM HEATING



to the bottom of the same. The condensation from radiators and piping may also be dripped or relieved by drip connections at the base of each riser or radiator connection, these being connected to a wet return. Fig. 21.

- 17. Q. What is the circuit system of piping and how is this system installed?
- A. A circuit system is one on which a single steam main rises from the boiler to as high a point as convenient and then makes a circuit of the basement supplying the various radiators by branches taken from the main pipe as occasion requires. As a rule this main terminates at a point near the boiler and an automatic air valve is placed on the end and a drop made with a smaller pipe into a return opening of the boiler. Fig. 22.
- 18. Q. What should be the difference in height between the end of the main and the water line of the boiler?
- A. Not less than 14 inches and a height of 18 inches is preferable.
- 19. Q. What conditions govern the height of the end of the main or the distance between it and the water line of the boiler?
- A. The size and length of the main as proportioned to the square feet of radiation or condensing surface on the job. The element of friction due to fittings and valves on the main is also considered, as friction reduces the velocity of the steam which affects the pressure drop at the end of the main. As the steam pressure on the water in the boiler is much greater than on the water in the return at the end of the line there is a point of equalization in the return and this may be anywhere from 6 to 20 inches or more above the water line, but on a carefully designed system should not exceed 12 or 14 inches; therefore a distance of 14 inches between the end of the main and the water line of the boiler should be sufficient.
 - 20. Q. What is the divided-circuit system?
- A. This system is similar in all respects to the circuit system except that the location of the boiler or shape of the building may make it advisable to run the main in two circuits, one in either direction.
- 21. Q. How should the returns be connected on a divided-circuit system?
- A. The mains usually terminate at a point in the basement distant from the boiler and an automatic air valve should be placed on the end of each main and the returns or bleeders from the ends

STEAM HEATING




Fig. 22.—The One-Pipe Circuit System of Steam Heating.





Fig. 23.—The Divided-Circuit System of Steam Heating.

STEAM HEATING



49

of each should drop and be connected together below the water line, and the single or combined return should be returned wet to the boiler. Fig. 23.

- 22. Q. Describe the two-pipe system of steam heating.
- A. The two-pipe system has a flow and return connection to




Fig. 25.—The Overhead or "Mills" System of Steam Heating.

each radiator or unit of radiation and a valve is placed on the connection at each end of the radiator.

The main of a two-pipe system is run in the same manner as for a circuit system; both it and the branch pipes are smaller than would be required for the one-pipe system as the supply pipes

STEAM HEATING

accommodate the steam only, all condensation returning through the return pipes. Fig. 24.

- 23. Q. Should the return pipes on a two-pipe system be wet or dry?
- A. Wet returns are preferable to dry returns for this system. The whole system of returns should drain or pitch slightly toward the boiler.
- 24. Q. What is the overhead or Mills system of steam heating?
- A. The overhead or Mills system takes its name from the fact that the main is taken upward through the building to the attic or top of the system and all risers or connections to radiators are supplied by drop risers from above, all drips from risers and returns from radiators being connected into the main returns which are run in the basement. This system was adopted by John H. Mills, who was a prominent engineer and heating man in the early days of steam and hot water heating, and therefore is known as the Mills system. As all steam and water flow in the same direction there is little friction and the system is therefore considered very efficient and serviceable for any building to which it can be adapted. Fig. 25.

- I. Q. What names are given to the various pipes which convey the steam from the boiler to the radiators or pipe coils?
 - A. Mains, branches, risers and returns.
 - 2. O. What is a steam main?
- A. By a steam main is meant those pipes which run horizontally from the boiler along the ceiling of the cellar or basement to convey steam to the various branches supplying the radiators or coils.
 - 3. Q. What is a branch or riser connection?
- A. The pipe leading from a steam main and connecting with a riser or a pipe supplying a radiator is called a branch or riser connection.
 - 4. O. What is a riser?
- A. A pipe which extends vertically through one or more floors of the building from the end of a branch to the topmost radiator supplied.
 - 5. Q. What is a drop-riser and how installed and used?
- A. A drop-riser is used with an overhead system of steam supply; that is to say, a system on which the mains or distributing pipes are run at the top of the system. The drop risers extend down to the basement, feeding or supplying the steam to the radiators downward, the condensation from the radiators flowing downward with the steam.
 - 6. Q. What is a return pipe?
- A. A return conveys the water of condensation from the end of the main and other points of the system to the boiler and may be run above or below the water-line of the boiler. When run above the water-line they are designated as "dry" returns. When run below the water-line they are called "wet" returns, as they are always full of water below the water-line.
 - 7. Q. What is generally spoken of as a radiator connection?
- A. Radiator connections are the fittings and short pipes which connect the radiators to risers or branches.
 - 8. Q. How should steam mains be installed?
 - A. The method of installation depends upon the character of

the work. The mains should always be carefully graded with sufficient pitch or fall to insure perfect drainage of the water of condensation which runs along the bottom of the pipe. They should extend around the basement a few feet from the foundation walls in a position convenient for connecting branches with the radiators or risers.

- 9. Q. What is meant by a "break" in a main or by the term "jumping the main"?
- A. Structural conditions of the building may require, or when the run is long it may be necessary to make, a rise in the main to a higher level.
- 10. Q. How is the drainage taken care of under such a condition?




Fig. 26.—Method of Bleeding a Main When Raised to a Higher Level.

A. By a bleeder or drip from the bottom of the low point which should be of sufficient capacity to accommodate the greatest amount of condensation likely to accumulate at such a point, and the bleeder or drip should be connected into a wet return or a return below the water-line of the boiler. Fig. 26.

11. Q. What is meant by a bleeder or drip?

A. A small pipe connecting a trap or low point of the piping system with a wet return, and drips may be used at any point on the piping of a steam system to relieve accumulated condensation.

12. O. What should be the size of the drip pipe or bleeder?

A. The size depends upon the size of the main and the length of the main drained by the drip. The following table gives the sizes necessary, it being supposed that a main of proper size has been installed.

DRIP PIPES FOR STEAM MAINS.

	Length of Steam Main in Feet.							
Diameter of Steam Main in Inches.	1 to 100	100 to 200	200 to 400	400 to 600				
	Diameter of Drip Pipe in Inches.							
1¼ to 2	1/2	1/2	1/2	3/4				
3 4	1/2 3/4	3/4 3/4	1 1	1 11/4				
5	34	11/	11/4	11/2				
7	1	114	11/2	11/2				
8	1	11/4	11/2	2 2				
10	11/4	11/4	11/2	2				

SIZE OF DRIPS FOR RISERS.

Square Feet of Radiation to Be Drained.		Diameter of Pig in Inches.
0 to 50		3⁄4
50 to 100		1 -
100 to 250		11/4
250 to 500	_	$1\frac{1}{2}$

This table is based on relieving the condensation from the main pipe only. If the condensation from the radiators enters the main the size of the drips should be increased accordingly.

13. Q. What important matter should be provided for in the installation of all steam piping?


A. Expansion of the pipes when heated, and contraction when cold. Piping installed in cold weather has contracted in length and when heated expands, the tremendous force of this expansion often cracking the fittings. Expansion or swing joints should be employed whenever necessary.

The expansion of wrought iron pipe under various conditions is as follows:

EXPANSION OF WROUGHT PIPE.

Tempera- ture of Air when Pipe is Fitted.	Length of Pipe when Fitted.			Length	of Pipe	When Heated to			
		which spor Atmo	Deg. F. n corre- nds to osphere ssure.	which spond Po	Deg. F. corre- s to 15 unds ssure.	which sponds Po	Deg. F. corre- to 84 unds ssure.	which sponds Po	Deg. F. corre- to 100 unds ssure.
Deg. F.	Feet. 100	Feet. 100	Inches.	Feet. 100	Inches. 2.21	Feet.	Inches.	Feet. 100	Inches.
32	100	100	1.47	100	1.78	100	2.12	100	2.45
64	100	100	1.21	100	1.61	100	1.87	100	2.19

- 14. Q. How can a main be reduced in size without forming a trap or low place where condensation can lodge or without required for steam?
- A By the use of reducing fittings tapped eccentric on the reduced end.
- 15. Q. What is meant by eccentric fittings or fittings tapped eccentric?
- A. An eccentric fitting is a fitting tapped with the center of the smaller opening at such a point that the lower side of pipes screwed or adjusted to either end will be on the same level. The lower side of each pipe being on a level insures perfect drainage through the fitting without forming a pocket in which the water might lodge. Fig. 27 illustrates a tee with the small end tapped eccentric.



Eccentric Reducing Tee.

Fig. 27.—A Reducing Tee Tapped Eccentric.

- 16. Q. How are the branch pipes supplying radiators or risers connected to a main?
- A. Two methods are in general use, the 90 degree connection and the 45 degree connection.
 - 17. Q. What is meant by the term "90-degree connection"?
- A. The tee on the main which supplies the branch is set with the side opening looking directly upward and a nipple and 90 degree elbow are used to connect the branch. Fig. 28.
 - 18. Q. What is a 45-degree connection?
- A. The tee on the main is set with the side opening looking upward at an angle of 45 degrees, and a nipple and 45 degree elbow are used for the branch connection. Fig. 29.

- 19. Q. Is the use of a tee "bull-head," or used on the end of a pipe to divide the flow, considered good practice?
- A. A tee should never be employed in this manner as the friction and unequal division of the flow will harm the efficiency of the work. Fig. 30 shows the effect of such a connection, the arrows indicating the direction of the flow.



Fig. 28.-- A 90 Degree Connection,

- 20. Q. Which style of connection is preferable for use on a gravity steam job where the condensation from the radiators returns to the main?
- A. The 45 degree connection allows the water of condensation to return to the main without saturating the steam which occupies the upper part of the pipe and is therefore the best for one-pipe installations. Fig. 31 shows the condensation returning through a 90 degree connection, and Fig. 32 the condensation returning through a 45 degree connection.




Fig. 29.—A 45 Degree Connection.

- 21. Q. When is the use of the 90-degree style of connection permissible?
- A. On two-pipe work or in the event of the branch pitching away from the main.
- 22. Q. What should be the size of the branch as compared with the riser or radiator connection fed by it?

A. On one-pipe work the branch should generally be one pipe size larger than the riser or connection to the radiator in order to lessen the velocity of the steam in the branch and thus allow





Fig. 30.—Effect of Using a Tee "Bull-Head."

the water of condensation to return in the bottom of the pipe against the pressure of the steam.

On two-pipe work the branch may be the same size as the riser or radiator connection as the drainage is made through a separate pipe.




90° Connection

Fig. 31.—Condensation Returning Through a 90 Degree Connection.

- 23. Q. When a branch pitches downward from the main how is the water of condensation cared for?
 - A. By what is known as a heel drip at the base of the riser or

radiator connection; this drip pipe connecting with a wet return. Fig. 33.

24. Q. What is known as a "swing" joint, and for what purpose is it used?



45 Connection.

Fig. 32.—Condensation Returning Through a 45 Degree Connection.




Fig. 33.—Method of Dripping a Riser.

- A. A swing joint is made with two elbows and a nipple and is employed to allow a pipe to expand at right angles to its alignment. Fig. 34.
- 25. Q. What is a "double swing" joint, and for what purpose is it employed?

A. A "double swing" or "universal" swing joint is made by employing four elbows and nipples and when employed allows the piping to expand in any direction without breaking the fittings or without disturbing the alignment of the pipe. Fig. 35.



Fig. 34.—A Swing Joint.

26. Q. How are radiators connected for the one-pipe system?

A. But one valve is employed and the connection is made to one end of the radiator only; this pipe being of sufficient size to accommodate the supply of steam and the returning condensation.




Fig. 35.—A Double Swing Joint.

. Several styles of connections are used and those allowing for expansion are the best. Fig. 36 illustrates some of these.

27. Q. How are radiators connected for the two-pipe system?

A. A valve is used on each end of the radiator; that on the return being generally two sizes smaller than the supply valve. The

separate connection on the return end is made to drain the radiator of condensation. Owing to this fact the supply connection is made smaller than that employed on the one-pipe system. Several styles of two-pipe radiator connections are illustrated by Fig. 37.

- 28. Q. How are radiators connected when the overhead system of piping is employed?
 - A. They are usually connected as on an up-fed one-pipe system




Fig. 36.—Methods of Connecting Steam Radiators, One-Pipe.

They may, however be connected with separate flow and return if the conditions of the work demand such a connection. Fig. 38. illustrates several methods.

- 29. Q. What causes "water hammer" or pounding in the piping of a steam heating system?
- A. The presence of cold water at low points in the piping caused by imperfect drainage. These are commonly called "traps." The water of condensation lodging at such points cools when the supply of steam is shut off or the system allowed to cool and when a pressure of steam is again turned into the piping and passes the

pockets or traps the pounding occurs. This is due to the sudden condensation of the steam which produces a vacuum in the piping. The water endeavoring to fill this vacuum coming in contact with the steam produces a snapping or pounding as of hammering on the piping.

- 30. Q. Should return mains be run wet or dry, that is, above or below the water-line of the boiler?
- A. The method of running the returns depends upon the character of the installation. They may be either wet or dry.




Fig. 37A.

A dry return should have no other return pipes connecting into it. If two or more returns are to be connected together the connection should be made below the water-line. For two-pipe work the wet return is preferred.

- 31. Q. How can this be accomplished when a portion of the cellar or basement is not excavated?
- A. By the employment of a false water-line to flood the return piping.
 - 32. O. How is a false water-line created?
- A. By trapping the main return at a point sufficiently high to keep the pipe and connections full of water. The trap should be

so arranged that it may be drained when desired. This is accomplished by making a connection from the bottom of the trap to the wet return and placing a valve on the connection. A balance or equalizing pipe should connect the top of the loop with the steam main. Fig. 39.

- 33. Q. What difference in height should be maintained between the end of a main or dry return and the water-line of the boiler?
- A. Where pipes of generous size are employed a distance of 14 inches is considered sufficient although under certain conditions




Fig. 37B.

It may be less or must be greater. Many heating engineers demand a distance of 30 inches between the end of main and the water-line. Fig. 40.

- 34. Q. Why is a distance of 14 inches between the end of main and the water-line necessary?
- A. Tables based upon accepted practice giving sizes of mains for various amounts of radiation are conditioned upon a pressure of 2 pounds to 5 pounds at the boiler, and a low velocity of the steam with a drop in pressure at the end of the line of from ½ to 1 pound. The difference in pressure (occasioned by the friction due to the length of the main and fittings on the same) causes the water in the return to rise above the level of the water in the boiler and

this difference in height of water is provided for by keeping the end of the main at a sufficient height above the water-line.

The reason of the rise of the water in the return is not always understood. When the fire is started in the boiler the water in the system stands level. As a pressure is created on the boiler it lowers the level of the water in the boiler and raises it in the return, the amount of rise being conditioned by the pressure of steam at the end of the main.

Supposing the pressure at the boiler is two pounds and at the




Fig. 37-A-B.—Methods of Connecting Steam Radiators, Two-Pipe.

end of the main one pound, a difference of a pound. The head of water equal to a pound pressure is 26.67 inches; therefore, the water in the return at the end of the system would stand 26.67 inches above the water in the boiler. Small mains increase this difference and large mains reduce it, therefore generous size mains should be used.

35. Q. Are rules given for determining the sizes of mains for low pressure steam heating?

A. Several very good rules are given but it should be stated that no two heating engineers agree exactly in their ideas of size. Baldwin has a simple rule as follows: To find the number of

square feet of heating surface a steam main will supply, square the diameter of the main in inches and multiply by 100. Example: A 2-inch main 50 feet in length. How many square feet of radiation will it supply?

 2×2 (2 inches squared) $\times 100 = 400$ square feet.

To find the size of steam main required to supply a given amount of radiation, point off two places in the amount of radiation given and find the square root of the remainder. Example: To supply 400 square feet of radiation with a main 50 feet long—4.00 (two places pointed off) = 4.

The square root of 4 is 2 $(2 \times 2 = 4)$, therefore a 2-inch main is required.

An increase in the length of a main or in the number of fittings used increases the frictional resistance to the flow of steam and demands an increase in the size of it.

į	Length of Main in Feet.									
Direct Radiation Sq. Ft. of Htg. Surface Supplied.	20	40	80	100	200	300	400	600	1000	Size of Return
вирриса.	Diameter of Pipe in Inches.									
150	11/2	11/2	11/2	11/2	2	21/2	21/2	3	3	1
300	2	2	2	2	$2\frac{1}{2}$	3	3	3	4	11/4
450	2	$2\frac{1}{2}$	$2\frac{1}{2}$	$2\frac{1}{2}$	3	3	31/2	$3\frac{1}{2}$	4	11/4
900	$2\frac{1}{2}$	$2\frac{1}{2}$	3	3	$3\frac{1}{2}$	31/2	4	4	41/2	11/2
1200	3	3	31/2	$3\frac{1}{2}$	4	4	41/2	$4\frac{1}{2}$	5	2
1600	$3\frac{1}{2}$	4	4	4	41/2	41/2	5	5	6	2
2000	4	4	41/2	$4\frac{1}{2}$	5	5	6	6	7	21/2
2500	4	41/2	41/2	5	6	6 7	6	7	8	3
4500	5	5	5	6	7		7	8	9	3
6500	5	6	7	7	8	8	8	9	10	31/2
9000	6	7	8	8	9	9	9	10	11	4
11,000	7	8	8	9	10	10	10	11	12	41/2

SIZE OF STEAM MAINS, ONE-PIPE SYSTEM.

Note: Size of returns as given in the table for "Wet" returns. For "Dry" returns one size larger pipe should be used.

36. Q. How is the expansion of the piping of a steam job provided for?

A. By the use of expansion hangers on the main and by swing or expansion joints on mains or risers. Mains supported on expansion hangers can move in either direction as the pipe expands or contracts.

- 37. Q. In the case of risers, in what direction is the expansion, and how can they be supported to allow for it?
- A. The expansion of a riser is either up or down. For an ordinary two or three story job this expansion may be provided for by a swing joint at base of riser. Fig. 41. For a riser of considerable length the expansion may be directed both upward and downward by anchoring the riser near the middle of its length. Fig. 42.
- 38. Q. How can a riser be supported without the employment of hangers?





Fig. 38.—Method of Connecting Steam Radiators, Overhead System.

- A. By using a coupling on the riser which rests upon a floor plate. The riser is cut to such a length that in coupling on the extension the bottom of the coupling will rest upon the floor plate which is a neat and practical method to employ. Fig. 43.
- 39. Q. What should be the area of the riser or risers out of the boiler as compared with the area of the main or mains?
- A. The risers out of boiler should be from 30 to 50 per cent. greater in area than the mains which they feed. Fig. 40.
- 40. Q. What is the reason for employing boiler risers or steam connections so much greater in area than the mains?
 - A. Because it is advisable that the initial velocity of the steam



as it leaves the boiler should be as much below the velocity of the steam in the main as possible in order to prevent the lifting of the water into the main.

41. Q. What would be the result of making risers and mains of equal area?

A. The velocity of steam in a vertical pipe is so much greater than in a horizontal pipe that under conditions of heavy firing or the presence of a little oil or dirt in the boiler a steady water-line




Fig. 40.—Showing Difference of 14 Inches in Water Line.

could not be maintained as the steam will carry water into the main and under certain conditions siphon the water from the boiler.

42. Q. Is the employment of a steam header on a boiler advisable?

A. The use of a header is good practice, particularly on sectional boilers having several steam outlets, and when properly constructed will prevent siphonage of the water into the mains and also provides for every movement of the pipe in expanding and contracting. A header filters the steam supply and insures dryer steam in the heating system. Fig. 44 shows an elevation of a steam header properly connected and Fig. 45 a plan of the same.




Fig. 41.—A Swing Joint at Bottom of Riser.




Fig. 42.-Method of Anchoring a Riser.

BOILER, RADIATOR, AND PIPE CONNECTIONS FOR STEAM HEATING

43. Q. What is an equalizing pipe, and for what use is it employed?

A. When two or more boilers are connected together or in battery a pipe connection between the steam space of each boiler, with a drip connecting to the return header, equalizes the pressure in the boilers and maintains an equal water-line in each. A large drip pipe connecting the header of a boiler with the return is also known as an equalizing pipe. It drains the condensation from the




Fig. 43.—Riser Supported on Floor Plate.

header and equalizes the pressure on the return. An equalizing pipe of this character is shown in the illustrations, Figs. 44 and 45.

44. Q. What is a return header, and for what purpose is it used?

A. When two or more boilers are connected together it is advisable to run a pipe across the rear of the boilers and connect the return openings of each boiler to it. This is called a return header and its use permits an equal distribution of the return water to each boiler. The return pipes from the heating system may then be connected to this header at any convenient point. Fig. 46. On work requiring a single sectional boiler of large size it is advisable to use a return header.




Fig. 44.—Showing Steam Header on Boiler.—Elevation.




Fig. 45.—Showing Steam Header on Boiler.—Plan.

BOILER, RADIATOR, AND PIPE CONNECTIONS FOR STEAM HEATING

45. Q. When it is necessary to pass over a beam with the main of a circuit job, how can the condensation be taken care of without bleeding or dripping the main?

A. By a drainage connection from the main on one side of the beam to the main on opposite side as shown by Fig. 47. The condensation will rise to its level on the low side and continue along




Fig. 46.—Return Header on Boiler.




Fig. 47.—Method of Crossing I Beam With Main.

the bottom of the main. The small pipe for conveying the condensation under the beam should be of sufficient size to pass all water and it should be carefully graded to pitch with the main. Provisions for draining the pocket may be made if desired by using a plugged tee at the low end in place of an elbow or inserting a drainage cock at this point.

HOT WATER HEATING.

I. Q. How are hot water heating systems classified?

A. As open systems—meaning systems which are open or vented to the atmosphere—and closed systems, which are systems closed to the atmosphere by sealing the outlet of the expansion tank. The latter is sometimes designated as a "pressure" system. There are several methods of installing the piping for either system and each of these methods is frequently called a "system" although they differ only in the manner of installations, the principle of circulation remaining the same.

2. Q. What type of hot water apparatus was the first to be employed commercially?

A. The closed or high pressure system. This was first in general use in England and was known as the Perkins system from the fact that a firm of foundrymen and engineers named Perkins and Son developed and used this system.

3. Q. When did hot water heating come into general use in the United States?

A. Not until the period 1875 to 1885, although hot water heat had been extensively used in Canada for several years previous to 1875.

4. Q. What system of piping was employed at this time?

A. The open tank system was the method ordinarily used although the closed or pressure system had also been employed to some extent, but had never met with popular favor.

5. Q. What advantages are claimed for the closed system?

A. The ability to carry a higher temperature of the water without boiling than is possible with an open system. Water in an open vessel at sea level boils at a temperature of 212 degrees, but when confined increases in temperature according to the pressure carried on the system. Smaller piping, fittings and valves are used on a pressure system than are required for an open tank system.

The following table gives the temperatures of hot water from the boiling point (the limit of temperature in an open system) to a pressure of 25 pounds—a temperature of 269.1 degrees.

HOT WATER HEATING

- 6. Q. What method is commonly employed to seal a hot water system and what precaution is it necessary to provide for safety?
- A. A safety valve is placed on the outlet to the expansion tank. This safety valve is set to operate at a nominal pressure, possibly 10 pounds. This valve should be examined frequently to see that it is in working order and operative at the pressure at which it is set. Should the valve stick or fail to operate an excess of pressure might accumulate which would rupture the apparatus and cause damage to the property and possibly endanger the lives of those occupying the building in which the apparatus was installed.

Pressure per Square Inch.	Temperature.	Pressure per Square Inch.	Temperatúre
0 lbs.	212 deg.	4 lbs.	225.6 deg
1/2 "	214.5 "	41/2 "	227.1 "
1 "	216.3 "	5 "	228.5 "
1½ "	218 "	7½ "	235.1 "
2 "	219.6 "	10 "	241. "
21/2 "	221.2 "	15 "	251.6 "
3 "	222.7 "	20 "	260.9 "
31/6 "	224.2 "	25 "	269.1 "

TABLE OF TEMPERATURES AND PRESSURES.

- 7. Q. Why is the open tank system preferred to the pressure or closed system?
- A. It is safer and more readily adapted for ordinary hot water installations. It being open to the atmosphere is absolutely safe under all conditions. It is also more readily attended or operated by an inexperienced person.
- 8. Q. What causes hot water to circulate through an open tank gravity system?
- A. The principles of hot water circulation are now very generally understood. A cubic foot of water at a temperature of 40 degrees weighs 62.42 pounds. A cubic foot of this water when heated to 180 degrees weighs but 60.55 pounds. In heating the water it expands and becomes lighter, increasing in volume about 5 per cent. when heated to 180 degrees. When confined in a vessel and heated it will expand upward.

Hot water circulation is the result of the law of gravitation. In a hot water system as the water in the boiler expands and becomes lighter the colder water returning to the boiler, which is denser and heavier, crowds the lighter, heated water upward, thus estab-

lishing a circulation through the system of piping and radiators; therefore it is the difference in weight or specific gravity between the flow and return columns above the source of heat energy that causes the circulation of the water, and the greater this difference in weight the greater will be the velocity of the circulation.

- 9. Q. Is the open tank system operated under a pressure?
- A. Yes, although it is not generally thought of as being operated under pressure. The average open tank system is operated under a pressure of from 15 to 20 pounds; this pressure is due to the height of water in the system.
- 10. Q. How many methods or systems of low pressure or open tank hot water installations are in general use?
- A. Three; the regular two-pipe system, the overhead system and the circuit or single main system.

THE TWO-PIPE GRAVITY SYSTEM OF HOT WATER HEATING.

- 1. Q. Describe the regular two-pipe system.
- A. The two-pipe system of hot water heating consists of a series of flow pipes leading from the boiler to the various radiators or heating surfaces and a corresponding or companion set of return pipes leading from the radiators to the boiler. Formerly, or during the period when hot water was first used, it was customary to run separate flow and return pipes to each large radiator or group of radiators with the result that frequently as many as eight or ten separate flow and return pipes were employed. At the present time, out one or two main flow and return pipes are to be found on an average sized job, each of the flows serving to supply a number of radiators, the pipes being installed sufficiently large for the purpose. The circulation to each radiator is guided by a certain character of pipe connection intended to equalize the flow and divide it equally among the several radiators supplied.

The general design of this system is shown by Fig. 48.

- 2. Q. Is the main run full size to the end of it or to the last radiator supplied?
- A. No. It is customary to reduce the size of the main as the branches are taken off or supplied. The main should not be reduced too rapidly as the water is colder and the circulation slower as the end of the line is approached.
- 3. Q. What conditions the size of piping required for mains or branches?
- A. The area of the valves on the radiators supplied. The area of the main flow should always equal or exceed the combined areas of all radiator valves and in reducing as the various branches and radiators are connected the area should remain sufficient to supply all radiators ahead of or beyond the point of reduction.
- 4. Q. What should be the area of the main at the end or point where the last radiator is supplied?
- A. At least one, and preferably two, pipe sizes larger than the vertical pipe leading to the radiator valve.
- 5. Q. How should the branches be taken from the main on a two-pipe gravity system?
 - A. The branches which supply risers leading to upper floors

should be taken from the side of the main. There is always a tendency for the flow of hot water to seek the highest point and branches to risers if taken from the top of the main would rob the circulation to first floor radiators. When the side connection is




Fig. 48.—The Two-Pipe Gravity System of Hot Water Heating.

used the first water heated (which always occupies the top part of the main) passes along to the connections of first floor radiators, and the branches to risers do not receive their supply until the hot water in the main has filled it sufficiently to feed through the side connection. Fig. 49.

THE TWO-PIPE GRAVITY SYSTEM OF HOT WATER HEATING

- 6. Q. How should the branches to first floor radiators be connected?
- A. From the top of the main with a 90 degree ell or at an angle of 45 degrees as illustrated by Fig. 50. The 45 degree connection is preferred.
- 7. Q. When it is necessary to divide the main into two flows leading in opposite directions, what type of fitting should be employed?




Fig. 49.—Branch Taken From Side of Main.

- A. A double elbow. A tee should never be used for this purpose on account of the friction at this point. The double elbow divides the flow evenly with the least friction possible. Fig. 51.
 - 8. Q. What position does the return main occupy?
- A. The return main follows the direction of the flow and is usually placed directly by the side of the flow (within a distance of



Fig. 50.—Branch Taken From Main With 45 Degree Connection.

from eight to twelve inches) until the boiler is reached, when there is a vertical drop to connect into the return opening of the boiler.

- 9. Q. How are return branches from first floor radiators connected into the return mains?
- A. On the side in order that the return circulation from one radiator or riser will not block the return from another should the temperature of the water in them be unequal.

- 10. Q. How are return branches from risers to upper floors connected to main?
 - A. Into the side of the bottom with a 45 degree connection.





Fig. 51.—Double Elbow Used to Divide Main.

- 11. Q. How are riser connections to upper floors made from a riser supplying a second floor radiator?
 - A. The radiator on the second floor should be connected from




Method of connecting second floor Rad and risers to floor above

Fig. 52.—Method of Connecting Hot Water Risers.

the top of the riser to the second floor and the risers supplying radiators to upper floors should be taken from the side of the riser supplying the second floor below the connection to the radiator. Fig. 52.

THE TWO-PIPE GRAVITY SYSTEM OF HOT WATER HEATING

- 12. Q. When two radiators on the same floor are supplied from a single riser how should they be connected?
- A. The connection from the top of the riser should supply the larger radiator. The side connection from the tee on riser should supply the smaller radiator. Fig. 53.
- 13. Q. With both radiators of equal size how should they be connected?
- A. Generally by reducing the size of the pipe connection to the radiator connected from the top of the riser.
- 14. Q. In cutting and threading the piping what precaution should be observed?



Method of connecting two radiators on same floor from single riser.

Fig. 53.—Method of Connecting Hot Water Risers.

- A. The burr left on the pipe by the cutting tool should be removed by reaming. On small pipes the burr left by the cutting tool will reduce the pipe one size and cause sufficient friction to seriously interfere with the velocity of the flow of water through the pipe.
- 15. Q. What provision is made for the expansion of the water in a hot water system to prevent overflowing when heated?

A small tank called an expansion tank is usually provided; it is located at the top of the system or above the highest radiator and from the bottom of the tank a pipe called an expansion pipe

is connected to the return from one of the highest radiators or the return at the boiler; from the top of the tank a vent pipe leads to the atmosphere.

- 16. Q. What expansion of the water takes place in an ordinary hot water system?
- A. Water as used in the ordinary hot water heating apparatus expands about 1-24 or 1-25 of its volume.

EYP	A BIC	TANT	T 4	MUC

No.	Size—Inches.	Gallons—Capacity.	Square Feet Direct Radiation Supplied.
0	10 x 20	8	250
1	12 x 20	10	300
2	12×30	15	500
3	14 x 30	20	700
4	16 x 30	26	950
5	16 x 36	32	1300
6	16 x 48	42	2000
7	18 x 60	66	3000
8	20 x 60	82	5000
9	22 x 60	100	6000

- 17. Q. What size of expansion tank should be used for the open tank hot water system?
- A. Based upon the expansion of water as stated above the following table of sizes of expansion tanks will be found sufficient for general use.

THE CIRCUIT SYSTEM OF HOT WATER HEATING.

- 1. Q. Describe what is known as the circuit system of hot water heating.
- The circuit system or as it is sometimes known, the single main system, is installed with a single main supply pipe which makes a circuit of the basement of the building in quite the same manner as the main of a single or one-pipe steam system. This main acts as both flow and return. The hottest water in a hot water main is always at the top of the main, the cooler water at the bottom, and on this fact the principle of the circulation of a circuit system is based—two bodies of water at different temperatures flowing through the same pipe. The main rises from the boiler to a point as high as desired and makes a circuit of the basement pitching downward from the boiler or up to a point which is called the high point of the main and from this high point whether it is immediately above the boiler or at some other part of the system the expansion tank is connected in order to relieve the air in the system from the high point. The radiators are connected with a flow and return branch, and risers are connected in the usual manner. Flow branches are connected from the main at the top and return branches enter the main at the bottom or at the side of the bottom. Fig. 54.
- 2. Q. What special fittings can be employed to advantage on the main of a circuit system?
- A. There are several special fittings manufactured which assist in dividing the flow and return circulation; among these are the Eureka Fitting shown by Fig. 55, and the Phelps Single Main Tee shown by Fig. 56.

The Eureka fitting has a double compartment which allows the return water to enter the fittings and which joins the water in the main through an opening at the bottom of the fitting without interfering with the flow of hot water from the same. The Phelps single main tee is a tee with an extra outlet which is located at the side of the bottom which is used for the return connection. Either of these special fittings assists in separating the flow and return and in increasing the circulation through the system.

3. Q. What should be the size of the main for a circuit or single main system?

A. As a rule the size of the main should be estimated by considering the size of the radiator valves or radiator connections. The size of main is also dependent somewhat upon the length of the circuit. If in making the circuit of the basement a main of considerable length is necessary it is well to increase the size of main owing to the fact that the temperature of the water in each leg of the main is considerably reduced, that is to say, the water in the last leg of the circuit is considerably cooler than that in the main as it leaves the boiler.

4. Q. In proportioning the radiation for a single main system what fact must be considered?

A. The fact mentioned above as to the cooling of the water in the main. The radiation attached or supplied from the last leg of




Fig. 54.—The Eureka Fitting.

the main should be figured quite a little stronger than that connected nearer to the boiler.

5. Q. Is the single main or circuit system an open tank system?

A. It may be the open tank or the closed tank system. Probably the best results are obtained where the water is circulated under a slight pressure as the rapidity of the circulation when used as a pressure job increases the temperature of the water sufficiently to reduce the amount of loss in making the circuit of the building.

6. Q. What should be the pitch of the main for a circuit system?

A. The main should have the usual pitch of $\frac{1}{2}$ to 1 inch in each 10 feet of length.

THE CIRCUIT SYSTEM OF HOT WATER HEATING

- 7. Q. How are the branches run and the risers and radiators connected for this system?
 - A. The same as for the regular two-pipe system.
- 8. Q. What size of pipe should be employed for the main of a circuit system?
- A. The size of main is conditioned largely by circumstances such as the square feet of radiation supplied, the length of the circuit and the number of radiator connections.

The following table shows what may be considered as an average




Fig. 55.—The Phelps Single Main Tee.

amount of radiation which can be supplied by a circuit main of given size:

SIZE OF MAINS FOR CIRCUIT SYSTEM.

Size of	Direct Radiation			
Main.	Supplied.			
2 inch	175 to 250 square feet			
$2\frac{1}{2}$ inch	300 to 450 square feet			
3 inch	500 to 650 square feet			
$3\frac{1}{2}$ inch	700 to 900 square feet			
4 inch	1,000 to 1,500 square feet			
5 inch	1,600 to 2,200 square feet			
6 inch	2,400 to 3,000 square feet			

THE OVERHEAD SYSTEM OF HOT WATER HEATING.

1. Q. Describe the overhead system of hot water heating.

A. The overhead system of hot water heating as its name implies is a method of supplying hot water to radiators located on various floors from a system of piping which is run overhead at the top of the building. The mains may be suspended from the ceiling of the top floor or be run through an attic or loft if such is available. Fig. 56.

A single large pipe riser (or risers) is run in the most convenient manner to the attic or top of the building and there is distributed through mains and branches to risers dropping down to the basement through the various floors supplying the various radiators connected to each riser.

The top of the main riser is the high point of the system and from this point all pipes pitch downward. The top of the riser being the high point of the system the expansion tank is connected from this point in order to relieve the air in the system when filling or which may accumulate later at this point.

2. Q. What advantage has the overhead system of piping over the ordinary two-pipe up-fed system?

As the supply riser or risers leading to the upper or top floor are the largest pipes on the system the water rises to the high point without the amount of friction usually found in several smaller pipes and in its descent through several smaller pipes supplying the radiators the friction is largely eliminated or taken care of by the weight of the water in the system which increases the circulation through the pipes and radiators. The circulation in an overhead system is much more rapid than is found in the open tank up-fed system and the results obtained from a given amount of fuel burned are very much greater than those obtained with the up-fed system. The use of this method also lacks one of the objectionable features of the regular two-pipe system; namely, the constant trouble from air accumulating in the upper radiators. The overhead system is installed without the use of air valves as all pipes pitch upward towards the top of the main riser and from this point all air is expelled to the tank, rendering the use of air valves unnecessary.

THE OVERHEAD SYSTEM OF HOT WATER HEATING

3. Q. What is the method of supplying the branches from the various mains at the top of the system?

In order to prevent air pockets which would interfere with circulation all branches are taken from the bottom of the main with a 90 degree or a 45 degree elbow; the 45 degree connection as shown by Fig. 57 is preferred.




Fig. 56.—The Overhead System of Hot Water Heating.

- 4. Q. What method is used to support the large risers carrying the supply of heated water to the top of the system?
- A. As the main riser or risers leading to the upper floor are the largest pipes on the work and contain the greatest weight of water it is difficult to support the same with ordinary hangers, and

it is good practice to use a fitting at the bottom of the riser known as a base elbow which should rest on a brick or cement pier supporting the riser.

- 5. Q. What should be the size of expansion tank for use with the overhead system?
 - A. The same size as for the regular two-pipe system.
- 6. Q. What should be the size of the main riser or risers for the overhead system?
- A. The area of a main riser or risers should be equal to the valve areas of all radiators supplied. This rule is the same as used for the regular system of two-pipe heating.
- 7. Q. What should be the size of the branches supplying the drop risers?




Fig. 57.—Method of Connecting Branch for Overhead System.

- A. The size of branches should be the same as for the two-pipe system. As a rule each branch should have an area equal to the valves on the radiators supplied by it.
- 8. Q. What should be the size of the drop risers for use with the overhead system?
- A. As the water is the hottest at the top of the system and cools and contracts in its descent it would seem that the riser might be reduced in size at the bottom of the system. This, however, is not good practice and on ordinary work it is best to run the drop risers full size to the bottom of the system; this size being sufficient to supply the various radiator connections fed by it. The piping sizes are very important for this system and in many cases are obtained more from practice than by calculation.
- 9. Q. How many valves are necessary on the radiator connections for the overhead system?

THE OVERHEAD SYSTEM OF HOT WATER HEATING

- A. It is customary to use but one valve and this may be placed on the flow or on the return connection as may be desired. It is customary to make the flow connection at the top of the radiator and the return connection at the bottom of the same end of the radiator.
- 10. Q. What should be the size of the radiator valves and connections?
- A. The connections for radiators of 50 square feet or less should be 1 inch. For larger radiators 1½ inch will be sufficient. The velocity of the circulation should be figured on large work and the size of connections should be based upon the velocity of the flow.
 - 11. Q. How should the radiators be connected?
- A. At the top and bottom of one end. It is good practice to run the drop riser near the wall and to make swing joint connections to the radiators.

BOILER, RADIATOR, AND PIPE CONNECTIONS FOR GRAVITY SYSTEMS OF HOT WATER HEATING.

- 1. Q. What trimmings or special appliances should be placed on every hot water system?
 - A. An altitude gauge and a hot water thermometer.
 - 2. Q. Describe an altitude gauge and explain its use.
- A. An altitude gauge is a spring gauge having a dial pointed off and numbered to represent the height of the water above the




Fig. 58.—The O S Fitting.

gauge in feet. It is built on the same principle as a Bourdon steam gauge. Any increase in pressure due to height of the water spreads or opens the hollow curved tube inside of the gauge; this action is transmitted by levers to the pointer on the dial which at once swings around to register the increased height of the water. This pointer is black. An additional red pointer, which is stationary, is placed on the dial. When the system has been completely filled

BOILER, RADIATOR, AND PIPE CONNECTIONS FOR GRAVITY SYSTEM OF HOT WATER HEATING

with water the position of the black pointer showing the height of the water is noted, the face of the gauge removed, and the red pointer is moved with the fingers to a corresponding position. Should the water be lowered by evaporation or otherwise the fact will be shown on the altitude gauge at the boiler, the reduced pressure allowing the black pointer to fall back from its former position and additional water should then be added to the system until the black pointer returns to its former position over the red




Fig. 59.—O S Fittings Used on Drop Supply Risers.

pointer. The loss of water is indicated and the system refilled to the proper height at the basement without the necessity of climbing to the top of the building to examine the water gauge on the expansion tank.

3. Q. What is a hot water thermometer and for what purpose is it employed on a hot water heating apparatus?

A. This thermometer is an ordinary temperature thermometer with the bulb containing the mercury or liquid encased in a thin

brass cup which is usually screwed into an opening or tapping of the boiler arranged for the purpose. Its purpose is to correctly register the temperature of the water in the boiler as a guide for the attendant in adjusting the dampers of the boiler to provide the proper degree of warmth in the building.

- 4. Q. What should be the temperature of the water at the boiler on an open tank system in coldest winter weather?
- A. The best results are obtained from a system with a boiler and radiators of sufficient size to furnish the proper heat with the water at 180 degrees at the boiler; a less temperature than this is better and a higher temperature is not considered economical.
- 5. Q. At what temperature should the water return to the boiler?




Fig. 60.—Radiator Connected at Bottom of Both Ends.

- A. Generally speaking at a temperature not more than 20 degrees cooler than the flow. On a well proportioned job this difference is very much less than 20 degrees.
- 6. Q. What should be the size of the flow pipes out of the boiler?
 - A. The same area as the mains which they feed.
- 7. Q. When a header is used to connect two boilers or two or more openings of the same boiler what should be its size?
- A. The header should have an area equal to or exceeding the area of all mains or flow pipes supplied by it.
 - 8. O. What should be the size of the return header?
- A. The same area as the flow. The return header should always be connected identically with the flow header.

BOILER, RADIATOR, AND PIPE CONNECTIONS FOR GRAVITY SYSTEM OF HOT WATER HEATING

- 9. Q. What special type of fitting is recommended for hot water work?
 - A. The O. S. Distributing Tee.
- 10. Q. What is this fitting and why superior for hot water work?
- A. Fig. 58 shows the character of the fitting. It is particularly serviceable for use on risers to divide the flow between the various floors and saves extra elbows and nipples in making such connections. It is also employed to good advantage on the drop risers of an overhead system. Fig. 59 shows its application.
 - II. Q. Why is it called an "O. S." fitting?
- A. It is so called as O. S. are the initials of the heating engineer who designed and patented it—Oliver Slemmer of Cincinnati, Ohio.




Fig. 61.—Radiator Connected at Top and Bottom of Opposite Ends.

- 12. At what point of a hot water system should the water connection for filling it be made?
- A. At the bottom or lowest point in order to better force the air from the piping and radiators.
 - 13. O. How is the air removed from the radiators?
- A. Through common compression air valves. These are lock and shield valves operated with a key in order that the valve may not be tampered with or inadvertently opened, thus allowing the water in the system to escape.
 - 14. Q. How should a hot water system be filled?
 - A. Open all of the air valves and turn on the water. When the

lower or first floor radiators are partially filled close all of the air valves until the water had reached the floor above; then open the air valves on the first floor radiators one by one until the air in each radiator has escaped and it is filled with water, then proceed to the next floor above and repeat the method. Finally when all radiators are filled allow the water to run until the expansion tank is about one-quarter filled. The system is then ready for firing.

- 15. Q. When radiators are located below the main piping system or on a level of the boiler how should they be supplied?
 - A. By a connection taken from a riser to an upper floor at such




Fig. 62.—Radiator Connected Top and Bottom of Same End.

a height that a pressure from the weight or height of water in the connection will circulate the water through the radiator.

- 16. Q. How are the radiators connected for hot water heating?
- A. On the ordinary system, and also on a circuit system, three methods may be used in connecting the radiators. (a) The flow may be connected at the bottom of one end and the return at the bottom of the opposite end. Fig. 60. (b) the flow may be connected at the top of one end and the return at the bottom of the opposite end. Fig. 61. (c) the flow may be connected at the top of one end and the return at the bottom of the same end. Fig. 62.

BOILER, RADIATOR, AND PIPE CONNECTIONS FOR GRAVITY SYSTEM OF HOT WATER HEATING

- 17. Q. What style of connection is most frequently employed?
- A. The first method with flow and return at bottom of opposite ends.
- 18. Q. How are radiators connected for the overhead system?
- A. Usually with the flow at the top and the return at the bottom of the same end and swing joints are employed on the drop riser in making the connection. Fig. 63.
- 19. Q. What should be the size of the radiator tappings for an ordinary system of hot water heating?
- A. The lower floor tapping should be larger than that for the second or upper floors.




Fig. 63.—Radiator Connected for Overhead System.

20. Q. What is the reason of this?

A. There is a tendency for the hot water in circulation to pass immediately to the upper floors and for this reason the connections for upper floors must be choked by reducing their size and the connections to first floor radiators are favored by increasing their size.

The following table gives the sizes of radiator tappings that will be found best for open tank hot water work. This table varies somewhat from the standard table published by radiator manufacturers:

RADIATOR TAPPINGS FOR HOT WATER.

(Open Tank Up-Fed System)

First Floor.

Size of Radiator	Size of Tapping	
25 square feet or less	3/4 inch	
25 to 50 square feet	1 inch	
50 to 85 square feet	$1\frac{1}{4}$ inch	
85 to 125 square feet	$1\frac{1}{2}$ inch	

Second Floor.

40 square feet or less	3/4 inch
40 to 60 square feet	1 inch
60 to 100 square feet	1¼ inch
100 to 175 square feet	1½ inch

Third and Higher Floors.

50 square feet or less	3/4 inch
50 to 80 square feet	1 inch
80 to 125 square feet	1¼ inch
125 square feet and larger	$1\frac{1}{2}$ inch

Hot Water Radiator Tappings.

(Indirect Heating.)

Size of Radiator	Size of Tapping
50 square feet or less	1 inch
50 to 100 square feet	1¼ inch
100 to 160 square feet	$1\frac{1}{2}$ inch
160 square feet and larger	2 inch

21. Q. What pitch should be given to the mains of a hot water system?

- A. They should pitch up from the boiler from $\frac{1}{2}$ to 1 inch for each 10 feet of length.
 - 22. Q. What pitch should be given to the branches?
 - A. At least 1 inch in each 5 feet of length.
 - 23. Q. What should be the size of the main?
- A. The sizes of the mains are conditioned by the square feet of radiation supplied, which in turn conditions the size of the valves; therefore we may say that the area or size of a hot water main is conditioned by the valve area supplied by it. Its cross sectional area should equal or exceed the area of all valves supplied.

BOILER, RADIATOR, AND PIPE CONNECTIONS FOR GRAVITY SYSTEM OF HOT WATER HEATING

24. O. How are the sizes of branches determined?

A. By the same method. Under ordinary conditions the following table will give the sizes of pipe required to supply a given amount of radiation. This table is compiled from standard authorities and represents the maximum amount of radiation that should be placed on a pipe of any given size.

SIZES OF MAINS AND BRANCHES.

	Mains.	s	Branches and Risers Square Feet of Surface in Radiators.			
Size of Pipe Inches.	Square Feet of Surface In Direct Radiation.	To First Floor.	To Second Floor.	To Third Floor.	To Fourth Floor.	
3/4			40	45	50	
1		50	75	80	85	
$ \begin{array}{c c} 1\frac{1}{4} \\ 1\frac{1}{2} \\ 2 \end{array} $	135	110	120	135	150	
11/2	220	180	195	210	230	
2	350	290	320	350	370	
$\frac{21}{2}$	460	400	490	525	550	
3	675	620	650	690	730	
31/2	850	820	870	920	970	
4	1,100	1,050	1,120	1,185	1,250	
4½ 5	1,350	1,325	1,400	1,485	1,560	
5	1,700					
6	3,600	l			l	

ACCELERATED HOT WATER HEATING.

- 1. Q. What is an accelerated system of hot water heating?
- A. A system in which the circulation of the water is assisted or accelerated by employing some special device which seals the system to the atmosphere and maintains a slight pressure on it. This pressure accumulates until it equals approximately ten pounds or until the water in the system has reached a temperature of 140 or 150 degrees (dependent upon the kind of appliance employed) when it is relieved automatically by the operation of the device which breaks the seal and permits all excess expansion of the water to pass to the expansion tank.
- 2. Q. In what way has the accelerated system an advantage over the sealed tank or ordinary pressure system?
- A. As has already been explained, the employment of a safety valve in sealing the outlet of the expansion tank, in order to operate the system under a pressure, is a dangerous practice. Not so, however, when a special device is used. Such devices are set to work automatically and to operate when the pressure has reached the point at which they are set. Some of the devices at present in use operate with a mercury seal which holds the pressure to a given point, others employ a balanced valve, and still others make use of a spring which controls the mechanism of the valve.
- 3. Q. What are the advantages of an accelerated system over the regular open tank gravity method?
- A. Greater flexibility and a greater range of temperatures. More heat units given off per square foot of radiation per hour, enabling a considerable reduction in the amount of radiation required, and owing to the increased velocity of the circulation much smaller pipe, fittings, and valves are used for the accelerated systems than would be required for the open tank systems.
 - 4. Q. What names are given the devices described?
- A. Generators, Heat Generators, Heat Economizers, Heat Retainers, etc.
- 5. Q. What device was first employed to accelerate the circulation in a hot water system?
- A. It is probable that the Honeywell Generator was the first mercurial device to be used for this purpose and the Phelps Heat

ACCELERATED HOT WATER HEATING

Retainer was one of the first devices of the balanced valve type to be put on the market.

6. Q. What is the construction of the Honeywell Generator?

A. A sectional illustration is shown by Fig. 64. The generator is composed of two hollow castings which are joined by a wrought




Fig. 64.—Sectional View of Honeywell Generator.

iron pipe. The upper casting is elliptical in shape and is called a separating chamber, the bottom casting is bottle shaped. This is called the mercury pot. The illustration shows the general construction of the device. A small pipe called a circulating pipe is held in position on the interior of the pipe connecting the castings.

This connecting pipe is screwed down through the neck of the bottle shaped casting to a point near the bottom of it and a shoe somewhat the shape of a reducing coupling is screwed on the pipe at the lower end. The small circulating pipe is attached to and has its inlet through the side of the shoe. A plug is screwed into the bottom of the lower casting which is then partially filled with mercury, a sufficient quantity (about 1 inch in depth in the mercury pot) being used to hold the pressure in the system until a pressure of 10 pounds has been reached.




Fig. 65.—Generator Connected to System in Basement.

7. Q. What is the action of the generator in operation?

A. The expansion pipe of the system is connected into the side of the bottle shaped casting above the mercury. The pipe leading to the expansion tank is connected from separating chamber at the top of the generator, Fig. 65. The mercury in the generator is between the water in the system and the water in the expansion tank. When the water is cold the mercury lies at the bottom of the mercury pot. As the water in the system is heated it begins to expand, the expansion pressing downward upon the mercury through the side connection to the mercury pot, thus forcing it upward

ACCELERATED HOT WATER HEATING

in the connecting and circulating pipes. The mercury rises higher and higher in the pipes as the pressure increases until a pressure of approximately 10 pounds has been reached, when the generator is in full and complete operation. Fig. 66.

The mercury has now been forced to the top of the pipes and




Fig. 66.—Generator in Full Operation.

begins to circulate, passing upward through the circulating pipe and downward through the larger pipe connecting the castings. The small circulating pipe extends above the larger connecting pipe and the difference in height and weight of the mercuripes starts the circulation. Any water carried upw

mercury through the circulating pipe separates from the mercury in the upper casting or separating chamber. The weight of the mercury holds or maintains the pressure.

- 8. Q. What other mercurial devices are used for accelerated heating?
- A. The Milwaukee Tank Generator, the Pierce Heat Economizer the Klymax Heat Economizer and several others.




Fig. 67.—The Milwaukee Heat Generator.

9. Q. How do these appliances operate?

A. The Pierce Heat Economizer is in many respects quite similar to the Honeywell Generator in construction and operation. The Milwaukee Heat Generator is placed in the upper part of the expansion tank with the separating chamber above the tank. Its appearance is shown by Fig. 67. The Klymax Heat Economizer

ACCELERATED HOT WATER HEATING

is a mercury device placed on the expansion line below the tank or between it and the heating system.

10. O. Describe the Phelps Heat Retainer.

A. The Phelps Heat Retainer operates by the opening and closing of a double acting valve. The valve opening to the tank and atmosphere is weighted and operates only when the water in the system has reached a temperature of 250 degrees or about 16½ pounds pressure.




Fig. 68.—The Phelps Heat Retainer.

The valve is encased in a cast iron boxing and the device is connected to the heating system immediately below the expansion tank. When the pressure increases above 16½ pounds the valve leading to the expansion tank operates, allowing the expansion to reach the tank. When the pressure goes below 16½ pounds the weight closes this valve and the shrinkage of the water opens the retainer valve, allowing it to flow back into the system. Fig. 68 shows the appearance of the device and the method of connecting it to the system.

- 11. Q. What other generator operates on the principle of a double valve?
 - A. The Belknap Generator.
- 12. Q. Describe the installation and operation of the Belknap Generator.
 - A. Fig. 69 shows the interior of the device and the controlling




Fig. 69.—The Belknap Generator.

valves A and B. It is placed on the expansion line between the tank and heating system.

As the water expands a pressure is created against the valve B. The spring of valve A is adjusted to withstand a pressure of 10 pounds. When the pressure rises above 10 pounds valve A opens and allows the excess expansion of the water to pass the tank. As the pressure lowers a vacuum is created in the system which, aided by the static

ACCELERATED HOT WATER HEATING

pressure of the water above the valve, causes it to open and allows the water to return again to the system.

- 13. Q. What other devices are used for placing a system under a slight pressure?
- A. There are several other devices used for the purpose, some operating with valves and some without valves. The B Heat




Fig. 70.—The B Heat Intensifier.

Intensifier is one of the spring valve variety. An interior of this is shown by the illustration Fig. 70, which displays the mechanism of the double acting valve. Like other devices of the kind it is placed on the expansion line under the tank or in the basement near the boiler.

14. Q. What is known as the Honeywell System of accelerated heating?

- A. Mr. M. C. Honeywell in the development of the Honeywell Generator devised, and experimented with, certain styles of pipe connections designed to equalize the flow of the water through the system, and this, together with the generator, has come to be known as the "Honeywell System."
- 15. Q. What size of piping is employed for a Honeywell system as compared with an open tank system?
- A. Pipe sizes are very much smaller for use with an accelerated system due to the fact that smaller valves and radiator connections are employed. The small sizes of piping used are based not alone on valve areas, but on the rate of heat transmission from radiators located at different heights and the velocity of the flow to the radiators thus located.
- 16. Q. What sizes of valves are required for the radiators when attached to an accelerated system?
 - A. For radiators located on first floor.

25 square feet or less	½-inch valve
25 to 50 square feet	3/4-inch valve
50 to 125 square feet	1 -inch valve

For radiators located on second floor:

30 square feet or less	⅓-inch valve
30 to 125 square feet	34-inch valve
125 square feet or more	1 -inch valve

For radiators located on third (or upper) floor:

40 square feet or less ½-inch valve
Over 40 square feet ¾-inch valve

- 17. What rules are given for the successful installation of accelerated piping?
- A. Rule 1. The main should always end at a first floor radiator. If this radiator is 40 square feet or less in size a ¾-inch valve may be used. For radiators exceeding 40 square feet a 1-inch valve should be used, and the size of the main at its termination should be two pipe sizes larger than the connection to the radiator.
- Rule 2. A branch should never be connected from the top of a main. There are three styles or types of radiator or branch connections from the mains as employed on Honeywell or accelerated systems. These are known as the "A," "B" and "D" connections. Fig. 71.

The "A" connection is employed in taking a branch from the main to supply a first floor radiator or a branch to a first floor

ACCELERATED HOT WATER HEATING

radiator which also supplies a riser to an upper floor. This connection is employed only at points where no reduction in the size of the main is made.

The "B" connection is employed for the same purpose at points where a reduction is made in the size of the main in order to relieve it of air which would otherwise collect at this point. The eliminating of air pockets is an important step towards the installation of a successfully working system.




Fig. 71.—Method of Branching From Main.

The "D" connection is employed in taking branches from a main to supply risers to upper floors and may also be used to connect a branch to a first floor radiator located very near the boiler as its use in this manner prevents the short-circuiting of the circulation and materially assists in balancing the job.

Rule 3. As the pipe sizes employed are small, any foreign substance in the pipe will interfere with the circulation and all lengths

of pipe before placing in position should be stood on end and hammered to remove scale or the possible clogging of dirt, and all pipe should be reamed to remove the burr made by the cutting tool.

- Rule 4. When a radiator or a group of radiators are connected from the main at a point very near to the boiler the return circulation is quicker and hotter than that from distant radiators, and it is well to make a separate return connection from them, connecting the return into the side of the main return at the bottom of the boiler. This connection will help to equalize the circulation.
- 18. Q. What sizes of mains are employed for an accelerated system?
- A. The sizes of mains to be used for an accelerated system are determined in the same manner as for an open system, namely, by the valve area of all radiators supplied. The main should never be reduced so that its area is less than the area of all valves beyond the point of reduction.
- 19. Q. Are branches and risers for an accelerated system run or installed the same as for a gravity system?
- A. There is no difference whatever in the method of running branches and risers or connections to upper floor radiators other than has been stated in the rules given. The pitch of the main and the pitch of branches should be the same as for an open tank system.
- 20. Q. Where should the altitude gauge be located on an accelerated system and why?
- A. The altitude gauge should be placed on the expansion pipe leading to the tank above the generator or device employed. It is placed thus to indicate the true height or weight of water in the system. Should it be placed on the boiler as with an open system any pressure registered on the system would be indicated on the gauge, the spring of the gauge opening so that the pointer would not register the height of the water correctly.
- 21. Q. What size of expansion tank should be employed for use with an accelerated system?
- A. The same size as would be employed for an open tank system. There is no difference in the expansion of the body of water in the system, and the tank size should be sufficient to accommodate the increase in bulk through 200 degrees range of temperature.
- 22. Q. What amount of radiation is required for accelerated heating as compared with the open tank system?
 - A. A reduction of 10 to 15 per cent. in the amount of radiation

ACCELERATED HOT WATER HEATING

required for an open system may safely be made for an accelerated system for the reason that range of temperatures is greater with the accelerated system. The limit of temperature with an open tank system is 212 degrees and this temperature is seldom reached without the water boiling. The limit of temperature of an accelerated system, as has already been explained, is 240 or 250 degrees, depending upon the apparatus used, and hence less radiation is required.

23. Q. When it is necessary to place the expansion tank of an accelerated system in a cold room or attic, requiring that it be circulated, what method of installation should be followed?




Fig. 72.—The Honeywell Tank Circulator.

A. The tank cannot be circulated in the ordinary manner without destroying the pressure caused by the accelerator. It is therefore necessary to use a small heater called a tank circulator. This is a hollow casting having an inner and outer compartment. It is connected to the system in such a manner that the hot water in circulation passing through the inner compartment warms the water in the outer compartment which is connected directly to the tank. Fig. 72 shows the Honeywell tank circulator and a method of connecting it to the heating system.

- 24. Q. What method other than those described is used to force or accelerate the circulation through a hot water system?
- A. Pumps are sometimes employed to force the circulation, particularly on large jobs where the water is heated by exhaust steam.
 - 25. Q. What type of pumps is most frequently used?
- A. Pumps of the centrifugal type. These are driven by steam or by an electric motor.
 - 26. Q. What general method of installation is used?
- A. It is common on large work to place the pump in a position to receive the returning circulation and force it through a live or exhaust steam heater, and thence through the heating system. Some systems employ two heaters, one for exhaust, and the other for live steam.
 - 27. Q. What are the advantages of using two heaters?
- A. The coldest water of the return circulation is first forced through the exhaust heater, which tempers it. It then flows through the live steam heater, which heats it to the maximum temperature desired.
- 28. Q. What methods of piping are especially adapted for use with this system?
 - A. The overhead system and the circuit, or one-main, system.

EXPANSION TANK CONNECTIONS.

- 1. Q. What general methods are employed in connecting the expansion tank to a hot water system?
- A. Three methods may be used: (a) Connecting the tank to the system without circulating the water to or in it; (b) connecting the tank to the system in such a manner that there is a circulation of hot water to the bottom of the tank; (c) connecting the tank in such a manner that the water in it will be circulated or heated.




Fig. 73.—Expansion Tank Connection—No Circulation.

2. Q. Describe each of these methods.

- A. (a) This method is illustrated by Fig. 73. The expansion line may be connected from the return of one of the high radiators on the system as shown, or it may be run to the basement and there connect with the return at the boiler.
- (b) The method of connecting the tank to circulate the water to it is shown by Fig. 74. The flow pipe may be connected from any convenient flow riser and the return pipe to any convenient return riser at the top of the system. These are joined together immediately under the tank in the manner shown and the connec-




Fig. 74.—Expansion Tank Connection—Circulation to Tank.

EXPANSION TANK CONNECTIONS

tion to the tank from the top of the loop acts as an air vent, the water passing upward to the tank through the flow and downward through the return as the circulation is established in the system.

(c) The flow connection to the tank should be connected into the side opening of the tank and may be run from any convenient flow riser. The return pipe in this instance is taken from the bottom of the tank and connects with a return riser. Fig. 75 illustrates the




Fig. 75.—Expansion Tank Connection—Circulation in Tank.

method. The tank when connected in this manner should be kept at least one-third full of water, and owing to this fact a larger size of tank than would ordinarily be employed is necessary to give capacity for the natural expansion of the water when heated.

- 3. Q. How should the vent pipe from the tank be connected?
 - A. It may be connected as shown on either one of the illustra-

tions already given. It should always be connected from the top of the tank and should be run through the roof or through the side of the building near the tank. If connection is made through the side of the building the horizontal pipe should pitch slightly towards the outside in order that no water may lodge in the pipe and freeze.

- 4. Q. How should the overflow from the expansion tank be connected?
- A. The vent pipe above referred to may also serve as the overflow pipe or a tee may be placed on the vent pipe immediately above the tank, and the side outlet of the tee used to connect the overflow pipe, or the side tapping of the tank may be used to connect the overflow.
- 5. Q. Is the running or connecting of the overflow into an open plumbing fixture, such as closet tank, advisable or good practice?
- A. No, it is not. If the overflow is connected separately from the vent pipe it should be carried to basement of the building and there be connected into some convenient drain or waste pipe.
- 6. Q. Is the use of valves on expansion tank connections necessary or advisable?
- A. Valves should never be placed on expansion tank connections. These pipes should be kept free and open in order to prevent the possibility of the closing of the system to the atmosphere and thus inadvertently place the same under pressure.
- 7. Q. How can the capacity of a round expansion tank be determined?
- A. Multiply the square of the radius of the tank in inches by 3.1416, then multiply this amount by the length of the tank in inches. Divide this result by 231, which represents the number of cubic inches in a gallon, and the result will be the capacity of the tank in gallons.
- 8. Q. What simple rule may be used for determining the size of the expansion tank required for a hot water system?
- A. For an installation requiring 500 square feet or less allow one gallon of tank capacity for each 30 square feet of radiation.

For 500 to 1,000 square feet of radiation allow one gallon of tank capacity for each 40 square feet.

For 1,000 to 3,000 square feet of radiation allow one gallon of tank capacity for each 50 square feet.

For 3,000 to 5,000 square feet of radiation allow one gallon of tank capacity for each 60 square feet.

EXPANSION TANK CONNECTIONS

This rule, while approximate, is sufficiently accurate for all ordinary work.

Or the following rule may be used:

When there is less than 1,000 square feet of radiation on a job multiply the amount of radiating surface by .03 to determine the size of the tank.

When there is between 1,000 and 2,000 square feet of radiation use the multiplier .025.




Fig. 76.—Expansion Tank Connection—Vertical for Overhead System.

For jobs requiring more than 2,000 square feet of surface multiply by .02.

This is a simple rule easily applied.

9. Q. Where should the expansion tank be located?

A. In a room that is warm in order to prevent freezing. If it is necessary to place the tank in a cold room or in an exposed position in the attic it should always be circulated in order that there

will be no possibility of its freezing in exceptionally cold weather.

- 10. Q. How should the expansion tank be connected to an overhead system of hot water heating?
- A. Fig. 76 shows a method of connecting the tank vertically. This connection may be used on any small job of overhead heating. When connecting the expansion tank to a larger system of hot water heating or one requiring an expansion tank of exceptionally large size it is well to use the tank horizontally and to suspend




Fig. 77.—Expansion Tank Connection—Horizontal for Overhead System.

the same from the roof joints by iron straps, connecting the expansion pipe to the under side of the tank and the vent pipe from the top side of the tank. The overflow may be connected from the top or from the centre of one end of the tank as shown by Fig. 77. If the water gauge is used on a large tank suspended horizontally it should be placed at the end of the tank as shown.

- 11. Q. In general what should be the size of the overflow pipe from an expansion tank?
 - A. It should be the same size as the expansion pipe in order

EXPANSION TANK CONNECTIONS

that there will be no choking of the overflow and the consequent filling up and running over through the vent pipe.

- 12. Q. At what point on a circuit or single main system should the expansion tank be connected?
- A. From the high point of the main, whether this is immediately over the boiler or at any other point on the system.
- 13. Q. When an accelerated system is used what should be the position of the expansion tank, and how should it be connected?
- A. It should be located above the highest radiator as for an open system and connected so that the accelerating device used will be between the tank and the heating system.

DOMESTIC HOT WATER HEATING.

- r. Q. How many methods can be used to heat a supply of water for domestic use?
- A. There are two general methods. First, by heating the water directly as with a water-back in a range, a coil or auxiliary heater placed in the fire pot of a furnace or boiler, or the use of a small tank or gas heater; and second (when steam is available) by placing a steam coil within a tank and heating the water by the condensation of the steam supplied to the coil.
- 2. Q. What kind of tanks are employed for the storage of the water when heated?
- A. The tank may be an ordinary kitchen or range boiler, or if required a special tank of larger capacity, called a storage tank, may be used. The former tank and method of connecting from the water back of the range is so familiar as to require no explanation. The tank should ordinarily be placed above the source of the heat.

A storage tank is a tank of larger size and greater capacity than a range boiler and the tappings of it are so arranged that it may be used in a vertical or in a horizontal position. When used vertically it is supported on an iron stand or legs. When used horizontally it may be hung from ceiling or floor joists with iron straps or rest upon brick, stone or cement piers.

- 3. Q. When a water back or water front is used in a range for heating water how is its capacity figured?
- A. Water backs are commonly rated on the basis of 2 or $2\frac{1}{2}$ square inches of heating surface (the face of the water back only) for each gallon capacity of the kitchen or range boiler. The capacity of a water back is largely increased at times when the range is operated to full capacity for baking, etc.
- 4. Q. When a coil or auxiliary heater is installed in the fire pot of a boiler how is its capacity determined?
- A. Each square foot of surface of a pipe coil installed in this manner will warm from 25 to 30 gallons of water per hour, from 55 to 60 degrees (the usual temperature of the return circulation) to 130 or 140 degrees for domestic use, when the coil is placed in direct contact with the fire.

DOMESTIC HOT WATER HEATING

- 5. Q. How are tank heaters rated when they are used for warming water for domestic use?
- A. The average rating of a tank heater is 250 gallons per hour for each square foot of grate surface. Tank heater ratings are usually excessive, and the fact that a large amount of the heated water is carried in storage, being heated at night or during periods of the day when but little hot water is used, is considered in rating the heater. Ordinarily 50 gallons warmed through 100 degrees would be considered a fair rating for constant service at full capacity.




Fig. 78.—Domestic Hot Water Supply—Vertical Boiler.

- 6. Q. When a storage tank is installed in a vertical position how are the pipe connections made from the boiler to the tank?
- A. Fig. 78 illustrates the usual method employed. The tank is placed on a stand or pedestal at such a height that the bottom of it is above the return connection of the tank heater. The flow from the heater is connected into the side of the tank about one-third distant from the bottom. The cold water supply is connected to the return pipe, which is at the bottom of the tank, and the hot water supply to the various fixtures is taken from the top of the tank.

- 7. Q. When the tank is placed in a horizontal position how should it be connected to the heater?
- A. As shown by Fig. 79. The hot storage water occupies the upper part of the tank and the cooler water in circulation the lower part of the tank. The illustration shows the method of making the various pipe connections.
- 8. Q. When a steam coil is placed within a storage tank what should be its position?
- A. The coil should be fastened vertically in order that the steam will flow in at the top of the coil and the water of condensation will flow out of the bottom. Fig. 80.




Fig. 79.—Domestic Hot Water Supply—Horizontal Boiler.

- g. Q. What size of the coil should be used in a tank?
- A. One square foot of heating surface for each 15 gallons of tank capacity.
 - 10. Q. Is this an economical method of heating water?
- A. It is not, unless a supply of exhaust steam (which would otherwise be wasted) is available for the purpose. Submerged coils condense an immense quantity of steam in heating water.
- II. Q. Of what material should the coil be made for warming water for domestic use?

DOMESTIC HOT WATER HEATING

- A. Copper, brass or galvanized iron. A galvanized coil is less effective than a brass or copper coil for this purpose.
- 12. Q. What provision can be made for relieving excess pressure due to the height of a building or overheated water?




Fig. 80.—Domestic Hot Water Supply—Steam Coil in Boiler.

A. A pressure relief or safety valve may be used. This should be set to operate at five pounds above the normal pressure of the heated water (which may be 150 or 160 degrees) or at five pounds above the static pressure due to the height of the water in the system.

VALVES AND AIR VALVES.

- 1. Q. What types of valves are employed on the various systems or apparatus installed for heating purposes?
- A. Globe, angle, gate and check valves in the regular or some special form.
- 2. Q. What is a globe valve, and for what purpose is it employed?
 - A. The common type of globe valve is illustrated by the sketch,




Fig. 81.—Globe Valve.

Fig. 81, which shows a sectional view of its construction. A bridge supporting the seat is cast in the body of the valve. A disc engaging with this seat is adjusted to the bottom of the valve stem which screws up or down to raise or lower the disc to open or close the valve. The stem passes through the bonnet of the valve and a wheel is provided at the top for operating it with the hand. Globe valves, owing to the restricted area of the opening through the seat, are used principally on steam work.

VALVES AND AIR VALVES

- 3. Q. How should a globe or angle valve be placed on a line of piping?
- A. In such a position that the flow will enter the valve under the seat and against the under side of the disc.
- 4. Q. How should a globe valve be placed on a horizontal, pipe?
 - A. When it is necessary to use a valve of this character on a horizontal pipe it should be placed with the stem in a horizontal position or pitching slightly downward; otherwise, owing to the interior construction of the valve, it will be impossible to obtain perfect drainage through the pipe. Fig. 82 illustrates this feature.
 - 5. Q. What type of valve may be used in any position on a line of piping and yet allow of perfect drainage?
 - A. A gate valve. This type of valve, owing to its construction,




Fig. 82.—Globe Valve on Horizontal Pipe—Imperfect Drainage.

offers no obstruction to drainage. The valve is opened and closed by raising or lowering a wedge shaped gate and when open admits of a full sized free opening through the valve. Fig. 83 shows this construction.

- 6. Q. What is an angle valve?
- A. An angle valve is used in the position of a 90 degree elbow at a point where a change of direction is made in the flow of steam or water.


The name is usually given to the common type of angle valve as illustrated by Fig. 84, although a large share of the radiator valves used are in reality valves of the angle type.

- 7. Q. What is a check valve and for what purpose is it employed?
- A. Fig. 85 illustrates several types of check valves. When it is necessary that the supply of steam or water should flow always

in one direction a check valve is placed on the pipe. The construction of the valve is such that it allows the steam or water to flow in one direction only and prevents any reverse circulation of the same.

8. Q. When extra large valves are required how are they usually constructed?

A. With a yoke over the bonnet of the valve to strengthen it and to provide a suitable guide and bracing for the large stem. Globe, angle and gate valves of large size have this construction. Fig. 86 illustrates a gate valve with yoke.



g. Q. What is the common form of a steam radiator valve?

A. The ordinary type of valve employed in making connection to a steam radiator is an angle valve having a wood wheel and a union connection for attaching to the radiator. Fig. 87 shows an outline of the standard type of valve. The usual steam radiator valve has a Jenkins or composition disc.

10. Q. What is a Jenkins disc?

A. A ring of a composition substance which is attached to the under side of the brass disc and which, when screwed against the valve seat, is intended to make an absolutely tight joint.

11. O. What is a ground seat or Frink seat valve?

A. A valve having the edge of seat and disc ground to a taper of the same degree in order to close tightly when the stem is screwed

VALVES AND AIR VALVES

down and the disc engages with the seat. Some valves of this character have a soft metal disc.

12. Q. What objection is there to the use of a ground or soft metal seat valve on steam piping?





Fig. 84.—Angle Valve.

A. For the reason that they are liable to leak and the slightest leak of steam through a valve when it is turned off will cause no end of trouble and annoyance.








Fig. 85.—Check Valves.

13. Q. What type of valve is used for connecting a hot water radiator?

A. The common form is illustrated by Fig. 88. The angle type of valve is commonly employed. The body of the valve is

cylindrical and a close fitting sleeve is placed on the inside of the body. This sleeve is attached to the stem which turns it, and one side being cut away so that when the sleeve is turned with this opening facing the radiator the valve is open or there is an open passage through it.

14. Q. What special type of radiator valve is frequently used for steam?

A. Valves of the so-called packless type. Packless valves are




Fig. 86.—Gate Valve With Yoke.

modern and a comparatively recent improvement in method of construction.

15. Q. What is the construction of a packless valve?

A. A packless radiator valve is a valve specially constructed so that the hexagon nut at the top of the bonnet does not require any packing around the stem of the valve to make it tight. Packless valves are made for both steam and hot water. Fig. 89 is a sectional view of a packless hot water radiator valve.

VALVES AND AIR VALVES

- 16. Q. What special forms of radiator valves are made for use on steam radiators?
- A. Right and left hand corner and straight-way valves, with and without off-set.
 - 17. O. How are these valves used?
- A. Principally when radiator connections are made above the floor. The corner off-set valves, right or left hand, are made for connecting a radiator directly with a riser above the floor with a swing joint at the riser. The off-set feature of the valve allows of




Fig. 87.—Steam Radiator Valve.

free drainage from the radiator to the riser. When a radiator is connected directly from a riser with a straight connection the straight type of off-set valve may be employed as shown on one-of the radiators illustrating one-pipe connections. Fig. 36.

- 18. Q. What special types of hot water radiator valves are to be had?
- A. Several special types of hot water radiator valves are manufactured; these are used principally in making a flow and return connection to a radiator when both connections are made at or through a single opening at one end of the radiator. The Honeywell Unique radiator valve, Fig. 90, is an illustration of a valve of

this type. The bonnet of the valve is cylindrical in shape and both flow and return pipes are joined to it by union connections quite similar in shape to a regular hot water union elbow. The valve stem engages with a double gate in the form of baffles on the interior of the body of the valve, which are set in such a position that when the valve is open to the radiator there is a passageway through one side of the valve into the radiator. The return circulation from the radiator is divided and separated from the flow by a projecting web in the spud of the valve which extends into the




Fig. 88.—Common Hot Water Radiator Valve.

radiator through one loop or section or sufficiently far to prevent an eddy forming at the inlet and outlet of the valve, due to the flow and return moving in opposite directions. The return circulation entering the bonnet of the valve is directed towards the return connection by one of the gates or baffles inside the valve. By turning the wheel of the valve to close it, the gates are moved to such a position that both flow and return passages into the radiator are closed and the water will then circulate freely from the flow riser through the valve to the return riser without entering the radiator. A very small turn of the wheel (1-6) closes or opens the

VALVES AND AIR VALVES

valve by changing the position of the gates. Fig. 91 is a plan of the valve showing the position of the gates when the valve is open, and Fig. 92 shows the position of the gates when the valve is closed.

Another type of special hot water valve is shown by the illustration, Fig. 93. A fin or baffle divides the body of the valve in the manner shown on the illustration, the flow passing along the top of this baffle and the return from the radiator entering underneath it through special openings at the end of the spud provided for this purpose, the illustration clearly showing the circulation through the valve.




Fig. 89.—Packless Hot Water Radiator Valve.

Other special types of valves are employed for hot water; those illustrated, however, will give a very good idea of the character of the single end valve or valves for connecting both flow and return to a single opening of the radiator.

- 19. Q. For what purpose are air valves employed?
- A. Air valves are used on coils, radiators and piping for the purpose of providing an outlet for the air when it is forced from a heating system by a pressure greater than that of the atmosphere.
 - 20. Q. How many types of air valves are manufactured?
 - A. Two general types. Positive and automatic.

21. Q. What is a positive air valve?

A. The regular type of positive air valve for steam is illustrated by Fig. 94. This valve is provided with a wood wheel or handle for operating it, and must always be opened and closed by hand.

22. Q. What type of air valve is employed on hot water radiators?

A. A positive air valve frequently called a compression valve, having a lock and shield and which is operated with a key, is regularly used on a hot water system when air valves are required. Fig. 95 shows the ordinary shape of this valve.




Fig. 90.—Honeywell Unique Radiator Valve.

23. Q. What improved type of air valve is now almost universally employed on all steam heating apparatus?

A. Automatic air valves. This valve is set so as to be always open when cold. When heated or when steam enters the valve it automatically closes, due to the expansion of some metal, composition, or liquid contained in the body of the valve, either of which is very susceptible to the effect of heat.

24. Q. What types of automatic air valves were first employed?

A. Among the first are the Breckenridge, Jenkins, American and Victor. The Breckenridge air valve operates by the expansion and contraction of a flat brass rod which is anchored or held rigid at each end, allowing the center, to which the valve is attached, to bend when heated, thus closing the exhaust opening to the atmosphere.

VALVES AND AIR VALVES

The Jenkins air valve operates by the expansion of a post made of a composition of hard rubber. This post is held rigid at the outer end by a threaded plug to which it is attached and which is screwed in and out of the body of the valve to adjust it. It is set so that the end of the composition post is slightly away from the air inlet and when heated expands against this outlet, closing the valve.

The Victor and American are quite similar to the Jenkins in operation except they are smaller in size.




Fig. 91.—Unique Valve Open—Sectional View.

25. Q. What is the construction of the later or more recent types of air valves?

A. There are dozens of shapes and varieties to be had. Some valves of later type operate by the vaporizing of a small amount of volatile liquid which is contained in a thin copper float on the interior of the valve to which the valve stem or disc is attached. When steam strikes the float the expansion of the float, due to the vaporizing of the liquid, closes the valve by plugging the inlet shut. Other valves employ an expansion plug and in addition contain a light metal float open at the bottom. Air valves frequently give annoyance by leaking, due to a sudden rush of water in the radiator

which is forced into the air valve by the steam pressure. The light float is intended to overcome this difficulty as a sudden rush of water will raise the float and temporarily close the outlet of the valve. When the water recedes the float will drop and open the outlet to allow the escape of the air.

26. Q. What condition should be guarded against in using automatic air valves?

A. Air valves are frequently ruined by carelessness. They are placed on new work before the boiler has been blown off to remove the greasy scum and dirt from the system, with the result that the




Fig. 92.—Unique Valve Closed—Sectional View.

movable parts of the valve and the small inlet and outlet become clogged with the scum or dirt.

27. Q. How may this condition be avoided?

A. Automatic air valves should not be placed on a heating system until it has been in operation for a period of a week or ten days and has been effectually cleaned of oil and dirt. Common compression valves should be used during this period.

28. Q. What other cause ruins the efficiency of automatic air valves?

VALVES AND AIR VALVES




Fig. 93.—Simplex Hot Water Radiator Valve.




Fig. 94.—Wood Wheel Air Valve.




Fig. 95.—Hot Water Key Air Valve.

A. Certain types of expansion post valves are so delicately sensitive that when adjusted to close at a slight pressure of steam are ruined by being subjected to a high temperature of the steam during a period when a considerable pressure is developed for testing piping or for blowing off the boiler. The carbon post buckles with the expansion due to the high temperature and will never regain its original shape and efficiency.

29. Q. What remedy is there for this condition?

A. Should the valves be in position during this period they should be left open and their adjustment should be deferred until normal conditions of pressure and temperature prevail.

VACUUM, VAPOR, AND VACUO-VAPOR HEATING.

A large share of the many troubles experienced by the steam and hot water fitter in the installation of steam and hot water apparatus for heating are due to the presence of air in the heating system.

Air forming in pockets in various parts of the piping system either blocks the circulation entirely or reduces the efficiency of the apparatus by reducing the effective area of the pipe or radiating surface at the point where the air pocket occurs.

Radiators and coils are often partially air bound. In a steamheating system this is due to the steam reaching and closing the automatic air valve before the air is entirely exhausted from the coil or radiator. Thus the air reduces the square feet of actual radiating surface and the efficiency of the apparatus.

Air has been called the arch enemy of the steam fitter, as it is the one agency against which he must continually fight in order to meet success or in order to install successfully working heating systems.

The development, during the last twenty-five years, of improved methods of heating has resulted in the designing of many appliances for ridding the heating system of air and the troubles due to it, and these methods are variously termed vacuum heating, vapor heating, vapor-vacuum heating, vacuo-vapor heating, etc. Since the year 1882 heating engineers, contracting fitters and others have been interested in the problem of circulating steam at or below the pressure of the atmosphere. They have recognized the loss sustained by allowing the exhaust from engines, pumps, etc., to be wasted, and have evolved a method of utilizing it to the best advantage in the heating system.

The following questions and answers are intended to explain the salient features of each system and to acquaint our readers with the method of their installation and the reasons for applying or using certain special fixtures or devices.

With a knowledge of the principles of vacuum and vapor heating and an understanding of what is to be accomplished by their use it will be seen that the methods adopted are neither complex nor difficult.

1. Q. What is meant by a vacuum?

A. The definition given by Webster states that a vacuum is a space absolutely empty or void of matter.

- 2. Q. Is a bottle empty in the sense that we remove from it its visible contents?
- A. No. The bottle is erroneously called empty, but it is not for the reason that when the visible contents are removed from a vessel it immediately refills with air, an invisible gas containing more or less water. This gas permeates or is forced into every opening or crevice in everything upon the face of the earth by reason of the weight of the atmosphere.
 - 3. Q. How can a vacuum be produced and maintained?
- A. By exhausting the air from the interior of a vessel either by the force of expansion of heat or steam or by employing some mechanical device, and then closing or sealing the vessel against the return of the air, or removing from it the pressure of the atmosphere.
- 4. Q. What is the pressure of the atmosphere, or atmospheric pressure as it is commonly called?
- A. The earth is surrounded to the height of something over forty miles with a belt of elastic gas or atmosphere. This air contains more or less moisture which, owing to its weight, exerts a pressure upon the surface of the earth, and all objects upon it, of approximately 14.7 pounds per square inch.
- 5. Q. Is there a difference in the pressure of the atmosphere at various points upon the earth's surface?
- A. Atmospheric pressure is usually based upon the pressure at sea level; the air at sea level is much more dense than at higher altitudes, consequently the weight of air or atmospheric pressure upon a mountain is much less than at the level of the sea.
- 6. Q. How does atmospheric pressure affect the working of a steam heating apparatus?
- A. Owing to the pressure of the atmosphere water (at sea level) will not boil until a temperature of 212 degrees Fahr. has been reached. By removing this pressure entirely the water will boil at approximately 98 degrees. No steam can be produced or flow through the pipes and radiators of a heating system until there is developed a pressure sufficient to overcome that of the atmosphere.
- 7. Q. How does the pressure of the atmosphere affect the piping and radiation or the steam space of the heating system?
- A. Through the air valve openings of the system the pressure of the atmosphere is exerted against the water in it, and therefore a pressure exceeding that of the atmosphere must be developed at the boiler to drive the air out of the system before the piping and radiators will fill with steam.

VACUUM, VAPOR, AND VACUO-VAPOR HEATING

- 8. Q. What is this pressure called when registered at the boiler?
- A. Gauge pressure, as it represents the pressure on the system, as indicated by the steam gauge, above that of the atmosphere.
 - 9. Q. What is absolute pressure?
- A. Absolute pressure is the gauge pressure shown plus 14.7 pounds, the pressure of the atmosphere. When the steam gauge registers 2 pounds at the boiler there is an absolute pressure on the system of 16.7 pounds, or 2 + 14.7 pounds.
- 10. Q. Can a complete vacuum be produced on a heating system?
- A. No, this is practically impossible; in fact it is unnecessary. Any vacuum whatever shows the absence of air in the system and this is the object of all appliances used for vacuum heating; a very slight vacuum being usually sufficient to produce the desired results.
- 11. Q. How does vacuum heating affect the heating system in the matter of economy of operation?
- A. In a steam heating system a large share of the fuel burned is required to create the pressure necessary to drive the air from the system. This operation must be repeated each time the system is filled with steam, or, as we commonly say, each time steam is raised on the system. With the pressure of the air removed any steam produced at the boiler immediately flows uninterrupted into the various pipes and radiators of the heating system.
- 12. Q. What percentage of fuel is saved by the use of a vacuum system as compared with an ordinary steam heating system?
- A. The saving in fuel is variously estimated at from 20 to 35 per cent. This saving is conditioned largely upon the amount of vacuum maintained on the system and the consequent lower temperature at which the water will boil.
- 13. Q. Is there a difference in the velocity of the circulation between a steam and a vacuum system?
- A. Steam at low pressure may flow through the system at a velocity of anywhere from 20 ft. to 200 ft. per second. The flow of steam in a complete vacuum attains a velocity of 1550 ft. per second. Thus a circulation in the vacuum heating system can be established quickly.
- 14. Q. How is the vacuum on a heating system produced and maintained?
 - A. The first types of vacuum systems were those used in con-

nection with exhaust heating on large installations, and on these systems it was customary to use a pump having a large cylinder, called a vacuum pump or a special type of apparatus called an exhauster to pump or suck the air out of the heating system and to maintain a vacuum. The later types of vacuum appliances, as are used for house heating, are not all mechanical. The vacuum under which many small systems are operated is created by the condensation of steam, special appliances in the way of special air valves, traps, or other devices being employed to maintain the vacuum so produced.

- 15. Q. What other help to a heating system is given by vacuum pump, exhauster, or similar appliance?
- A. The return of the condensation or water to the boiler is hastened, or accelerated, as the pump or exhauster not only sucks or pumps the air, but also sucks or drains the condensation from the various coils and radiators.
 - 16. Q. Of what benefit is this on some types of installations?
- A. It is frequently necessary or desirable to locate radiators or coils below the water line of the system. In this event the pump or exhauster lifts the return water to a height above that of the water line in order that it may be returned to the boiler by gravity.
- 17. Q. What character of piping is used for a vacuum system?
- A. Various styles of installations are used, dependent upon the character of the system employed. An important condition is that the piping be erected absolutely air tight; that the stuffing boxes of all valves be carefully packed and made tight, or that a valve of the packless variety be used, and also that all boiler trimmings should be tight fitting.
 - 18. Q. What is the reason for this precaution?
- A. Should air leak into the system through loose joints or loose stuffing boxes of valves any vacuum developed on the system would be immediately destroyed and the benefits of employing the vacuum appliances would be lost.
- 19. Q. What other features make a vacuum system particularly desirable?
- A. The low cost of installing the system; the employment of a less amount of radiation than would be required for other systems, particularly that required for hot water heating; and the removal of all danger from frosts or leaks, the system being absolutely dry above the basement. The trouble frequently experienced from

VACUUM, VAPOR, AND VACUO-VAPOR HEATING

the inability to drain long runs of piping or, as before stated, any radiation located below the water line of the boiler, is overcome and is a point of efficiency gained by the use of a vacuum system.

- 20. Q. What principle is employed in producing a vacuum by the condensation of steam?
- A. Water, when converted into steam, occupies a space approximately seventeen hundred times as great as it did in the form of water, a cubic inch of water producing seventeen hundred cubic inches of steam. When, therefore, a radiator or coil filled with steam is allowed to cool, but one seventeen-hundredth part of the space is occupied by the water of condensation, the remaining portion of the space filling with air (if the air valve is open) or if the air valve is closed and all connections are absolutely tight, this space is left a void, producing a vacuum in the radiator or coil.
 - 21. O. Can this vacuum be maintained continuously?
- A. It is rather hard to construct an absolutely air-tight system of piping and radiator connections, and therefore a vacuum produced on a heating system will after several hours be destroyed by leakage of air unless some device for maintaining it is employed.
 - 22. Q. How is vacuum measured or registered?
- A. In inches. If a tube of mercury were connected to an air valve opening of a radiator under a vacuum, the suction of the vacuum would pull the mercury a number of inches up the tube. A complete vacuum would raise the mercury 29.92 inches; therefore we speak of the result as having 29.92 inches of vacuum and under this condition the water in the system would boil at a temperature of 98 degrees.
- 23. Q. Give the boiling point of water when the apparatus is under a partial vacuum?
- A. The following table will show the temperature at which water will boil from complete vacuum to a gauge pressure of 10 pounds:

BOILING POINT OF WATER.

Vacuum in Inches. Steam Pressure in Pounds.	Boiling Point of Water of Temperature.	
29 . 92	98 deg	Fahr.
29	100	"
28	102	"
27	114	"
26	125	"
25	133	"
24	140	"

Vacuum Steam Press	in Inches. sure in Pounds.	Boiling T	Point emper	of Water or
23		146	deg.	Fahr.
22		152	Ü	44
21		157		6
20		161		"
19		165		"
18		169		"
17		172		"
Inches 16		175		"
of 15		178		"
Vacuum 14		181		"
13		184		"
12		186		"
11		188		"
10		191		"
9		194		"
8		196		"
7		199		"
6		201		"
5		203		"
4		205		"
3	•	207		"
2		208		"
1		210		"
0	Atmospheric Pressure	212		"
1		215		"
2		219		"
3		222		"
Gauge 4		225		"
Pressure 5		227		"
Pounds 6		230		"
7		232		"
8		235		"
9		237		"
10		440		"

24. Q. What is vapor heating?

A. Vapor heating may be said to be the circulation of vapor or steam at a pressure slightly above that of the atmosphere. This circulation is accelerated or assisted by the use of certain appliances which remove the air pressure and increase the velocity of the flow.

VACUUM, VAPOR, AND VACUO-VAPOR HEATING

- 25. Q. What pressure is ordinarily used on a vapor system?
- A. A vapor system is provided with a controlling device which prevents the steam from attaining a pressure of more than a few ounces, this appliance closing the drafts of the boiler and regulating the amount of heat from the fire.
- 26. Q. What advantage, if any, has the vapor system over the vacuum system of heating?
- A. Practically none, except that the low temperature carried on the apparatus may be considered as an advantage. The range of temperature on a vacuum system may be from the temperature of a low vacuum to any steam pressure desired. The range of temperatures on a vapor system is that obtained from a low vacuum to practically 212 degrees, the boiling point of water.
- 27. Q. What is known as the vapor-vacuum system or a vacuo-vapor system of heating?
- A. A combination of the principles of both vapor and vacuum heating which allows a considerable pressure to be carried on the system when desired, or the system may be operated at as low a temperature as the amount of vacuum produced will allow?
- 28. Q. What amount of radiation is necessary for a vacuum system?
- A. Approximately 10 per cent. less than would be required for the regular type of steam heating apparatus; it being conceded that the removal of all air from the system increases the efficiency of the radiating surface about 10 per cent. and therefore decreases the amount of radiation necessary for use on an open system.
- 29. Q. What amount of radiation is required for a vapor system?
- A. Practically the same amount of radiation as would be required for a regular hot water system of heating, the range of temperatures corresponding very closely to those of an open tank hot water apparatus.
- 30. Q. What amount of radiation is necessary for a vapor-vacuum or vacuo-vapor system?
- A. Approximately 70 per cent. of the radiation required for the open tank hot water system or possibly 10 per cent. more than would be required for vacuum steam system. The amount of radiation required for vacuum heating would be sufficient for vapor-vacuum or a vacuo-vapor heating system, but in order to obtain the best and most economical results the system should be operated at low temperatures, and therefore a slight increase in the amount of radiation is advisable.

- 31. Q. What vacuum systems were first employed for heating?
- A. The Williams, Webster and Paul systems were undoubtedly the first to be used, at least, to any great extent. Mr. N. P. Williams took out the original patents of his vacuum system in the year 1882.
- 32. Q. What is the principle of operation of vacuum heating systems?
- A. The operation of a vacuum system is based upon the flow of steam and condensation from a pressure slightly above into a pressure slightly below that of the atmosphere, or into a partial vacuum. The air in the system is exhausted before turning on the steam, which then flows rapidly into the lower temperature.
 - 33. Q. How may vacuum systems of heating be classified?
- A. First, those systems employed for heating factories or large buildings—mechanical systems we may call them—where exhaust steam or steam at high pressure is available for heating purposes, and a pump, exhauster or other appliance is used to create and maintain the vacuum. The Williams, Webster, Paul, Van Auken and others are of this class. Second, those systems operating without pressure other than that obtained from the ordinary low pressure boiler, the vacuum being maintained by a mercury seal, hydraulic pump or other device. Among these are found the systems of the Vacuum Heating Co. (Trane), the K—M—C System (Morgan Patents), Gorton (Jenkins Bros.), Dunham (C. A. Dunham), Bishop-Babcock-Becker Co., Eddy and several others.

MECHANICAL SYSTEMS OF VACUUM HEATING.

1. Q. Describe the Webster System of vacuum heating.

A. On a Webster system the vacuum is produced by a pump. On the return end of all radiators or pipe coils and at the base of all risers or drainage points a motor valve having a water seal is




Fig. 96.—Webster Motor Valve on Riser.

placed. Fig. 96 shows the valve connected at the base of a riser, a dirt pocket being provided at each low point.

An air trap on the interior of which is a corrugated float partially filled with a volatile liquid which vaporizes at a low temperature is also used in place of the motor valve. This operates much the same as some types of automatic air valves.

When steam is turned into a radiator or coil, the air in it is forced out quickly through the motor valve or trap which closes against the steam. When sufficient condensation has accumulated to lift the float of the valve or trap, the water passes into the return and the float returns to its former position.

The original device used for many years by the Webster Company on the return end of heating units was called a thermostatic valve in which a composition hard rubber post governed the operation of the valve by expansion. The vacuum pump delivers the




Fig. 97.—Paul Exhauster—Low Pressure.

air and condensation together to a separating tank or receiver which is vented to the atmosphere, the air passing out of this vent and the water returning to the system. In the installation of the system the usual exhaust steam specialties such as pumps, separators, feed water heaters, etc., may be used according to the character of the installation.

- 2. Q. Who designed and developed what is known as the Paul System of vacuum heating?
- A. Mr. Andrew G. Paul, an engineer who early realized the value and effectiveness of the vacuum method of heating.

MECHANICAL SYSTEM OF VACUUM HEATING

3. Q. In what way does the method designed by Mr. Paul differ from the Webster System?

A. The Webster system makes use of a pump which relieves the system of air and water through a single return pipe from each radiator connected into main return and air lines, hence all radiators and coils are connected as for the two-pipe system.

The Paul system makes use of an appliance called an exhauster, and the suction of this device being on the air line only the radiators may be connected one or two-pipe as circumstances require.




Fig. 98.—Paul Exhauster—High Pressure.

- 4. Q. What form of air device is placed on each radiator or coil?
- A. A special type of automatic air valve with a drip connection called a Paul air valve.
 - 5. Q. How are these air valves connected to the system?
- A. By air lines. A small air pipe is connected to the drip of each air valve and these air pipes are in turn connected into a larger air pipe or air line which terminates at the exhauster in the base-

ment which produces a suction on the air lines and maintains the vacuum.

6. Q. How is the exhauster constructed?

A. In the form of a steam jet. Fig. 97 shows the construction of the exhauster as used for low pressure, and Fig. 98 the type used for high pressure or larger installations.




Fig. 99.—Paul System—Down Feed Exhaust.

7. Q. How does the Paul System operate?

A. The exhausting device is first started and all air is removed from the piping and radiators and the system is placed under a vacuum. Steam is then turned on and flows through the system quickly, uninterrupted by atmospheric pressure. Fig. 99 shows

MECHANICAL SYSTEM OF VACUUM HEATING




Fig. 100.—Paul System—Regular High Pressure.

the Paul system applied to a single-pipe, down-fed exhaust system, and Fig. 100 its application to two-pipe systems of exhaust heating.

- 8. Q. What are some of the advantages of the Paul System?
- A. (a) It may be applied to any old air bound steam system that is reasonably tight so long as proper means are provided for the return of the water of condensation to the boiler; (b) unlike a pump, the exhauster or jet device has no movable parts to require lubrication or to get out of repair; (c) the economical features are astonishing. It has been repeatedly shown that where the Paul system has been installed in remodeling old systems the saving in fuel for a single season has paid the entire expense of remodeling the system.
- 9. Q. Are the principles used in the Paul system applied to any other systems of vacuum heating?
- A. Yes, in a modified form air exhausters or aspirators are employed. Compressed air from a small air compressor driven by an electric motor can be substituted for steam when steam power is not available for the exhauster.

The vacuum may be maintained on the air lines only or the whole system may be placed under a vacuum.

- 10. Q. How do the Van Auken and other systems operate?
- A. The heating system is drained and the system relieved of air through a special form of automatic appliance attached to the return end of the radiator. That used on the Van Auken system is called a Belvac Thermofier; other systems use air traps. Regardless of the name and construction of each appliance all of them perform the same function, viz., automatically drain the condensation and relieve the air from radiating surfaces of the heating system.
- II. Q. What methods are followed in the construction of all air and condensation traps or valves?
- A. Two distinct principles are used which may be called the flotation principle and the thermostatic principle, and in some valves or traps these principles are in a measure combined.
 - 12. Q. What is the flotation method or principle?
- A. This method is so called from the fact that a float is utilized in the chamber of the trap, usually a metal float, which is loose in the chamber and which rises and falls with the accumulating and relieving of the condensation in the trap, rising to allow the condensation to flow out of the radiator and falling to close the orifice or opening through the trap to prevent loss of steam into the return.

MECHANICAL SYSTEM OF VACUUM HEATING

13. Q. What is the thermostatic principle?

A. In many respects the same as applied to the construction of automatic air valves. The operation of a thermostatic air trap depends upon the fact that steam is hotter than the condensation and that air is heavier than steam and therefore collects at the bottom of a radiator.

In some thermostatic valves an expansion post constructed with a composition of hard rubber is used. In others a volatile liquid is contained in a thin copper receptacle and in either case these expand when heated and contract when cooled. When in contact with the water of condensation the trap remains open to allow the water to enter the return. As soon as the radiator is emptied of water and steam comes in contact with the valve the composition post expands or the volatile liquid vaporizes (causing expansion) and closes the valve against the steam.

NON-MECHANICAL VACUUM SYSTEMS.

- I. Q. Are the vacuum systems known as "non-mechanical" systems operated without the use of mechanical devices?
- A. Not all of them. They seem to be known as non-mechanical systems in order to distinguish them from the mechanical as applied to exhaust or high pressure systems. Many of the vacuum systems applied to ordinary low pressure steam heating or small installations make use of mechanical devices to produce and maintain the vacuum.
- 2. Q. Describe the Trane Vacuum System (Vacuum Heating Company).
- A. The Trane system is a mercurial system; that is to say, the vacuum is held by immersing the end of the air line in a pot of mercury which prevents the air from returning to the system through the air valves after once having been exhausted.
- 3. Q. What is this mercurial device called and how constructed?
- A. It is called a mercury seal. The general construction is shown by Fig. 101. The air line is connected into the top of the seal, the pipe extending through the chamber of it to a point near the bottom. At the bottom of the device is a casting having a hollow cup on the top side which holds the mercury and into which the air line projects. From the side of this chamber a pipe leads to the atmosphere through which the air is exhausted.
- 4. Q. What special appliances are used on the radiators for this system?
- A. Packless radiator valves should be used although a radiator valve with a well-packed stuffing box may be substituted. The radiators may be connected one-pipe or two-pipe as may be desired. The air valves used are a special type of Paul air valve having a large expansion post (Fig. 102) which has a drip connection and from the drip connection of each air valve a small air pipe connects with an air line in the basement. This air line may be carried directly under the cellar joists, terminating at a point near the boiler, where it drops and connects to the mercury seal. The air line should be carefully graded to pitch downward toward the mercury seal.

NON-MECHANICAL VACUUM SYSTEM

5. Q. How does this system operate?

A. Steam generated in the boiler at a few ounces of pressure will flow through the radiators, driving the air out of them through the air valves into the air line and finally out of the system through the mercury seal. The air cannot return through the air line and




Fig. 101.—Trane Vacuum Mercury Seal System.

air valves owing to the mercury seal. By checking the fire a vacuum is produced on the apparatus which can be maintained for several hours. Should any air find its way into the system through a leak or otherwise it may again be expelled by repeating the above operation.

- 6: Q. What range of temperatures may be had by using this system?
- A. A range of temperatures from practically 100 degrees to 250 degrees Fahr. (equaling 15 pounds pressure) may be obtained or used with this system.
- 7. Q. Are any other special appliances necessary for this method of heating?
- A. No further appliances are required other than have been mentioned. In the installation of the system it is well to use extreme care that there is a perfect drip of all condensation into



Fig. 102.—Trane-Paul Air Valve.

the return line and back to the boiler so that all condensation may return to the boiler by gravity. A wet return system of piping is the best method to use and the connections to radiators should be made from the top of the steam main. If only one radiator is connected the vertical air line should be $\frac{1}{4}$ inch and the horizontal line $\frac{3}{8}$ inch in size, and where two or more radiators connect into the same line the pipe should be increased to $\frac{1}{2}$ inch; in the basement the air line risers are joined into a common air line $\frac{3}{4}$ inch or larger according to the size of the apparatus or the number of radiators employed on the work.

NON-MECHANICAL VACUUM SYSTEM

- 8. Q. What method is known as the K-M-C system, designed by D. F. Morgan?
- A. The K—M—C system makes use of a mercury appliance similar to that employed by the Vacuum Heating Company, and in addition to this a small tank, called an accumulating tank, into which the air line connects in order to condense any vapor or steam which might enter into the return line. The air connection from the tank to the mercury seal device passes through floating checks and thence from the mercury or air seal to the atmosphere. When the accumulating tank is placed in a horizontal position the connections to checks and mercury seal are made as shown by Fig. 103. When there is sufficient head room to place the tank in a vertical




Fig. 103.—K-M-C Vertical Checks—Vertical Tank.

position the floating checks are connected as shown by Fig. 104. This illustration does not show the connection to the mercury seal.

- 9. Q. What device is used on the return end of a radiator as an air trap or to prevent the steam from entering the air line?
- A. A special form of air valve called a retainer valve of the shape and character shown by Fig. 105 is employed in place of an ordinary air valve. This valve is of the float and expansion variety and is so constructed as to immediately close when steam enters it.
- 10. Q. What type of radiator valve is employed for use on a K-M-C system?
 - A. A special packless diaphragm radiator valve is recommended.
- 11. Q. How, and of what size, is the air piping installed for use with this system?
 - A. Practically the same as for all other air line systems. A

small pipe connects the bottom of the retainer valve with a horizontal air line, the horizontal connections being made slightly larger than the vertical connections from the radiators. In the event of the air lines from two radiators being connected together the size of piping is increased to ½ inch and the air line proper which is run in the basement may be ¾ inch or 1 inch, according to the size of the job. There should be a continued pitch of the air lines from the radiators to the point where they are connected to the accumulating tank.

12. Q. What is known as the Gorton system of heating?

A. The Gorton system of heating is a vacuum system formerly owned by the Gorton & Lidgerwood Co., now manufactured and marketed by Jenkins Brothers Co. Unlike the systems which




Fig. 104.—K-M-C Vertical Checks—Horizontal Tank.

have been described, the Gorton system makes use of a radiator connection at the top of a radiator, similar to a radiator connected for vapor heating, the return being taken from the bottom of the opposite end. The Gorton system is a two-pipe system. A special type of appliance called a relief valve is connected from the top of a steam main to a relief pipe on the return main and operates in the same manner as an automatic air valve. Fig. 106 shows the method of connecting the relief valve to the heating system. Its purpose is later described under the method of operating this system.

- 13. Q. To what type of heating installations can the Gorton system be applied to advantage?
 - A. The Gorton system is particularly adapted to small or

NON-MECHANICAL VACUUM SYSTEM

moderate sized systems in which the water returns to the boiler by gravity without the use of a pump or other mechanical device, and unlike a number of the non-mechanical vacuum systems the return from the system should be the ordinary dry return, dropping down at the boiler in the usual manner and a loop seal is used at the end of the main.

- 14. Q. What type of radiator valve is employed on a Gorton system?
- A. A fractional, or graduated supply, radiator valve is used on each radiator or unit of radiation, by the use of which the




Fig. 105.—Retainer Valve—K-M-C System.

amount of steam or vapor supplied to each radiator is limited or controlled.

- 15. Q. What type of valve or trap is employed on the return end of a radiator for this system?
- A. A special valve called an automatic drainage or impulse valve is placed at the end of each radiator to connect it with the return, the seat of which is made considerably smaller than the pipe connection. Fig. 107 shows the construction of this valve. The seat is inserted at such an angle as to prevent wedging or sticking and will pass the ordinary dirt in the system without trouble. A cone projects from the disc of the valve into the opening of the seat and a counterweight is applied in such a manner that

they both act to render the opening of the valve very gradual for differences in pressure.

- 16. Q. How is the air removed from the system?
- A. The air removal is accomplished by means of the automatic relief valve illustrated by Fig. 108, which is acted upon by the varying pressures created in the return pipe by reason of the presence of air or steam.
 - 17. Q. What type of radiators are used for this system?
- A. Radiators of the hot water type having top and bottom connections through them.
 - 18. Q. How does the Gorton system operate?
 - A. Steam is generated and enters the main, the friction of its




Fig. 106.-Method of Connecting Relief Valve-Gorton System.

movement causing a slight pressure in the boiler, which communicates to the under side of the diaphragm of the relief valve and closes the air outlet, which remains closed until the pressure passes into the radiators and opens the drainage valve, compressing the air in the return. The relief valve then opens and exhausts this air from the system, the flow continuing until all air passes out of radiators and return pipes and the pressure in the return is sufficiently reduced to allow the relief valve to close. By reducing the weight upon the relief valve a little more than is necessary to close it, and leaving it just heavy enough to open when the system is cooled down, it is very easy to keep the return pipes partially filled with air at all times. This air flows along with the steam and

NON-MECHANICAL VACUUM SYSTEM

cools at the relief valve ready to discharge whenever an additional amount of air is returned from a radiator. Owing to the top connection of the radiator and the graduated supply valve used, any radiator may be partially heated, admitting sufficient steam or vapor to the radiator as may be required by the condition of the weather.

19. Q. What is known as the Dunham system of vacuum heating?

A. The Dunham vacuum system is an air line system in which all air is returned to a receiving tank located above the boiler. A special form of radiator or air trap is the distinguishing feature of the Dunham system, a sectional view of which is shown by Fig.




Fig. 107.—Impulse Valve—Gorton System.

109. These traps are made for a straightway or angle connection. The trap permits the discharge of all water of condensation and air from the radiator without the loss of steam. The end of a pipe loop called an equalizing tube extends into the boiler to a point level with the water line. On the end of this tube is a bell shaped attachment. This equalizing tube is used to keep the pressure in the boiler from communicating itself to the receiving tank until such a time as the water of condensation in the tank (due to the condensation of steam from the boiler) will be sufficient to cause the water in the boiler to lower below the bell of the equalizing tube. At this moment steam from a dome of the boiler rushes

up through the equalizing tube, the end of which is now open in the steam dome, and into the tank; steam entering the tank closes an air valve located at the top and the swing check valves on the return lines connected to the tank, thus equalizing the pressure in the tank with that in the boiler and the water which has accumulated in the tank flows back into the boiler through the check valves at the bottom return openings, raises the water line in the boiler and seals the bottom of the equalizing tube.

The tank is now full of steam and as this steam condenses a vacuum is formed in all of the return lines. Fig. 110 shows the method of making connections to the boiler and tank.

20. Q. What method is used by the Bishop-Babcock-Becker system of vacuum heating?




Fig. 108.—Automatic Relief Valve—Gorton System.

A. The Bishop-Babcock-Becker system is a vacuum system installed with the regular air line method of exhausting the air. To the end of the air line there is attached an hydraulic pump which is so adjusted as to create and maintain any desired vacuum on the apparatus. It produces and maintains the vacuum positively, it being equipped with an automatic cut-off so that when the degree of vacuum has been attained for which this cut-off is adjusted the pump stops, and when the vacuum drops slightly below this point the pump automatically begins to operate, continuing to suck the air out of the system until the desired degree of vacuum is again produced.

21. Q. What method of piping is used for this system?

A. The method of piping employed is similar to that used for the one-pipe system of gravity steam heating. Connections to radiators should be made in such a manner that all condensation

NON-MECHANICAL VACUUM SYSTEM

will return from the radiators to the main through the supply branches, and the drip from the main should convey the condensation to the boiler by gravity. An automatic air valve having a drip connection is placed at the end of each radiator and the air line connections from this drip to an air line main in the basement which terminates at the pump connection. A condensing apparatus is placed near the pump to condense any steam that may be drawn into the air line. Fig. 110 shows the pump and condenser.

- 22. Q. What type of radiator valve is used with the Bishop-Babcock-Becker system?
- A. Any good type of a tight radiator valve may be used although a packless radiator valve is preferred.
- 23. Q. What amount of vacuum should be carried on this system?




Fig. 109.—Dunham Air Trap.

- A. It is usual to operate the pump until there is about 7 inches of vacuum on the system and the automatic cut-off on the pump should then be set to maintain this vacuum.
- 24. Q. What amount of water pressure is necessary for the operation of the hydraulic pump with this system?
- A. This pump can be used where the water pressure is 20 pounds or more and is built in various sizes suitable for any size of heating apparatus.
 - 25. O. How does the Eddy vacuum system operate?
- A. The Eddy system makes use of a combined receiving tank, exhausting and vacuum valve. The system is particularly an air line system, the air lines being installed in the usual manner.
 - 26. Q. Are air valves used with this system?
- A. Air valves are not used. In place of air valves a small appliance known as a retarder is introduced into the air vent opening of each radiator and the air line is connected from the bottom of each retarder.

27. Q. How is the vacuum produced which operates the system?

A. By the condensation of steam, the exhausting and vacuum valve sealing the system to the atmosphere and preventing the




Fig. 110.—Connections to Boiler and Tank—Dunham System.

NON-MECHANICAL VACUUM SYSTEM

return of air into the system after it has once been exhausted. This operation is entirely automatic. It may be operated with steam or vapor at a temperature of 160 degrees or at a pressure of two pounds or more if desired. The range of temperatures obtained in its operation makes the system particularly serviceable.

- 28. Q. What other vacuum systems are in use at the present time?
- A. There are several types of vacuum systems known and used locally in certain sections, each of which, however, embodies some one of the principles described and illustrated in the foregoing systems. Many of these systems are unknown except in a restricted territory.

To properly classify the following systems would be a difficult matter. We have divided them into three classes, viz.: Vapor systems, vapor-vacuum or vacuo-vapor systems, and atmospheric or modulated systems, although some of them might properly be considered in the non-mechanical vacuum class.

Some of the so-called vapor systems make use of vacuum principles and some of those called vacuum-vapor are operated principally as vapor systems.

It would seem that in naming each system the inventor or designer, in many instances, sought to adopt a name which would distinguish his particular system from others of a similar character. The Broomell and Mouat systems are called "Vapor" systems, and that of the Vapor Regulator Company an "Atmospheric Vapor" system. The Moline, Kriebel and Kinealy systems are known as "Vacuum-Vapor" systems, and the Dunham non-mechanical system as "Vacuo-Vapor."

Other systems such as the "Adsco" (American District Steam Company) are known as "Atmospheric" systems, and that of the Warren Webster Company as a "Modulating" system.

Possibly it is sufficient to say that the vacuum systems mentioned and those described on the following pages represent the very latest ideas and practice in the circulation of steam or vapor at or below the pressure of the atmosphere or at a few ounces above atmospheric pressure, and their exact classification is not so important a matter.

The one feature common to all of these systems is that no air valves of any kind are employed on the radiators, all air being removed through an air or return line to the basement and exhausted from the system through some device installed for this purpose.

VAPOR SYSTEMS.

- I. Q. What system of vapor heating may be called the original vapor system?
- A. The Broomell system was no doubt the first vapor system to be extensively used.
 - 2. Q. What method of piping is employed with this system?
- A. Any good method of piping, where a dry line is assured, will prove satisfactory. The sizes of mains and branches are much smaller than those required for an ordinary steam heating system. The return connections from the radiators are all ½ inch and where two are joined together the connection should be made ³⁄₄ inch. The size of the main and return line is proportioned according to the size of the installation.
- 3. Q. What type of radiators is used with the Broomell system?
- A. The hot water type, having the supply tapping at the top of one end; the return tapping is usually at the bottom of the opposite end.
- 4. Q. What amount of radiation is required for the Broomell vapor system as compared with other methods of heating?
- A. About the same as for an ordinary hot water heating apparatus. However, as with all other systems of heating, the best results are obtained from the operation of the system when an adequate amount of radiating surface is installed. The system being very sensitive it is necessary to use only as much of the radiation provided as may be necessary to supply the desired temperature in the room.
 - 5. Q. How are the radiators connected?
- A. At the supply end a special type of radiator valve called a quintuple valve is used and is so named from the fact that each valve has five holes or ports through the seat, and the handle which opens and closes the valve may be moved to open or close one, two or more of these ports as desired. At the return end of the radiator joining it to the return line is placed a special form of union elbow. Fig. 112 shows a sectional view of the valve and Fig. 113 the union elbow.
- 6. Q. For what reason is the special type of radiator valve employed?

VAPOR SYSTEM

- A. In order to admit to the radiator only as much vapor as is required to give the necessary amount of heat. The radiator heats downward, the upper part being first filled with vapor by opening the valve one port and as the valve is opened further the vapor in greater quantity flows into the radiator, heating it further and further toward the bottom until, if desired, the entire surface of the radiator is available for warming.
 - 7. Q. How is the Broomell system regulated?
 - A. An important part-possibly the all important part-of




Fig. 111.—Pump and Condenser—Bishop-Babcock-Becker System.

the Broomell system is the combined receiver and regulator. This controls the draft doors of the boiler and controls the amount of heat furnished to the system.

8. Q. What is the operation of this receiver and regulator?

A. It is connected to the boiler and piping system as shown by Fig. 114. From the top of the receiver the air line is connected to a condensing radiator usually composed of several sections of indirect radiation suspended below the ceiling of the basement.

The receiver operates the draft doors of the boiler by reason of a copper float moving up and down in the receiver according to the expansion of the water, a chain being attached from the float to the draft doors. If the draft door is allowed to remain open in such a manner that the chain from the damper regulator will not operate to close it, the water in the receiver will rise until the copper float engages with and lifts a lever connected with a relief valve which opens the valve and relieves the system of the accumulated pressure.




Fig. 112.—Quintuple Valve—Broomell System.

9. Q. What pressure is ordinarily carried on the boiler with this system?

A. It is usual to set the appliance to open the relief valve at from 7 to 10 ounces of pressure.

10. Q. What is known as the Mouat vapor heating system?

A. The Mouat vapor system is not unlike the system already described. Radiators are installed of similar capacity and are connected the same as on the system already described. At the return end of the radiator a special union elbow connection is provided which prevents the vapor from entering the return piping. A special form of a pressure regulator is used on the boiler which

VAPOR SYSTEM

operates the draft doors and the usual amount of pressure carried on the system is from 5 to 8 ounces. A fractional radiator valve is used on the supply of each radiator; it is placed at the top of one end, the condensation and air being exhausted through the opposite end of the radiator. Fig. 115 shows the character of the installation of the system.

11. Q. How is the piping installed for the Mouat vapor system?

A. The supply main is run in a similar manner to the one-pipe system of steam heating, the drip at the end of each supply line returning wet to the boiler, the mains pitching from the boiler toward this drip connection. The return and air line is vented into the smoke flue and a swing check is employed at a point where it is connected into the return of the boiler.

12. Q. What is the principal feature of the Mouat vapor system?




Fig. 113.—Union Elbow-Broomell System.

A. The Mouat regulator. The regulator or method of regulation is the principal feature of all vapor systems. In other respects the system differs but very little from all systems of a similar nature.

13. Q. Describe the installation of the Trane system of vapor heating.

A. The Trane system is installed in quite the usual manner for vapor heating. A supply pipe with branch connections conveys the vapor through riser connections to the radiators, the supply being connected into the top of the radiator. The return may be connected from the bottom of the opposite end or in the case of second or upper floor radiators the return may be connected from the bottom of the supply end, making it more convenient for running the risers. The Trane system is regulated by a very sensitive diaphragm regulator which is so adjusted as to operate the draft doors at a pressure of from 1 to 6 ounces. The return water of condensation and the air in the system are connected into a receiver,

the water returning by gravity. At the receiver the air and water separate, the air passing through the opening at the top of the receiver and the water returning to boiler through a pipe connecting with the return opening. A float on the inside of the receiver makes it possible to return the water to the boiler at any time and prevents the water from leaving the boiler even under a pressure of several pounds. Fig. 116 shows the appearance of the receiver.

- 14. Q. How is the air exhausted from the radiators?
- A. A union elbow connection is made at the return of each




Fig. 114.—Receiver and Regulator—Broomell System.

radiator. The spud of the elbow connecting to the radiator is closed with the exception of two small openings, one at the top and one at the bottom. The top opening is small for the escape of air and the bottom opening is made larger for the escape of water. The bottom opening is supposed to be completely filled with water at all times, the size of the hole being sufficient to allow the condensation to pass from the radiator to which it is attached.

- 15. Q. How does the Trane system operate?
- A. When a pressure of a pound or more is attained at the

VAPOR SYSTEM

boiler, and the receiver is opened to the atmosphere, water will stand higher in the receiver than in the boiler, the same as would be the case with water in an ordinary water column without a top equalizing connection. As the pressure increases the level of the water rises in the receiver until the float closes the upper open-




Fig. 115.—Broomell Receiver and Regulator Connected to System.

ing. At this time the system is filled and the pressure throughout becomes more uniform, there being so little difference between the pressure in the boiler and receiver that the water of condensation returns to the boiler by gravity. It is intended that sufficient

radiation be installed to warm a building with one or two ounces of pressure or with vapor at a slight pressure above that of the atmosphere. The various appliances used with the Trane system are intended to be so carefully adjusted as to operate the system at this small pressure. Vapor in the radiators is quickly condensed and returning to the receiver at the boiler is separated from the air and enters the boiler to be again quickly warmed. At the same time the system is so constructed that adjustment may easily be





Fig. 116.—Receiver Trane Vapor System.

made for excessively cold weather. Fig. 117 shows the general construction of the system.

16. Q. What types of radiators and valves are required for the Trane system?

A. The radiators should be of the hot water type, having a top and bottom connection, and the radiator valve used should be a graduated radiator valve, or, as they are sometimes called, a fractional valve, in order that the amount of vapor admitted to the radiator may be carefully and easily regulated. As with other vapor systems sufficient vapor may be admitted to warm only



the upper portion of the radiator, or one-half or three-quarters of its surface may be used as required, the amount of surface warmed always being conditioned by the amount of vapor admitted to it.

17. Q. Describe the vapor system of the Vapor Regulator Company.

A. The method of piping employed for use with this system is exactly similar to those already described. The features of the system are the manner of regulating the pressure by a float type of vapor regulator; the manner of draining the radiator of air and condensation through what is known as a bushing trap which may be used on the return end of all drop hub radiators, or through an appliance called a union trap which is used on the return end of any style of radiator. This trap is made in both straightway and angle patterns. The construction of it is not unlike the




Fig. 118.—Regulator, Non-Overflowing Vent and Traps—Vapor Regulator Co.

special union elbow employed with the Broomell system. The idea of both bushing and trap is to prevent the loss of vapor into the return line. Fig. 118 shows a detail of the regulator, non-overflowing vent and traps.

One feature of the piping as used with this system is different from that employed on the ordinary system of vapor heating. A vent pipe is taken from the piping connection at the top of the receiver to a point on the second floor, where it is connected into the smoke flue. On this pipe is placed a non-overflowing vent, the purpose of which is, as its name suggests, to allow the air to be exhausted from the system without the possibility of the water overflowing through the vent pipe should a more than ordinary pressure be generated at the boiler. The radiators are connected

VAPOR SYSTEM

and the graduated supply valve employed precisely as with other vapor systems. Fig. 119 illustrates the method of installing this system.

18. Q. What size of piping is recommended for use with this system?

A. Pipe sizes for this system are not different from other vapor systems and the following table will give the sizes recommended for various quantities of radiation with mains of various lengths. In the event of an increase in the length of main beyond that given in the table the next larger size of supply and return is recommended.




Fig. 119.—Method of Installing Atmospheric System—Vapor Regulator Co.

19. Q. Describe the Moline system of vacuum-vapor heating.

A. The Moline system employs both vapor and vacuum principles designed to operate without the use of pumps or traps and in its general construction is in many respects similar to the ordinary vapor heating systems. The two-pipe method of connecting the radiators is used with the Moline system, one pipe conveying the vapor to the radiators and the other taking the air and water from the radiators; the principal difference between this and other systems being the method of separating the air from the return

water and of keeping the air out of the system by placing it under a partial vacuum.

20. Q. How is the air exhausted from a Moline system?

A. Through an automatic air trap which is a compound air trap and vacuum valve. This is placed on the system at a point near the boiler and is in reality an automatic air valve of such size, however, that it is very quick and efficient in expelling the air, and also prevents loss of steam.

21. Q. How does this air trap operate?

A. The operation of the trap is caused by the expansion and contraction of a small quantity of air contained in an open bottomed float. The usual automatic air valve operates by the expansion and contraction of a small expansion post or by the vaporizing of volatile fluid confined in a small float. These principles are not used on the Moline air trap.

Square Feet of Radiation.	Main Supply.	Dry Return.	Drip.	Length of Pipe.
100	11/4	3/4	3/4	30
175	11/2	1 1	3/4	60
300	2	11/4	84	90
500	21/2	11/4	1	120
800	3	11/2	1	150
1,100	31/2	11/2	1	175
1,600	4	2 2	11/4	200
2,500	5	2	11/2	225
3,600	6	21/2	11/2	250

SIZES OF SUPPLY, RETURN AND DRIP PIPES-VAPOR HEATING.

- 22. Q. For what purpose is the Moline vacuum valve employed?
- A. The Moline vacuum valve seals the piping and radiators against the return of air after it has once been expelled from the system.
- 23. Q. In the removal of air from the Moline system what other appliances are required other than the air trap?
- A. An ejector and condenser. A radiator (usually one of the first floor radiators) is used as a condensing radiator on larger installations; on smaller installations a coil of pipe is used on the ceiling of the basement. A connection from the steam main is made to this coil or radiator. Fig. 120. The appliance called an ejector is placed on this connection and the return from the loop or condensing radiator is connected to the air trap. The steam passing

VAPOR SYSTEM

through the ejector causes a suction which draws the air from the system and delivers it to the air trap, from which it is exhausted to the atmosphere. Fig. 121 shows the method of installation and position of the various fixtures.

24. Q. What is the operation of the Moline system?

A. The first heat from the boiler expands the air and forces it from the system through the condenser, ejector and air trap. As soon as vapor is formed in the boiler it flows through the system and reaching the ejector flows through it with sufficient velocity to draw the air from the air main. This action reduces the air pressure in the radiators and causes a more rapid circulation of the vapor to them. After all radiators are thoroughly heated a small quantity of vapor passes through the ports or openings in the return valves to the condenser. When the condenser becomes heated the vapor travels on to the air trap. After reaching the




Fig. 120.—Ejector and Condenser-Moline System.

air trap it expands a small volume of air in the trap float and closes the opening of the air trap so that no vapor can escape. When the steam pressure is removed at the boiler or the system allowed to cool the air trap cools and opens up, but the vacuum valve closes tightly and prevents the return of air, with the result that the system is placed under a partial vacuum and the heat given off at the radiators condenses as long as there is any vapor in the system. When the drafts of the boiler are again opened and a slight pressure is raised on it above that of the atmosphere the vapor or steam can pass without interruption into all of the radiators the same as on a vacuum installation.

25. Q. What sizes of pipes are used in the installation of a Moline system?

A. The mains and returns should be sized as follows:




Fig. 121.-Method of Installing Moline System,

VAPOR SYSTEM

Square Feet of Radiation.	Size of Main.	Size of Return.		
100 to 300 sq. ft.	1½ inches	1 inches		
300 to 600 ""	2 "	11/4 "		
600 to 1,000 "	2½ "	11/2 "		
1,000 to 1,400 "	3 "	2 "		
1,400 to 1,800 "	3½ "	2 "		
1,800 to 2,500 "	4 "	2 "		
2,500 to 3,500 "	4½ "	2½ "		
3,500 to 5,000 "	5 "	21/2 "		

SIZES OF BRANCHES AND RISERS.

3/4	inch	$\mathbf{w}ill$	supply	60	sq. ft.	in	one	radiator	1/2	inch	return
1	"	"	"	100	"	"	"	"	1/2	"	"
11/4	"	"	"	150	"	"	"	"	8/4	"	"

- 26. Q. What is known as the Kriebel system of heating?
- A. The Kriebel system may be called a vapor system or a




Fig. 122.—Baffler—Kriebel System.

vacuum-vapor system as its installation combines both vapor and vacuum principles of heating.

- 27. O. How is the Kriebel system installed?
- A. The arrangement of the piping is very similar to that required for the ordinary low pressure gravity return steam job. The connections to radiators are made two-pipe, the supply being connected at the top of a radiator and the return and air line connected at the bottom of the opposite end.
 - 28. Q. What size of piping is necessary for this system?
- A. As the Kriebel system operates at a temperature below atmospheric pressure or slightly above it the piping should be the size ordinarily employed for vapor heating, the best results being obtained where a carefully constructed system of piping has been installed.

29. Q. What method is used in connecting the radiators for this system?

A. A graduated supply valve is used in order to more easily govern the amount of vapor or steam admitted to a radiator, and on the return end, in order to prevent the loss of vapor or steam into the return line, there is placed a union elbow in which a small baffler is employed; the baffler being quite similar to the clapper




Fig. 123.—Controller—Kriebel System.

of an ordinary swing check valve, but lightened to such an extent that a very small weight of water will operate it. When sufficient condensation has collected to open the baffler the water is passed through into the return line, when it immediately closes against the steam or vapor. Fig. 122 illustrates this elbow.




Fig. 124.—Circulation Through Radiator—Kriebel System.

30. Q. How is the air expelled from a Kriebel system?

A. Through an appliance known as a vapor-vacuum controller. This controller is in reality an expansion air trap composed of a brass expansion tube and valve held in an iron frame which is attached to the ceiling of the basement at a point near the boiler. This controller has an adjusting device on the valve, a spring holding the seat in place, and there is also provided an air outlet




Fig. 125.—Installation of Kriebel System,

with a baffler. The controller allows all air to escape from the system until sufficient heat reaches it to close it by expansion, when the piping system is held under a vacuum. The character of the controller is shown by Fig. 123.

31. Q. Describe the operation of the Kriebel system.

A. Shortly after the fire has been started in the boiler, the vapor commences to rise from the water in it and to flow through the main supply pipe into the radiators. As the vapor enters the piping the air is forced ahead of it and discharged from the radiators through the bafflers into the air and return line. From there it is ejected from the system through the controller, the controller at this time acting as a large air valve for the entire system. As soon as the heat enters the brass expansion tube of the controller it expands and closes the exhaust opening; this action closes the system against the pressure of the atmosphere.

The system is now filled with vapor or steam and when the drafts of the boiler are closed the system is placed under a vacuum by reason of the action of the controlling device and all radiators will continue to give off heat as long as there is any vapor present in the system. Immediately more heat is provided at the boiler by opening the drafts, the vapor or steam generated flows uninterrupted through all the piping and radiating surfaces. The system is very simple in operation.

The flow of vapor through a radiator is illustrated by Fig. 124. The vapor enters at the top of one end of the radiator, passes to the opposite end and condenses as it settles toward the bottom of each loop. Fig. 125 illustrates the manner of piping and general method of installing the Kriebel system.

ATMOSPHERIC AND MODULATED SYSTEMS.

- 1. Q. What system is known as the "Atmospheric system"?
- A. The Adsco system of the American District Steam Co.
- 2. Q. Describe this system and its method of operation.
- A. This system is adapted for use with the one-pipe circuit or regular one-pipe gravity method of piping. It is not a vacuum system as no vacuum principles are applied. It is intended that only so much steam as is required be admitted to each radiator and for this purpose a graduated supply valve is employed and the supply connection is made at the top of one end of each radiator, which should be of the hot water type; the condensation leaves the radiator through a union elbow at the bottom of the opposite end of the radiator and is returned to boiler through a gravity return, where it is connected into a graduated receiver which is open to the atmosphere through a vent line connected into a chimney flue. The condensation passes by gravity from the bottom of the receiver to the boiler.

The system operates without pressure except that of a few ounces at the boiler.

- 3. Q. What special appliance controls the operations of the boiler?
- A. A combined damper regulator and relief valve which is extremely sensitive and will operate the drafts of the boiler with a few ounces of pressure. It is connected to the boiler in the same manner as the water bottle of a common diaphragm regulator and will maintain an equal pressure at all times.
- 4. Q. What type of boiler is used with this system, and what boiler capacity should be provided?
- A. Any good type of low pressure boiler may be used. The boiler selected should have a low water line so there may be sufficient height in the average cellar or basement from the water line of the boiler to the top of the receiver into which the returns must connect.

The boiler should have at least 50 per cent. more rated capacity than the actual square feet of radiation to be supplied.

- 5. Q. What is the character of the receiver into which the returns are connected?
 - A. A specially constructed cylindrical shaped casting with

openings at the top for air outlet and return connections and an opening at the bottom for drip or return connections to the boiler. On the receiver is placed a scale graduated in ounces and a water gauge, the glass of which is open to the atmosphere.

- 6. Q. Can this system be applied to heating installations other than of the character described?
- A. This system (by the addition of some special gauges, etc.) may be used on high pressure installations (with reduced pressure) or an apparatus receiving the steam supply from a central plant.
- 7. Q. What size of piping is required for the Atmospheric system?
- A. The following table gives the size of main and return piping recommended for installations of various size:

Square Feet of Radiation.	Main Steam Pipe.	Return Pipe.	Length of Pipe of Given Sizes. (See Note.		
50 Feet	3/4 Inch	½ Inch	30 Feet		
75 "	1 "	3/4 "	60 "		
125 "	11/4 "	1 1 "	70 "		
200 "	11/2 "	1 "	70 "		
300 "	2 "	11/4 "	140 "		
600 "	21/2 "	11/2 "	200 "		
900 "	3 "	11/2 "	250 "		
2,200 "	4 "	2 "	300 "		
3,600 "	5 "	2 "	350 "		
6,000 "	6 "	21/2 "	650 "		

SIZES OF MAIN AND RETURN-ATMOSPHERIC SYSTEM.

Note.—If greater length of pipe is required than is given in the table, use next larger size.

8. Q. What is the Webster modulation system of heating?

A. A two-pipe steam system connected with the ordinary type of low pressure boiler and so installed that a pressure of from 8 ounces to 1½ pounds will furnish all heat necessary. There is no pressure on the return lines as they are vented to the atmosphere and therefore no possibility of water hammer in the piping.

Graduated supply valves are used on the radiators (which should be of the hot water type) the connection being made at the top of the radiator. The return is connected from the bottom of the end opposite to the supply and at this point a special automatic device called a water-seal motor is placed which takes the place of the usual valve or air trap on the return.

ATMOSPHERIC AND MODULATED SYSTEM

- 9. Q. What method of piping is employed for this system?
- A. The method of piping is very much the same as that employed for the regular two-pipe gravity system of steam heating, except that smaller sizes of piping are used. No air valves are used or required with this system.

HEATING GREENHOUSES.

- I. Q. What modern methods are employed for warming greenhouses and conservatories?
- A. Steam and hot water systems are both used; steam at low pressure or hot water, both open tank and pressure systems.
 - 2. Q. Which system is more generally employed?
- A. Hot water. There are doubtless four or five hot water systems used to one of steam.
- 3. Q. What reason can be assigned for this favoring of hot water?
- A. Several conditions contribute to this. Thousands of the smaller greenhouses and conservatories are maintained for the propagation of choice flowers for private use and these are invariably heated with hot water. Steam is used more particularly in commercial houses of large acreage in which hothouse vegetables, fruits or flowers are grown for market sale. Houses of this character have firemen who attend the heating apparatus day and night; on the contrary the heating plant in a smaller or private conservatory seldom has night attendance and for this reason hot water heat is preferred, as should the fire for any reason get low the water continues to circulate and give off heat for hours.
- 4. Q. Which type of apparatus is considered to be the best for the propagation of fruit, vegetables, or flowers?
- A. Hot water. The heat from hot water in circulation is mild and the atmosphere in a house heated by hot water is balmy and humid and well adapted to the strong and healthy growth of the plants.
- 5. Q. Which is the more economical system to use—steam or hot water?
- A. Hot water is the more economical with regard to the fuel requirements, and a considerable saving in fuel is effected by using hot water in preference to steam. As the cost of heating is the largest single item of the florists' expenses, this fact no doubt has largely to do with their preference for hot water heat.
- 6. Q. In what shape are greenhouses usually built, and how are they constructed?
- A. As a rule greenhouses are built long and narrow. Some houses have an aisle two and one-half or three feet wide in the

HEATING GREENHOUSES

centre with beds from four to six feet wide on either side. Larger houses have a wide centre bed in addition to those on the sides and consequently have two aisles. The general construction of all commercial houses is similar. They are sided with boarding single or double to the height of the beds; the roof and ends above this line are glass. In low built houses the eaves of the roof begin slightly above the outer edge of the beds. In larger houses there is sometimes a belt of glass between the eaves of the roof and the beds. The pitch of the roof is about one-third to the ridge. Large private conservatories and those in parks and botanical gardens are built in a variety of shapes with all sorts of roof construction, making it necessary to adapt the heating system to the style of construction followed.

- 7. Q. How is the radiation required for heating a greenhouse determined?
- A. The amount of glass surface is alone figured in estimating radiation as practically all of the cooling surface is glass.
- 8. Q. How can the glass surface in the ordinary greenhouse be quickly determined?
- A. For an approximate estimate, when only the dimensions of the house are given, the glass surface may be considered as equal to the length of the building multiplied by the width plus one-third; the one-third allowance being equal to the ends and the pitch of the roof. Should the greenhouse have a belt of glass on the sides and ends, this additional glass surface should be added.
- 9. Q. What temperature must be maintained inside of a greenhouse in zero weather?
- A. The temperature required depends upon the character of the plants or flowers grown. A night temperature is figured on the basis of zero outside and 45 to 55 degrees inside for carnations, 60 to 65 degrees for roses, 55 to 60 degrees for chrysanthemums, etc.
- 10. Q. What kind of radiating surface is employed for green-house heating?
- A. Pipe coils are used almost exclusively on account of the large area of surface covered by a pipe coil and the more evenly distributed heat.
- II. Q. How is the amount of radiating surface required determined?
- A. For steam to obtain the square feet of heating surface divide glass surface by 7 to obtain a temperature of 50 degrees, 6½ for 55 degrees, 6 for 60 degrees, 5½ for 65 degrees or 5 for 70 degrees.

For hot water use as divisors: $4, 3\frac{3}{4}, 3\frac{1}{2}, 3\frac{1}{4}$ and 3. This is for zero weather. For climates where there are protracted periods of temperature below zero add $1\frac{1}{2}$ per cent to the radiating surface for each degree below zero. The following tables while not strictly in accordance with the above rules are considered sufficient for average requirements.

FOR STEAM.

Square Feet	Number Square Feet Radiation Required at							
Glass Exposure.	40 Deg.	45 Deg.	, 50 Deg.	60 Deg.	70 Deg.			
100	11	13	14	17	20			
200	23	25	30	33	40			
300	34	38	43	50	60			
400	45	50	57	67	80			
500	56	63	72	83	100			
1,000	112	125	143	167	200			
2,000	223	250	286	333	400			
3,000	334	375	429	500	600			
4,000	445	500	571	667	800			
5,000	556	625	714	833	1,000			
10,000	1,112	1,250	1,429	1,667	2,000			
20,000	2,223	2,500	2,857	3,333	4,000			
30,000	3,334	3,750	4,286	5,000	6,000			
40,000	4,445	5,000	5,714	6,667	8,000			
50,000	5,556	6,250	7,143	8,333	10,000			

FOR WATER.

Square Feet Glass	Number Square Feet Radiation Required at								
Exposure.	40 Deg.	45 Deg.	50 Deg.	60 Deg.	70 Deg.				
100	17	20	. 25	29	33				
200	33	40	50	57	67				
300	50	60	75	86	100				
400	67	80	100	114	133				
500	83	100	125	143	167				
1,000	167	200	250	286	333				
2,000	333	400	500	572	667				
3,000	500	600	750	857	1,000				
4,000	667	800	1,000	1,143	1,333				
5,000	833	1,000	1,250	1,429	1,667				
10,000	1,667	2,000	2,500	2,857	3,333				
20,000	3,333	4,000	5,000	5,714	6,667				
30,000	5,000	6,000	7,500	8,572	10,000				
40,000	6,667	8,000	10,000	11,429	13,333				
50,000	8,333	10,000	12,500	14,286	16,666				

HEATING GREENHOUSES

Radiation called for by above table is for tight, well-built houses. For poorly constructed houses add at least 10 per cent.

- 12. Q. What boiler capacity is required for this class of heating, and how is the proper size determined?
- A. Greenhouses offer very little resistance to the cold, and therefore require strong boiler power in order to provide quickly for additional warmth to meet the demands of a sudden drop in temperature; therefore ample capacity should be figured. In determining boiler capacity consider 100 square feet of greenhouse coils as equivalent to 125 square feet of cast iron radiation.




Fig. 126.—Method of Piping a Greenhouse.

Reserve equal to 50 per cent. of the total actual requirements should be provided.

- 13. Q. What method of piping is employed in installing a heating apparatus for a greenhouse?
- A. The system commonly called the "overfed system" is most frequently used owing to the benefit derived from a more even distribution of the heating surface.
 - 14. Q. Describe the overfed system and method of piping.
- A. It is usual for the flow main (or mains—there may be more than one) to enter the house at the end nearest the boiler and to run overhead to the far end of the house, the pipe being hung on

the centre posts supporting the roof. At the far end this pipe is divided, the branches dropping to supply coils usually run under the beds. The flow pitches downward to the far end of the house and the coils pitch downward toward the boiler end; thus there is perfect drainage provided which insures a good circulation. At the boiler end of the house the returns from coils are usually con-




Fig. 127.—Elevation of Greenhouse Piping System.

nected together into a single pipe which leads to the return of the boiler. Fig. 126 illustrates this method.

- 15. Q. Is there a difference in the method of piping for hot water or steam heating?
- A. The general arrangement of the flow and also of the return coils is similar for both systems. If hot water is used the air is exhausted from the system from the high point of the piping through the expansion tank connection at this point.

HEATING GREENHOUSES

- 16. Q. Where is the expansion tank located, and how should it be connected?
- A. In building a greenhouse it is usual to erect a potting shed at one end. This portion of the building is usually excavated for a cellar or pit to accommodate the boiler and in many instances has a second floor for use as storage or for the use of the man who attends the heating apparatus. The tank is located in this building well above the high point of the piping and it is connected to the system in the same manner as for the regular overhead system of hot water heating. Fig. 127 shows an elevation of a small house and potting shed.
- 17. Q. How and where should valves be placed on a heating system for a greenhouse?
- A. It is customary to divide the piping into two or more coils according to the size of the house, and each section or unit of radiation should be so valved that a part of the heating surface may be cut out in moderate weather when only a portion of it is required to maintain the desired temperature.
- 18. Q. Is an accelerated or pressure system adapted to this class of heating?
- A. Pressure systems are very commonly employed, a safety valve being used on the outlet of the expansion tank. Accelerated systems may be readily adapted to this work and in the case of exceptionally large plants centrifugal pumps can be employed to advantage.

The rules, tables and data given on the following pages have been compiled with great care from competent authorities, and the author believes the same to be thoroughly reliable.

For reference the information given will prove of value and service when used in connection with practical experience.

ATR.

Air is an elastic gas composed of 1/5 oxygen and 4/5 nitrogen, and a small amount of carbonic acid gas.

Air expands 1/179 of its bulk. Air may be compressed to liquid form.

One pound of air contains 13,817 cubic feet.

The weight of one cubic foot of air at 32 deg. Fahr. is .080728 pound. At 86 deg. Fahr. a cubic foot of air weighs .07286 pound.

It requires .02056 heat unit to raise the temperature of one cubic foot of air one degree, or 1.4392 heat units to raise the temperature of a cubic foot of air from zero to 70 deg. Fahr.

Theoretically it requires 12 pounds of air to burn 1 pound of coal. Practically 16 to 18 pounds of air may be used.

The pressure of the air (atmospheric pressure) is 14.7 pounds at sea level. The earth is surrounded by a belt of atmosphere something more than forty miles in thickness. The weight of this air presses down upon the earth, exerting an average pressure of 14.7 pounds per square inch.

Air contains more or less moisture (aqueous vapor), the amount varying with the temperature. Air at a temperature of 32 deg. Fahr. can sustain vapor equal to one one hundred and sixtieth (1/160) part of its own weight. At 86 degrees it can sustain one one hundred and fortieth (1/140) part of its own weight.

WATER.

Water is composed of two parts hydrogen and one part oxygen. Water weighs $62\frac{1}{3}$ pounds per cubic foot, or $8\frac{1}{3}$ pounds per gallon, and there are $7\frac{1}{2}$ gallons in a cubic foot.

Water is at its greatest density and occupies the least space at 39 deg. Fahr.

Water freezes at 32 deg. Fahr. and boils (at sea level) at 212 degrees. It expands 1/10 of its bulk in freezing and 1/23 of its bulk in boiling.

186

Water boils at a lower temperature as atmospheric pressure is removed; therefore the higher above sea level the lower the temperature of the boiling point.

Water expands about 1700 times its volume in changing into steam. One cubic inch of water produces one cubic foot of steam.

Water in circulation is the best known absorbent of heat (excepting mercury) and has greater specific heat than any other liquid.

Water in a radiator at a temperature of 180 degrees—temperature of room 70 degrees—emits or gives off to the air 150 B. T. U. per square foot per hour.

The water contained in a cast iron radiator of the ordinary type is approximately one pint for each square foot of radiator surface.

It requires 966 B. T. U. to evaporate 1 pound of water into steam from and at 212 degrees; 34.5 pounds of water evaporated from and at 212 degrees equals one horse-power.

A column of water 27.672 inches high gives a pressure of one pound. A common estimate is one-half pound pressure for each foot in height.

STEAM.

Steam is the vapor arising from water at or above its boiling point, 212 degrees. Steam proper is perfectly transparent and colorless, dry, and wholly invisible except when partly condensed. It is moist only when condensed.

Saturated steam is steam which, in contact with the fluid from which it is formed, carries with it a proportion of its moisture.

Superheated steam is steam heated to a temperature higher than is due to its pressure after leaving the fluid from which it is formed.

The elastic force of steam is equal to the pressure under which it is generated. For example, if generated to a pressure of 50 pounds and freed, its elastic force free will be 50 pounds.

Steam rising from water at its boiling point (212 degrees) has a pressure equal to that of the atmosphere (14.7 pounds per square inch) and at this pressure one pound of steam contains 27.222 cubic feet.

Steam in a radiator at a temperature of 3 to 5 pounds—temperature of the room 70 degrees—emits or gives off to the air of the room 250 B. T. U. per square foot of radiating surface per hour.

FUEL.

Fuel is any substance that can be burned to produce heat. The common varieties of fuel are wood, peat, lignite, coal, gas and oil. Coal is the principal fuel in the United States and many other

countries of the world. Coal is ordinarily classified as anthracite and bituminous, or hard and soft coal.

Anthracite is the hardest of all varieties of coal, richest in carbon and greatest in density. Anthracite is almost entirely a product of the State of Pennsylvania.

"True anthracite, when pure, is slow to ignite, conducts heat very badly, burns at a very high temperature, radiates an intense warmth, and is difficult to quench."—Barr.

Bituminous coal is a "soft" coal containing a large amount of volatile (gaseous) matter which burns with a smoky flame. It is found in various parts of the United States, the better grades coming from Pennsylvania.

More than 2,000 years ago coal was mined and used in certain parts of the Chinese empire and had been known for years prior to that period.

Virginia coal (bituminous) was mined as early as 1750. Anthracite coal was mined in the Wyoming Valley near Wilkes-Barre in 1768. Coal was mined in the years 1770, 1776, and 1791 in other sections of Pennsylvania.

The calorific values of fuel of various kinds average about as follows:

Anthracite coal, 12,000 to 14,500 B.T.U. per pound. Bituminous coal, 11,000 to 15,500 " " "

Petroleum (raw), 18,500 to 20,000 " " "

Wood, $2\frac{1}{4}$ pounds of dry cord wood equals 1 pound of coal.

For low pressure heating purposes, from 5 to 7 pounds of coal per hour are usually considered for each square foot of grate; for high pressure, 12 to 15 pounds per hour for each square foot of grate.

Three tons of anthracite coal per heating season for each 100 square feet of steam radiation and $1\frac{1}{2}$ tons for each 100 square feet of hot water radiation for the heating season is considered a fair average of fuel consumption.

Fifty pounds of anthracite or 40 pounds of soft coal will occupy a space equal to one square foot of grate.

A ton of hard coal occupies space equal to 37 cubic feet; a ton of soft coal occupies 40 cubic feet of space.

MISCELLANEOUS.

Horse-Power.

One horse-power is the power required to raise 33,000 pounds one foot high in one minute; or

The evaporation of 30 pounds of water per hour from a feed water temperature of 100 deg. Fahr. into steam at 70 pounds gauge pressure. This is equivalent to 34½ pounds from and at 212 deg. Fahr.

Tank Capacity.

To find the number of gallons in a round tank multiply the diameter in inches by itself and the result by 0.34.

To find the number of gallons in a rectangular tank determine the cubical contents by multiplying together the length, breadth and height. Multiply this result by 7.48 (the U. S. gallons in one cubic foot).

Mensuration.

Diameter \times 3.1416 = Circumference.

Diameter \times 0.8862 = Side of an equal square.

Diameter squared \times 0.7854 = Area of a circle.

Circumference + 3.1416 = Diameter.

· Circumference + 6.28318 = Radius.

Circumference $\times \frac{1}{4}$ the diameter = Area of circle.

Square inches $\times 0.007 =$ Square feet.

Cubic inches \times 0.00058 = Cubic feet.

Surface in Pipe Coils.

To ascertain the lineal feet of pipe to use when heating by pipe coils, multiply the square feet of radiating surface required as follows:

For	1 -	-inch	pipe	multiply	radiating	surface	by	0.3
		- "		"	"	"		
"	11/2	- "	"	"	"	"	"	2.0
"	2 .	_ "	"	66	"	"	"	1 6

Blowing Off Boiler.

To remove oil and greasy scum from a boiler it should be blown off under pressure.

Close the valves on supply and returns, or, if none, close all radiator valves. Build a wood fire and generate a pressure of ten or twelve pounds, then open the blow-off valve and draw the fire, open all doors and allow the boiler to thoroughly cool before closing the blow-off cock. When cold refill and build the fire.

Boilers on new work should be blown off two or three times at intervals of two to three weeks. Boilers on old work should be blown off every fall before starting a coal fire.

To Clean a Water Gauge.

To clean the glass gauge on the water column without removing the same, add a teaspoonful of muriatic or other raw acid to a cup of hot water; close both water gauge valves.—Open the draw-off or pet-cock at the bottom and the upper water gauge valve and blow the water out of the glass, then immediately close the top valve and submerge the end of the pet-cock in the acid solution. The vacuum caused in the gauge glass sucks in the solution. By keeping the pet-cock in the solution and alternately opening and closing the upper gauge valve, the solution may be drawn into and expelled from the glass until it is clean. Finally, close the pet-cock and open both gauge valves. There should be one or two pounds of steam pressure on the boiler at the time of the operation.

The Care of a Heating Apparatus.

Proper care of a heating apparatus adds largely to its record of efficiency.

All valves upon a steam job should be left open in the summer when not in use.

Hot water apparatus when unused during the summer should always remain filled with water. This prevents rusting. All doors on the heater should be open and the smoke pipe should be taken down and cleaned and the boiler thoroughly cleaned of ashes and soot.

In the fall before starting a fire the hot water apparatus should be emptied and then refilled with fresh water.

Heating Surface in Tubular Boilers.

To ascertain the heating surface in tubular boilers multiply twothirds the circumference of the boiler by the length of the same in inches and add to it the outside surface of all the tubes.

Strength of Tubular Boilers.

One-sixth of the tensile strength of plate multiplied by the thickness of the plate and divided by one-half the diameter of the boiler gives a safe working pressure for boilers having single riveted longitudinal seams. For boilers having double riveted seams add 20 per cent.

Chimneys.

The chimney has rightly been called the pulse of the heating system. When called to look at a "sick" job of heating the first

move should be to test out the pulse of the system—the chimney—for here lies 90 per cent. of all trouble.

A study of chimneys and their peculiarities is one of the first requirements of the doctor of heating—otherwise the heating engineer.

Bronzing and Painting.

The work of a heating contractor, in a large measure, is judged by the neatness displayed in finishing a job.

Radiators and exposed piping look best when treated with plain gold or aluminum bronze, the surfaces having first been primed with a coat of flat color, white or light gray if aluminum is to be used, or yellow ochre if gold is selected.

A pound of gold bronze and a quart of liquid will cover 100 feet of direct radiation. Aluminum bronze having more bulk requires about ½ pound for 100 feet of radiation.

TABLE I.

BOILING POINTS OF FLUIDS.

Ammonia140 deg. Fal	nr. Phosphorus554 deg. Fahr.
Alcohol173 . "	Sulphur570 "
Benzine 176 "	Sulphuric Acid590 "
Water 212 "	Linseed Oil597 "
Sea Water213 "	Mercury 676 "

TABLE II.

TEMPERATURE OF FIRE.

Approximate—Judged by its Appearance Table of M. Pouillet.

Appearance of Fire.	Te	emperature.
Red, Just Visible	977	deg. Fahr.
Red, Dull	1290	"
Red, Cherry Dull	1470	"
Red, Cherry Full	1650	"
Red, Cherry Clear		"
Orange, Deep		46
Orange, Clear	2190	"
White Heat	2370	"
White, Bright	2550	"
White, Dazzling	2730	"

TABLE III.

APPROXIMATE MELTING POINTS OF METAL.

Mercury39 d	eg. Fahr.	Silver 1850 deg	g. Fahr.
Tin 442	"	Brass1900	"
Bismuth 510	"	Gold2100	"
Lead 618	"	Copper1975	"
Zinc 750	"	Cast Iron2100	"
Aluminum1150	"	Steel	"
Bronze1692	"	Wrought Iron .2850	"
Alloy, 3 Lead, 2 Tin, 1	Bismuth	199	"
Alloy, 1½ Tin, 1 Lead.			"
Alloy, 1 Tin, 1 Lead		466	"

TABLE IV.

Size	Area	Size	Area	Size	Area	Size	Area
1/8	0.0123	10	78.54	30	706.86	65	3318.3
1/4	0.0491	1/2	86.59	31	754.76	66	3421.2
3/8	0.1104	11	95.03	32	804.24	67	3525.6
1/2	0.1963	1/2	103.86	33	855.30	68	3631.6
5/8	0.3067	12	113.09	34	907.92	69	3739.2
1/8/4/8/2/8/4/8	0.4417	1/2	122.71	35	962.11	70	3848.4
7/8	0.6013	13	132.73	36	1017.8	71	3959.2
1	0.7854	1/2	143.13	37	1075.2	72	4071.5
1/8	0.9940	14	153.93	38	1134.1	73	4185.3
1/8/4/8/1/2/8/3/4/8	1.227	1/2	165.13	39	1194.5	74	4300.8
3/8	1.484	15	176.71	40	1256.6	75	4417.8
1/2	1.767	1/2	188.69	41	1320.2	76	4536.4
5/8	2.073	16	201.06	42	1385.4	77	4656 .0
3/4	2.405	1/2	213.82	43	1452.2	78	4778.3
7/8	2.761	17	226.98	44	1520.5	79	4901.6
2	3.141	1/2	240.52	45	1590.4	80	5026.5
1/4	3.976	18	254.46	46	1661.9	81	5153 .0
1/2	4.908	1/2	268.80	47	1734.9	82	5281.0
1/2 3/4	5.939	19	283.52	48	1809.5	83	5410.6
3	7.068	1/2	298.64	49	1885.7	84	5541.7
1/4 1/2 3/4	8.295	20	314.16	50	1963.5	85	5674.5
1/2	9.621	1/2	330.06	51	2042.8	86	5808.8
3/4	11.044	21	346.36	52	2123.7	87	5944 .6
4	12.566	1/2	363.05	53	2206 .1	88	6082.1
1/2	15.904	22	380.13	54	2290.2	89	6221.1
5	19.635	1/2	397.60	55	2375.8	90	6361.7
1/2	23.758	23	415.47	56	2463.0	91	6503.8
6	28.274	1/2	433.73	57	2551.7	92	6647.6
1/2	33.183	24	452.39	58	2642 .0	93	6792.9
7 -	38.484	1/2	471.43	59	2733 .9	94	6939.7
1/2	44.178	25	490.87	60	2827.4	95	7088.2
8	50.265	26	530.93	61	2922.4	96	7238.2
1/2	56.745	27	572.55	62	3019.0	97	7389.8
9	63.617	28	615.75	63	3117.2	98	7542.9
1/2	70.882	2 9	660.52	64	3216 .9	99	7697.7

TABLE V.

CHIMNEY FLUES.

Steam *Square Feet	Water *Square Feet	Height of Chimney in Feet.						
Rated Boiler Capacity	Rated Boiler Capacity	30	40	50	60	80	100	
250	375	7.0						
500	750	9.2	8.8	8.2	8.0			
750	1,125	10.8	10.2	9.6	9.3	8.8	8.5	
1,000	1,500	12.0	11.4	10.8	10.5	10.0	9.5	
1,500	2,250	14.4	13.4	12.8	12.4	11.5	11.2	
2,000	3,000	16.3	15.2	14.5	14.0	13.2	12.6	
3,000	4,500	18.5	18.2	17.2	16.6	15.8	15.0	
4,000	6,000	22.2	20.8	19.6	19.0	17.8	17.0	
5,000	7,500	24.6	23.0	21.6	21.0	19.4	18.6	
6,000	9,000	26.8	25.0	23.4	22.8	21.2	20.2	
7,000	10,500	28.8	27.0	25.5	24.4	23.0	21.6	
8,000	12,000	30.6	28.6	26.8	26.0	24.2	23.4	
9,000	13,500	32.4	30.4	28.4	27.4	25.6	24.4	
10,000	15,000	34.0	32.0	30.0	28.6	27.0	25.4	

^{*}Indirect radiation should be made equivalent to direct radiation by adding 50 per cent.

TABLE VI.

PRESSURE IN INCHES OF WATER BY SIPHON DRAFT GAUGE.

Height Water Inches	Pressure per Pound	Velocity Feet per Second	Velocity Feet per Minute	Height Water Inches	Pressure per Pound	Velocity Feet per Second	Velocity Feet per Minute
.1	.521	15.05	903	1.1	5.731	49.9	2994
. 15	. 781	18.17	1090	1.15	5.991	57.0	3060
. 2	1.042	21.3	1278	1.2	6.252	52.1	3126
. 25	1.302	23.05	1090	1.25	6.512	53.2	3189
. 3	1.563	26.06	1564	1.3	6.773	54.2	3252
. 35	1.823	28.08	1685	1.35	7.033	55.3	3315
. 4	2.084	30.1	1806	1.4	7.294	56.3	3378
. 45	2.344	31.76	1911	1.45	7.554	57.4	3415
. 5	2.605	33.6	2016	1.5	7.815	58.2	3492
. 55	2.865	35.2	2112	1.55	8.075	59.3	3523
. 6	3.126	36.8	2208	1.6	8.336	60.2	3612
. 65	3.386	38.3	2298	1.65	8.596	61.3	3666
.7	3.647	39.8	2388	1.7	8.857	62.0	3720
.75		41.2	2469	1.75	9.117	63.1	3774
.8	4.168	42.5	2550	1.8	9.378	63.8	3828
. 85	3.907	43.8	2628	1.85	9.638	64.9	3882
. 9	4.689	45.1	2706	1.9	9.899	65.6	3936
. 95	4.949	46.3	2778	1.95	10.159	66.7	3987
1.0	5.210	47.5	2850	2.0	10.420	67.3	4038

TABLE VII.

AMOUNT OF VACUUM SECURED AT DIFFERENT TEMPERATURES.

V	Vacuum Gauge Inches of Vacuum		Temperature of Steam or Boiling Point of Water			Vacuum Gauge Inches of Vacuum			Temperature of Steam or Boiling Point of Water.		
0 .	Atmosphere	212	Deg.	Fah.	16 I	nches	175	Deg.	Fah.		
1	"	210	"	"	17	"	172	"	"		
2	"	208	"	"	18	"	169	"	"		
3	"	207	"	"	19	**	165	"	"		
4	"	205	"	"	20	"	161	"	"		
5	"	203	"	"	21	"	157	"	"		
6	"	201	"	"	22	"	152	"	"		
7	"	199	"	"	23	66	146	"	"		
8	6 2	196	"	"	24	"	140	"	"		
9	"	194	"	"	25	44	133	"	"		
10	"	191	"	"	26	66	125	"	"		
ii	"	188	"	66	27	"	114	"	"		
12	"	186	"	"	28	"	102	"	"		
13	"	184	"	"	29	u	100	"	"		
14	**	181	"	"	29.7	7 46	98	"	"		
15	"	178	"	"					_		

TABLE VIII.

VELOCITY OF FLOW OF WATER

In Feet per Minute, Through Pipes of Various Sizes, for Varying Quantities of Flow.

Gals. per Minute	inch	inch	inch	inch	2 inch	21/4 inch	3 inch	4 inch
5	218	1221/2	781/2	541/2	301/2	191⁄2	131/2	73/9
10	436	245	157	109	61	38	27	151/6
15	653	3671/2	2351/2	1631/2	911/2	$58\frac{1}{2}$	401/2	23
20	872	490	314	218	122	78	54	303/
25	1090	6121/2	3921/2	2721/2	1521/2	971/2	$67\frac{1}{2}$	381/3
30		735	451	327	183	117	81	46
35		8571/2	5491/2	3811/2	2131/2	1361/2	$94\frac{1}{2}$	53 3 ⁄3
40		980	628	436	244	156	108	611/3
45		11021/2	7061/2	4901/2	2741/2	1751/2	$121\frac{1}{2}$	69
50		'-	785	545	305	195	135	763/
75		ł	11771/2	8171/2	4571/2	$292\frac{1}{2}$	$202\frac{1}{2}$	115
100		1	1	1090	610	380	270	1531/
125		l	ļ		7621/2	4871/2	3371/2	
150		i	Ī		915	585	405	230
175]			10671/2	$682\frac{1}{2}$	$472\frac{1}{2}$	
200		1			1220	780	540 ¯	30633

TABLE IX.

B. T. U. REQUIRED FOR HEATING AIR.

This table specifies the quantity of heat in British thermal units required to raise one cubic foot of air through any given temperature interval.

Exter-										
nal Temp.	40°	50°	60°	70°	80°	90°	100°	110°	120°	130°
-40° -30° -20°	1.540 1.290	1.760 1.505	1.980 1.720	2.479 2.200 1.935	2.420 2.150	$2.640 \\ 2.365$	2.860 2.580	3.080 2.795	3.300 3.010	3.520 3.225
-10° 0° 10° 20° 30° 40°	0.822 0.604 0.393 0.192 0.000	1.028 0.805 0.590 0.385 0.188	1.234 1.007 0.787 0.578 0.376	1.208 0.984 0.770 0.564	1.645 1.409 1.181 0.963 0.752	1.851 1.611 1.378 1.155 0.940	2.056 1.812 1.575 1.345 1.128	2.262 2.013 1.771 1.540 1.316	2.467 2.215 1.968 1.733 1.504	2.673 2.416 2.165 1.925 1.692
50° 60° 70°	0.000	0.000	0.000	0.179	0.359	0.538	0.718	0.897	1.077	1.470 1.256 1.049

TABLE X.

VENTILATION.

Table Showing the Quantity of Air, in Cubic Feet, Discharged per Minute Through a Flue of Which the Cross-.

Sectional Area is One Square Foot.

(External Temperature of the Air, 32° Fahr.; Allowance for Friction, 50 Per Cent.)

Height of Flue	Exce	ss of Tem	perature	of Air in	Flue abov	e that of	External	Air
in Feet	10°	15°	20°	25°	30°	50°	100°	150°
1	34	42	48	54	59	76	108	133
5	76	94	109	121	134	167	242	298
10	108	133	153	171	188	242	342	419
15	133	162	188	210	230	297	419	514
20	153	188	217	242	265	342	484	593
25	171	210	242	271	297	383	541	663
30	188	230	265	297	325	419	593	726
35	203	248	286	320	351	453	640	784
40	217	265	306	342	375	484	684	838
45	230	282	325	363	398	514	724	889
50	242	297	342	383	419	541	765	937
60	264	325	373	420	461	594	835	1006
70	286	351	405	465	497	643	900	1115
80	306	375	453	485	530	688	965	1185
90	324	398	460	516	564	727	1027	1225
100	342	420	485	534	594	768	1080	1325
125	383	468	542	604	662	855	1210	1480
150	420	515	59€	665	730	942	1330	1630

Above table for Gravity Ventilation taken from standard authorities but not guaranteed.

TABLE XI.

HEAT UNITS IN WATER.

Between 32 and 212 Degrees Fahrenheit, and Weight of Water

per Cubic Foot.

			per	Cubic I	ю.			
Tem- perature Degrees F.	Heat Units	Weight in Pounds per Cubic Foot	Tem- perature Degrees F.	Heat Units	Weight in Pounds per Cubic Foot	Tem- perature Degrees F.	Heat Units	Weight in Pounds per Cubic Foot
32	0.	62.42	123	91.16	61.68	168	136.44	60.81
35	3.	62.42	124	92.17	61.67	169	137.45	60.79
40	8.	62.42	125	93.17	61.65	170	138.45	60.77
45	13.	62.42	126	94.17	61.63	171	139.46	60.75
50	18.	62.41	127	95.18	61.61	172	140.47	60.73
52	20.	62.40	128	96.18	61.60	173	141.48	60.70
54	22.01	62.40	129	97.19	61.58	174	142.49	60.68
56	24.01	62.39	130	98.19	61.56	175	143.50	60.66
58	26.01	62.38	131	99.20	61.54	176	144.51	60.64
60	28.01	62.37	132	100.20	61.52	177	145.52	60.62
62	30.01	62.36	133	101.21	61.51	178	146.52	60.59
64	32.01	62.35	134	102.21	61.49	179	147.53	60.57
66	34.02	62.34	135	103.22	61.47	180	148.54	60.55
68	36.02	62.33	136	104.22	61.45	181	149.55	60.53
70	38.02	62.31	137	105.23	61.43	182	150.56	60.50
72	40.02	62.30	138	106.23	61.36	183	151.57	60.48
74	42.03	62.28	139	107.24		184	152.58	60.46
76	44.03	62.27	140	108.25		[7 185	153.59	60.44
78	46.03	62.25	141	109.25		186	154.60	60.41
80	48.04	62.23	142	110.26		187	155.61	60.39
82	50:04	62.21	143	111.26	61.32	188	156.62	60.37
84	52:04	62.19	144	112.27	61.30	189	157.63	60.34
86	54:05	62.17	145	113.28	61.28	190	158.64	60.32
88	56:05	62.15	146	114.28	61.26	191	159.65	60.29
90	58:06	62.13	147	115.29	61.24	192	160.67	60.27
92	60.06	62.11	148	116.29	61.22	193	161.68	60.25
94	62.06	62.09	149	117.30	61.20	194	162.69	60.22
96	64.07	62.07	150	118.31	61.18	195	163.70	60.20
98	66.07	62.05	151	119.31	61.16	196	164.71	60.17
100	68.08	62.02	152	120.32	61.14	197	165.72	60.15
102	70.09	62.00	153	121.33	61.12	198	166.73	60.12
104	72.09	61.97	154	122.33	61.10	199	167.74	60.10
106	74.10	61.95	155	123.34	61.08	200	168.75	60.07
108	76.10	61.92	156	124.35	61.06	201	169.77	60.05
110	78.11	61.89	157	125.35	61.04	202	170.78	60.02
112	80.12	61.86	158	126.36	61.02	203	171.79	60.00
114	82.13	61.83	159	127.37	61.00	204	172.80	59.97
115	83.13	61.82	160	128.37	60.98	205	173.81	59.95
116	84.13	61.80	161	129.38	60.96	206	174.83	59.92
117	85.14	61.78	162	130.39	60.94	207	175.84	59.89
118	86.14	61.77	163	131.40	60.92	208	176.85	59.87
119	87.15	61.75	164	132.41	60.90	209	177.86	59.84
120	88.15	61.74	165	133.41	60.87	210	178.87	59.82
121	89.15	61.72	166	134.42	60.85	211	179.89	59.79
122	90.16	61.70	167	135.42	60.83	212	180.90	59.76

197

TABLE XII.

PROPERTIES OF SATURATED STEAM.

	Absolute		Total Heat	above 32° F.	Todama	Volume,
Vacuum, Inches of Mercury	Pressure, Lbs. per Sq. Inch	Tempera- ture, Fahrenheit	In the Water Heat-Units	In the Steam Heat-Units	Latent Heat, Heat-Units	Cu. Ft. in 1 Lb. Of Steam
27.88	1 .	101.83	69.8	1104.4	1034.6	333.0
25 .85	2	126.15	94.0	1115.0	1021.0	173.5
23 .81	3	141.52	109.4	1121.6	1012.3	118.5
2 1.78	4	153.01	120.9	1126.5	1005.7	90.5
19.74	5	162.28	130.1	1130.5	1000.3	73.33
17.70	6	170.06	137.9	1133.7	995.8	61.89
15.67	7	176.85	144.7	1136.5	991.8	53.56
13.63	8	182.86	150.8	1139.0	988.2	47.27
11.60	9	188.27	156.2	1141.1	985 0	42.36
9.56	10	193.22	161.1	1143.1	982.0	38.38
7.52	11	197.75	165.7	1144.9	979.2	35.10
5.49	12	201.96	169.9	1146.5	976.6	32.36
3.45	13	205.87	173.8	1148.0	974.2	30.03
1.42	14	209.55	177.5	1149.4	971.9	28.02
Pounds : Steam Gauge.					•	
	14.70	212	180.0	1150.4	970.4	26.79
0.3	15	213.0	181.0	1150.7	969.7	26.27
1.3	16	216.3	184.4	1152.0	967.6	24.79
2.3	17	219.4	187.5	1153.1	965.6	23.38
3.3	18	222.4	190.5	1154.2	963.7	22 .16
4.3	19	225.2	193.4	1155.2	961.8	21.07
5.3	20	228.0	196.1	1156.2	960.0	20.08
6.3	21	230.6	198.8	1157.1	958.3	19.18
7.3	22	233.1	201.3	1158.0	956.7	18.37
8.3	23	235.5	203.8	1158.8	955.1	17.62
9.3	24	237.8	206.1	1159.6	953.5	16.93
10.3	25	240.1	208.4	1160.4	952.0	16.30
11.3	26	242.2	210.6	1161.2	950.6	15.72
12.3	27	244.4	212.7	1161.9	949.2	15.18
13.3	28	246.4	214.8	1162.6	947.8	14.67
14.3	29	248.4	216.8	1163.2	946.4	14.19
15.3	30	250.3	218.8	1163.9	945.1	13.74
16.3	31	252.2	220.7	1164.5	943.8	13.32
17.3	32	254.1	222.6	1165.1	942.5	12.93
18.3	33 34	255.8 257.6	224.4 226.2	1165.7 1166.3	941.3	12.57
19.3 2 0.3	35	257.0 259.3	227.9	1166.8	$940.1 \\ 938.9$	12.22 11.89
4 0.3	้อก	208.0	261.9	1100.0	300.B	11.09

TABLE XIII.

NUMBER OF U. S. GALLONS IN TANKS.

Depth							1	Diameter	in Inches							
Feet.	18	72	30	38	42	48	2	99	99	72	78	84	06	8	108	120
2	26		73	105	144	188	238	l		424	497	577	662	750	954	1,178
21%	33		8	131	180	235	298			530	621	721	827	937	1,192	1,472
<u>'</u> က	40	71	109	157	216	282	357	440	534	636	745	865	992	1,124	1,430	1,766
$\frac{31}{2}$	47		127	183	252	329	416			742	698	1,009	1,157	1,311	1,668	2,060
4	54		145	200	288	376	475			848	993	1,153	1,322	1,498	1,904	2,354
41/2	61		163	235	324	423	534			954	1,117	1,297	1,487	1,685	2,144	2,648
ິນ	68		180	261	360	470	593			1,060	1,241	1,441	1,652	1,872	2,382	2,942
$5\frac{1}{2}$	75	•	200	287	396	517	652			1,166	1,356	1,585	1,817	2,059	2,620	3,236
9	82		217	313	432	564	711		_	1,272	1,489	1,729	1,982	2,246	2,858	3,530
$6\frac{1}{2}$	83		235	339	468	611	220		-	1,378	1,613	1,873	2,147	2,433	3,096	3,824
7	96		253	365	50	658	829	_	_	1,484	1,737	2,017	2,312	2,620	3,334	4,118
71%	103		271	391	540	705	888	_	-	1,590	1,861	2,161	2,477	2,807	3,572	4,412
· •	110		289	417	226	752	947	_	_	1,696	1,985	2,305	2,642	2,994	3,810	4,706
87%	-	203	307	443	612	799	1,006	_	_	1,802	2,109	2,449	2,807	3,181	4,048	5,000
10	•	239	361	521	720	940	1,183	_	_	2,120	2,481	2,881	3,302	3,742	4,762	5,882
12	<u>:</u>	287	433	625	864	1,128	1,419	_	N	2,544	2,977	3,457	3,962	4,490	5,714	7,058
14		:		:	1,008	1,316	1,655	CA	N	2,968	3,473	4,033	4,622	5,238	999,9	8,234
16	:		_ :	•	1,152	1,504	1,891	C	C)	3,392	3,969	4,609	5,282	5,986	7,618	9,410
18	-		:	:	:	:	2,127	CA	က	3,816	4,465	5,185	5,942	6,734	8,570	10,586
20	_: ::	-:	:	_ :		:	2,363	C	က	4,240	4,961	5,761	6,602	7,482	9,522	11,762

TABLE XIV.

	Gallons of Water per 100	To or Trongen	8.	<u>.</u>	1.0	1.6	2.7	4.5	7.7	10.6	17.4	24.8	38:4	51.3	66.1	82.9	103.8	150.0	202.0	260.0	326.0	410.0	495.0	590.0
PIPES.	Size of Tep Drill		280 -14	este col-4		60/E9	- to	1,8	135	- CARC	2 8	211	93 196	<u>က</u>	482	4	544	67%	72	80 186	9	1016	11 5	12,5
IRON	Length of Full Thread		. 19	.29	.30	.39	.40	.51	.54	. 55	. 58	68 .	.95		1.05	1.10	1.16	1.26	1.36	1.46	1.57	1.68	1.79	1.90
DARD WROUGHT	Nominal wt. Pounds per		.24	.42	. 26	88.	1.12	1.67	2.24	2.68	3.61	5.74	7.54	6	10.67	12.34	14.50	18.76	23.27	28.18	33.70	40.04		48.99
S OF STANDARD	Lineal Feet per sq. ft.	Surface.	9.43	7.08	5.66	4.55	3.64	2.90	2.30	2.01	1.61	1.33	1.09	96	.85	92.	69	. 58	. 20	.44	.40	98.	.33	.30
D CAPACITIES	Area Square In.		90.	. 10	. 19	.30	. 53	98.	1.50	2.04	3.36	4.78	7.38	68.6	12.73	15.96	19.99	28.89	38.74	50.02	62.73	78.82	95.03	113.09
DIMENSIONS AND	ismeter, nes	Outside	.41	72.	89.	78 .	1.05	1.32	1.66	1.90	2.38	2.88	3.50	4.	4.50	5.	5.56	6.63	7.63	8.63	9.63	10.75	11.75	12.75
DIMI	Actual Diameter Inches	Inside	.27	98.	. 49	.62	.83	1.05	1.38	1.61	2.07	2.47	3.07	3.55	4.03	4.51	5.05	6.07	7.02	7.98	8.94	10.02	11.	12.
	Nominal Inside	Diameter	1%	74		7	% **	· —	11/4	11%	5	21%	ന	31/2	4	41/2	ີ່ຜ	9	_	œ	6	10	11	12

TABLE XV.
HEATING SURFACE IN WROUGHT PIPE.

Length of Pipe in		IBAII				Size of	Pipe.			
Feet.	×	1	11%	11%	2	21/2	3	4	5	6
1	. 275	. 346	. 434	. 494	. 622	. 753	. 916	1.175	1.455	1.739
2 3 4 5	.5 .8 1.1 1.4	1.0 1.4 1.7	.9 1.3 1.7 2.2	1.0 1.5 2.0 2.4	1.2 1.9 2.5 3.1	1.5 2.3 3.0 3.8	1.8 2.7 3.6 4.6	2.4 3.5 4.7 5.8	2.9 4.4 5.8 7.3	3.5 5.2 7.0 7.7
6 7 8 9 10	1.6 1.9 2.2 2.5 2.7	2.1 2.4 2.8 3.1 3.5	2.6 3.0 3.5 3.9 4.3	2.9 3.4 3.9 4.4 4.9	5.0 5.6	4.5 5.3 6.0 6.8 7.5	7.3 8.2	7.0 8.2 9.4 10.6 11.8	8.7 10.2 11.6 13.1 14.6	10.5 12.1 13.9 15.7 17.4
11 12 13 14 15	3.0 3.3 3.6 3.8 4.1		5.6 6.1	5.4 5.9 6.4 6.9 7.4	8.1 8.7	9.0		12.9 14.1 15.3 16.5 17.6	16.0 17.4 18.9 20.3 21.8	19.1 20.9 22.6 23.4 26.1
16 17 18 19 20	4.4 4.7 5.0 5.2 5.5	6.6	7.8 8.3	8.4 8.9 9.4	10.6 11.2 11.8	12.0 12.8 13.5 14.3 15.0	15.5 16.5 17.4	18.8 20.0 21.2 22.3 23.5	23.2 24.7 26.2 27.6 29.1	27.8 29.5 31.3 33.1 34.8
25 30 35 40	9.6	10.4 12.1	13.0 15.2	14.8 17.3	$\begin{array}{c} 18.7 \\ 21.8 \end{array}$	18.8 22.5 26.3 30.1	$27.5 \\ 32.0$	29.3 35.3 41.1 47.0	36.3 43.6 50.9 58.2	43.5 52.1 60.8 69.5
45 50 55 60	13.8 15.2	17.3 19.0	$21.7 \\ 23.9$	$24.7 \\ 27.1$	$31.1 \\ 34.3$	41.3	41.2 45.8 50.4 55.0	52.9 58.7 64.6 70.5	65.5 72.7 80.1 87.3	78.2 87.0 95.6 104.3
65 70 75 80	19.4 20.7	24.2 26.0	$30.4 \\ 32.6$	34.6 37.1	43.5 46.6	48.8 52.7 56.5 60.2	64.1 68.7	76.4 82.3 88.1 94.0	94.5 101.9 109.1 116.4	112.9 121.7 130.4 139.1
85 90 95 100	24.8 26.2	31.1 32.9	39.1 41.2	44.5 46.9	56.0 59.6	71.5 75.3	82.4 87.2	99.9 105.8 111.6 117.5	123.7 130.9 138.2 145.5	147.9 156.5 165.2 173.9

TABLE XVI.

INTERNAL AREAS OF DIFFERENT SIZES AND WEIGHTS OF PIPE.

		Internal Areas of Corresponding									
Diameter in Inches	A Circle	Standard Weight Wrought Pipe	Extra Strong Wrought Pipe	Double Extra Strong Wrought Pipe							
1½	1.76	2.04	1.75	. 93							
2	3.14	3.36	2.93	1.74							
$\frac{21}{2}$	4.91	4.78	4.20	2.41							
3 -	7.06	7.39	6.56	4.09							
$3\frac{1}{2}$	9.62	9.89	8.85	5.79							
4	12.56	12.73.	11.44	7.72							
4½ 5 6	15.90	15.96	14.38	9.96							
5 -	19.63	19.99	18.19	12.96							
6	28.27	28.89	25 .97	18.66							
7	38.48	38.74	34.47	27.10							
8	50.26	50.04	45.66	37.12							
9	63.61	62.73	58.42								
10	78.54	78.84	74 . 66								

TABLE XVII.

CAPACITIES AND THREADS OF STANDARD WROUGHT-IRON PIPE.

Nominal Inside	Length of	Longth of Pipe	Contained Libe.	Nominal Inside	Length of	Length of Pipe	Contained Lbs.
Diameter	Thread	Containing One	of Water per	Diameter	Thread	Containing One	of Water per
Inches	Inches	Gallon—Feet	Lineal Foot	Inches	Inches	Gallon—Feet	Lineal Foot
1/8 1/4 3/8 1/2 3/4 1 1/4 1/2 2 2/2 3 3/4	\$2 \$8 \$7 \$6 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1	336.6 148.8 100.8 63.2 36.1 22.3 12.8 9.4 5.7 4.02 2.6 1.95 1.51	.024 .044 .082 .132 .23 .373 .648 .883 1.454 2.072 3.202 4.285 5.517	41/2 5 6 7 8 9 10 11 12 13 14 15	11/4 11/4 13/8 11/2 15/8 15/8 13/4	1.2 .96 .66 .49 .38 .3 .24 .2 .17 .139 .12 .102	6.908 8.668 12.521 16.79 21.688 27.58 34.171 41.189 49.017 59.762 69.125 81.07 91.559

TABLE XVIII.

GALVANIZED SHEET IRON—SIZES AND WEIGHTS.

Size Size Sq. Ft. Infrounds Gauge Size Sq. Ft. Infrounds Gauge Gauge Sq. Ft. Infrounds Gauge Gauge Sq. Ft. Infrounds Gauge Gauge Gauge Sq. Ft. Infrounds Gauge Gau		GALVA			ON SIZE	AND WE	Ounces	Walaht
16 26 x 84 42 1/2 40 1/4 23 30 x 96 20 1/2 25 1/2 16 28 x 84 42 1/2 43 1/2 23 32 x 96 20 1/2 27 1/2 16 24 x 96 42 1/2 46 1/2 23 40 x 96 20 1/2 34 1/2 16 26 x 96 42 1/2 46 23 44 x 96 20 1/2 37 1/2 16 28 x 96 42 1/2 49 3/4 24 24 x 84 18 1/2 16 1/2 16 30 x 96 42 1/2 53 24 26 x 84 18 1/2 16 1/2 18 24 x 84 34 1/2 30 1/4 24 26 x 84 18 1/2 19 18 26 x 84 34 1/2 35 1/4 24 30 x 84 18 1/2 20 1/2 18 30 x 84 34 1/2 35 1/4 24 30 x 84 18 1/2 22 18 30 x 84 34 1/2 34 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42 1/2 42	Gauge	Size	8q. Ft.		Gauge	Size	Sq. Ft.	Weight of Sheet in Pounds
16	14	26 x 84	521/2 521/2	46 4914	23 23	40 x 84	201/2	20
16			521/2	53%	23		201/2	201/2
16			421/2		23		2012	
16			421/2	401/4	23		201/2	2534
16 28 x 96 42 ½ 49 ¼ 24 24 x 84 18 ½ 16 ⅓ 16 30 x 96 42 ½ 53 24 26 x 84 18 ½ 17 18 24 x 84 34 ½ 30 ¼ 24 28 x 84 18 ½ 19 18 26 x 84 34 ½ 35 ¼ 24 30 x 84 18 ½ 20 ½ 18 30 x 84 34 ½ 35 ¼ 24 30 x 84 18 ½ 20 ½ 18 30 x 84 34 ½ 35 ¼ 24 36 x 84 18 ½ 22 ¼ 18 24 x 96 34 ½ 34 ½ 24 24 x 96 18 ½ 22 ¼ 18 26 x 96 34 ½ 34 ½ 24 24 x 96 18 ½ 21 ½ 18 26 x 96 34 ½ 36 ½ 24 26 x 96 18 ½ 21 ½ 18 30 x 96 34 ½ 36 ½ 24 26 x 96 18 ½ 23 ½ 18 30 x 96 34 ½ 25 ½ 24 30 x 96 18 ½ 23 ½ 19 28 x 84			421/2	1 461/6	23		2012	31
16 28 x 96 42 ½ 49 ¼ 24 24 x 84 18 ½ 16 ⅓ 16 30 x 96 42 ½ 53 24 26 x 84 18 ½ 17 18 24 x 84 34 ½ 30 ¼ 24 28 x 84 18 ½ 19 18 26 x 84 34 ½ 35 ¼ 24 30 x 84 18 ½ 20 ½ 18 30 x 84 34 ½ 35 ¼ 24 30 x 84 18 ½ 20 ½ 18 30 x 84 34 ½ 35 ¼ 24 36 x 84 18 ½ 22 ¼ 18 24 x 96 34 ½ 34 ½ 24 24 x 96 18 ½ 22 ¼ 18 26 x 96 34 ½ 34 ½ 24 24 x 96 18 ½ 21 ½ 18 26 x 96 34 ½ 36 ½ 24 26 x 96 18 ½ 21 ½ 18 30 x 96 34 ½ 36 ½ 24 26 x 96 18 ½ 23 ½ 18 30 x 96 34 ½ 25 ½ 24 30 x 96 18 ½ 23 ½ 19 28 x 84	16	24 x 96	421/2	421/6	23	40 x 96	201/2	341/8
18 24 x 84 34½ 32½ 24 30 x 84 18½ 20⅓ 18 26 x 84 34½ 35¼ 24 30 x 84 18½ 20⅓ 18 30 x 84 34½ 35¼ 24 30 x 84 18½ 22 18 36 x 84 34½ 45¼ 24 40 x 84 18½ 27 18 24 x 96 34½ 36½ 24 26 x 96 18½ 20 18 28 x 96 34½ 40½ 24 26 x 96 18½ 20 18 28 x 96 34½ 40½ 24 28 x 96 18½ 20 18 30 x 96 34½ 40½ 24 28 x 96 18½ 21¾ 18 36 x 96 34½ 51¼ 24 30 x 96 18½ 21¾ 18 36 x 96 34½ 51¼ 24 30 x 96 18½ 21¾ 19 28 x 84 30½ 31 24 36 x 96 18½ 31 20 28 x 84 26½ 23 <							l	
18 24 x 84 34½ 32½ 24 30 x 84 18½ 20⅓ 18 26 x 84 34½ 35¼ 24 30 x 84 18½ 20⅓ 18 30 x 84 34½ 35¼ 24 30 x 84 18½ 22 18 36 x 84 34½ 45¼ 24 40 x 84 18½ 27 18 24 x 96 34½ 36½ 24 26 x 96 18½ 20 18 28 x 96 34½ 40½ 24 26 x 96 18½ 20 18 28 x 96 34½ 40½ 24 28 x 96 18½ 20 18 30 x 96 34½ 40½ 24 28 x 96 18½ 21¾ 18 36 x 96 34½ 51¼ 24 30 x 96 18½ 21¾ 18 36 x 96 34½ 51¼ 24 30 x 96 18½ 21¾ 19 28 x 84 30½ 31 24 36 x 96 18½ 31 20 28 x 84 26½ 23 <			421/2	4934			181/2	161/4
18 28 x 84 34½ 35¼ 24 32 x 84 18½ 22½ 18 30 x 84 34½ 37¾ 24 36 x 84 18½ 24 18 36 x 84 34½ 45¼ 24 40 x 84 18½ 27 18 24 x 96 34½ 36½ 24 24 x 96 18½ 21 18 26 x 96 34½ 36½ 24 26 x 96 18½ 20 18 28 x 96 34½ 40½ 24 26 x 96 18½ 20 18 28 x 96 34½ 40½ 24 28 x 96 18½ 21¾ 18 30 x 96 34½ 42½ 24 30 x 96 18½ 21¾ 18 36 x 96 34½ 51¾ 24 30 x 96 18½ 23 18 36 x 96 34½ 21¾ 24 36 x 96 18½ 24¾ 20 28 x 84 26½ 23 24 40 x 96 18½ 31 20 28 x 84 26½ 29 <t< td=""><td></td><td>24 x 84</td><td>341/2</td><td>301/</td><td></td><td></td><td>181/2</td><td></td></t<>		24 x 84	341/2	301/			181/2	
18 30 x 84 34 ½ 37 ¾ 24 36 x 84 18 ½ 24 18 36 x 84 34 ½ 45 ¼ 24 40 x 84 18 ½ 27 18 24 x 96 34 ½ 34 ½ 24 24 x 96 18 ½ 20 18 26 x 96 34 ½ 36 ½ 24 26 x 96 18 ½ 20 18 28 x 96 34 ½ 40 ⅓ 24 28 x 96 18 ½ 21 ¾ 18 30 x 96 34 ½ 42 ¼ 24 30 x 96 18 ½ 21 ¾ 18 36 x 96 34 ½ 42 ¼ 24 30 x 96 18 ½ 21 ¾ 19 28 x 84 30 ½ 31 24 36 x 96 18 ½ 24 ¾ 20 24 x 84 26 ½ 23 24 40 x 96 18 ½ 37 ¾ 20 28 x 84 26 ½ 23 24 40 x 96 18 ½ 31 20 28 x 84 26 ½ 29 26 26 x 84 14 ½ 12 ¾ 20 30 x 84 2		26 x 84	341/2	32			181/2	201/4
18 36 x 84 34 ½ 34 ½ 34 ½ 24 x 96 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 18 ½ 20 18 ½ 20 28 x 96 18 ½ 20 28 x 96 18 ½ 21 ¾ 24 28 x 96 18 ½ 21 ¾ 24 30 x 96 18 ½ 21 ¾ 21 ¾ 24 30 x 96 18 ½ 23 24 ¾ 24 36 x 96 18 ½ 24 36 x 96 18 ½ 24 36 x 96 18 ½ 24 ¾ 24 36 x 96 18 ½ 24 ¾ 20 24 x 84 26 ½ 23 24 40 x 96 18 ½ 27 ½ 20 26 x 84 26 ½ 23 24 40 x 96 18 ½ 27 ¾ 20 26 x 84 26 ½ 23 24 44 x 96 18 ½ 31 24 x 96 18 ½ 27 ¾ 20 26 x 84 26 x 84 14 ½ 12 ¾ 20 26 x 84 26 ½ 26 26 x 84 26 x 84 14 ½ 12 ¾ 20 26 x 84 14 ½ 12 ¾ 20 26 x 84 26 x 84 14 ½ 12 ¾ 12 ¾ 20 26 x 84 26 x 84 14 ½ 18 ½ 12 ¾ 12 ¾ 26 26 x 84 14 ½ 16 27 x 84 14 ½ 16 27 x 84 16 27 x 84 14 ½ 16 27 x 84 14			1	/ -			l	
18 24 x 96 34 ½ 34 ½ 36 ½ 24 26 x 96 18 ½ 20 18 28 x 96 34 ½ 40 ½ 24 26 x 96 18 ½ 20 18 30 x 96 34 ½ 42 ½ 24 30 x 96 18 ½ 21 ½ 18 36 x 96 34 ½ 51 ½ 24 30 x 96 18 ½ 24 ½ 19 28 x 84 30 ½ 31 24 36 x 96 18 ½ 24 ½ 20 24 x 84 26 ½ 23 24 40 x 96 18 ½ 27 ½ 20 28 x 84 26 ½ 25 24 44 x 96 18 ½ 23 ¾ 20 28 x 84 26 ½ 25 24 44 x 96 18 ½ 12 ½ 20 30 x 84 26 ½ 29 26 26 x 84 14 ½ 12 ½ 20 36 x 84 26 ½ 26 ½ 28 x 84 14 ½ 14 ½ 20 26 x 96 26 ½ 26 ½ 28 x 84 14 ½ 17 20 28 x 96 26 ½			341/2	3734	24 24		181/2	
18 26 x 96 34 ½ 36 ½ 24 28 x 96 18 ½ 21 ½ 18 30 x 96 34 ½ 42 ¾ 24 30 x 96 18 ½ 21 ¾ 18 36 x 96 34 ½ 51 ¾ 24 32 x 96 18 ½ 24 ½ 19 28 x 84 30 ½ 31 24 36 x 96 18 ½ 27 ½ 20 24 x 84 26 ½ 23 24 40 x 96 18 ½ 31 20 28 x 84 26 ½ 25 24 44 x 96 18 ½ 34 20 28 x 84 26 ½ 27 26 24 x 84 14 ½ 12 ½ 20 30 x 84 26 ½ 29 26 28 x 84 14 ½ 12 ½ 20 36 x 84 26 ½ 26 ½ 26 x 84 14 ½ 14 ½ 20 26 x 96 26 ½ 26 ½ 30 x 84 14 ½ 16 20 28 x 96 26 ½ 33 26 24 x 96 14 ½ 17 20 30 x 96 26 ½ 33 2	18	24 x 96	34 1/6	343/4			181/2	1814
18 30 x 96 34 ½ 42 ¾ 24 30 x 96 18 ½ 23 18 36 x 96 34 ½ 51 ¾ 24 32 x 96 18 ½ 24 ½ 19 28 x 84 30 ½ 31 24 36 x 96 18 ½ 27 ½ 20 24 x 84 26 ½ 25 24 40 x 96 18 ½ 31 20 28 x 84 26 ½ 25 24 44 x 96 18 ½ 34 20 28 x 84 26 ½ 27 26 24 x 84 14 ½ 12 ½ 20 30 x 84 26 ½ 29 26 26 x 84 14 ½ 13 ½ 20 36 x 84 26 ½ 34 ¾ 26 28 x 84 14 ½ 14 ½ 20 26 x 96 26 ½ 26 ¾ 26 30 x 84 14 ½ 17 20 28 x 96 26 ½ 31 26 36 x 84 14 ½ 17 20 28 x 96 26 ½ 33 26 24 x 96 14 ½ 15 14 20 36 x 96		26 x 96	34 1/2	361/2			181/2	∣ 20
20 24 x 84 26 ½ 25 24 44 x 96 18 ½ 34 20 28 x 84 26 ½ 25 24 44 x 96 18 ½ 34 20 28 x 84 26 ½ 29 26 26 x 84 14 ½ 13 ½ 20 30 x 84 26 ½ 34 ¾ 26 26 28 x 84 14 ½ 13 ½ 20 24 x 96 26 ½ 26 ½ 26 30 x 84 14 ½ 16 20 24 x 96 26 ½ 26 ½ 28 ¾ 26 32 x 84 14 ½ 16 20 28 x 96 26 ½ 28 ¾ 26 32 x 84 14 ½ 16 20 28 x 96 26 ½ 31 26 36 x 84 14 ½ 17 20 28 x 96 26 ½ 33 26 36 x 84 14 ½ 19 20 36 x 96 26 ½ 33 26 26 26 x 96 14 ½ 14 ½ 20 20 36 x 96 26 ½ 32 x 96 14 ½ 17 20 36 x 96 26 ½ 33 26 26 26 x 96 14 ½ 17 22 24 x 84 22 ½ 21 ½ 21 ¼ 26 30 x 96 14 ½ 17 22 25 x 84 22 ½ 21 ½ 21 ½ 26 36 x 96 14 ½ 18 ½ 22 28 x 84 22 ½ 23 26 36 x 96 14 ½ 18 ½ 22 28 x 84 22 ½ 29 ½ 28 24 x 84 12 ½ 11 22 36 x 84 22 ½ 29 ½ 28 28 24 x 84 12 ½ 11 22 36 x 84 22 ½ 29 ½ 28 28 24 x 84 12 ½ 11 22 26 x 96 22 ½ 26 ½ 26 x 84 12 ½ 12 ½ 22 26 x 96 22 ½ 26 26 x 84 12 ½ 13 ½ 22 26 x 96 22 ½ 26 26 x 84 12 ½ 13 ½ 22 26 x 96 22 ½ 26 26 x 84 12 ½ 12 ½ 22 26 x 96 22 ½ 26 26 36 28 32 x 84 12 ½ 12 ½				1			i	
20	18 18	30 x 96	34 1/2	4214		30 x 96	1812	23
20	19	28 x 84	301/2	31		36 x 96	1814	27%
20	20		26 1/2	23			181/2	31
20			1				1	1
20 36 x 84 26 ½ 34 ¾ 26 28 x 84 14 ½ 16 20 26 x 96 26 ½ 26 ½ 26 30 x 84 14 ½ 16 17 20 28 x 96 26 ½ 31 26 36 x 84 14 ½ 19 20 30 x 96 26 ½ 33 26 24 x 96 14 ½ 14 ½ 20 36 x 96 26 ½ 33 26 24 x 96 14 ½ 15 ½ 20 36 x 96 26 ½ 33 26 28 x 96 14 ½ 15 ½ 22 24 x 84 22 ½ 19 ¾ 26 28 x 96 14 ½ 17 22 28 x 84 22 ½ 21 ½ 26 32 x 96 14 ½ 18 ½ 22 28 x 84 22 ½ 24 ½ 26 36 x 96 14 ½ 18 ½ 22 30 x 84 22 ½ 24 ½ 26 36 x 96 14 ½ 19 ½ 22 36 x 84 22 ½ 24 ½ 28 24 x 84 12 ½ 11 ½ 22 40 x 84	20 20		261/2		26		1416	1234
20 24 x 96 26 ½ 26 ½ 26 ½ 30 x 84 14 ½ 16 20 28 x 96 26 ½ 31 26 36 x 84 14 ½ 19 20 30 x 96 26 ½ 33 26 24 x 96 14 ½ 14 ½ 20 36 x 96 26 ½ 42 26 26 x 96 14 ½ 15 ½ 22 24 x 84 22 ½ 19 ¾ 26 28 x 96 14 ½ 15 ½ 22 26 x 84 22 ½ 21 ¼ 26 30 x 96 14 ½ 18 ½ 22 28 x 84 22 ½ 21 ½ 26 32 x 96 14 ½ 18 ½ 22 28 x 84 22 ½ 23 26 32 x 96 14 ½ 19 ½ 22 30 x 84 22 ½ 24 ½ 26 36 x 96 14 ½ 19 ½ 22 36 x 84 22 ½ 23 ½ 26 36 x 96 14 ½ 19 ½ 22 36 x 84 22 ½ 29 ½ 28 24 x 84 12 ½ 11 ½ 22 36 x 84 22 ½ 29 ½ 28 24 x 84 12 ½ 11 ½ 22 26 x 96 22 ½ 22 ½ 28 28 x 84 <	20		261/2	343/	26		1416	1434
20 28 x 96 26 ½ 31 26 36 x 84 14 ½ 19 20 30 x 96 26 ½ 33 26 24 x 96 14 ½ 14 ½ 19 20 36 x 96 26 ½ 42 26 26 x 96 14 ½ 15 ½ 15 ½ 22 24 x 84 22 ½ 19 ¾ 26 28 x 96 14 ½ 17 17 22 26 x 84 22 ½ 21 ½ 26 30 x 96 14 ½ 18 ½ 18 ½ 22 28 x 84 22 ½ 24 ½ 26 36 x 96 14 ½ 18 ½ 19 ½ 22 30 x 84 22 ½ 24 ½ 26 36 x 96 14 ½ 19 ½ 21 ½ 22 3 26 36 x 96 14 ½ 21 ½ 21 ½ 22 3 26 36 x 96 14 ½ 21 ½ 21 ½ 22 3 26 36 x 96 14 ½ 21 ½ 21 ½ 22 3 26 36 x 96 14 ½ 21 ½ 21 ½ 22 3 26 36 x 96 14 ½ 21 ½ 21 ½ 21 ½ 22 3 26 36 x 96 14 ½ 21 ½ 21 ½ <td>20</td> <td></td> <td>261/2</td> <td>2614</td> <td></td> <td></td> <td>141/2</td> <td>16</td>	20		261/2	2614			141/2	16
20			1				1	
22 24 x 84 22½ 19¾ 26 28 x 96 14½ 17 22 28 x 84 22½ 23 26 32 x 96 14½ 18½ 22 30 x 84 22½ 24½ 26 36 x 96 14½ 21¾ 22 36 x 84 22½ 24½ 26 36 x 96 14½ 21¾ 22 36 x 84 22½ 29½ 28 24 x 84 12½ 11 22 40 x 84 22½ 33 28 26 x 84 12½ 11³ 22 24 x 96 22½ 22 28 28 x 84 12½ 12¾ 22 26 x 96 22½ 24¼ 28 30 x 84 12½ 13¾ 22 28 x 96 22½ 26¼ 28 32 x 84 12½ 14½ 22 28 x 96 22½ 28 36 x 84 12½ 14½ 22 30 x 96 22½ 28 36 x 84 12½ 16½ 22 36 x 96 22½ 28 36 x 84 12½ 16½ 22 36 x 96 22½ 28 28 36 x 84 12½ 16½ 22 36 x 96 22½	20 20		261/2	31			141/2	19
22 24 x 84 22½ 19¾ 26 28 x 96 14½ 17 22 28 x 84 22½ 23 26 32 x 96 14½ 18½ 22 30 x 84 22½ 24½ 26 36 x 96 14½ 21¾ 22 36 x 84 22½ 24½ 26 36 x 96 14½ 21¾ 22 36 x 84 22½ 29½ 28 24 x 84 12½ 11 22 40 x 84 22½ 33 28 26 x 84 12½ 11³ 22 24 x 96 22½ 22 28 28 x 84 12½ 12¾ 22 26 x 96 22½ 24¼ 28 30 x 84 12½ 13¾ 22 28 x 96 22½ 26¼ 28 32 x 84 12½ 14½ 22 28 x 96 22½ 28 36 x 84 12½ 14½ 22 30 x 96 22½ 28 36 x 84 12½ 16½ 22 36 x 96 22½ 28 36 x 84 12½ 16½ 22 36 x 96 22½ 28 28 36 x 84 12½ 16½ 22 36 x 96 22½	20		261/2				1416	1534
22	22		221/2	193/4		28 x 96	141/2	17
22		26 x 84		211/4	1		/-	1
22 26 x 96 22 ½ 24 ¼ 28 30 x 84 12 ½ 13 ¾ 22 28 x 96 22 ½ 26 ¼ 28 32 x 84 12 ½ 14 ½ 22 30 x 96 22 ½ 28 28 36 x 84 12 ½ 16 ½ 22 36 x 96 22 ½ 28 28 36 x 84 12 ½ 16 ½ 12 ¾ 22 36 x 96 22 ¼ 28 28 24 x 96 12 ¼ 12 ¾ 22 36 x 96 22 ¼ 28 24 x 96 12 ¼ 12 ¾ 28 28 24 x 96 12 ¼ 12 ¾ 28 28 24 x 96 12 ¼ 12 ¾ 28 28 28 28 28 X 96 X 9	22		221/2	23	26		141/2	191/2
22 26 x 96 22 ½ 24 ¼ 28 30 x 84 12 ½ 13 ¾ 22 28 x 96 22 ½ 26 ¼ 28 32 x 84 12 ½ 14 ½ 22 30 x 96 22 ½ 28 28 36 x 84 12 ½ 16 ½ 22 36 x 96 22 ½ 28 28 36 x 84 12 ½ 16 ½ 12 ¾ 22 36 x 96 22 ¼ 28 28 24 x 96 12 ¼ 12 ¾ 22 36 x 96 22 ¼ 28 24 x 96 12 ¼ 12 ¾ 28 28 24 x 96 12 ¼ 12 ¾ 28 28 24 x 96 12 ¼ 12 ¾ 28 28 28 28 28 X 96 X 9	22		221/2	291/6	28		121/6	11
22 26 x 96 22 ½ 24 ¼ 28 30 x 84 12 ½ 13 ¾ 22 28 x 96 22 ½ 26 ¼ 28 32 x 84 12 ½ 14 ½ 22 30 x 96 22 ½ 28 28 36 x 84 12 ½ 16 ½ 22 36 x 96 22 ½ 28 28 36 x 84 12 ½ 16 ½ 12 ¾ 22 36 x 96 22 ¼ 28 28 24 x 96 12 ¼ 12 ¾ 22 36 x 96 22 ¼ 28 24 x 96 12 ¼ 12 ¾ 28 28 24 x 96 12 ¼ 12 ¾ 28 28 24 x 96 12 ¼ 12 ¾ 28 28 28 28 28 X 96 X 9	22	40 x 84	221/6	33	28	26 x 84	121/2	113/4
22 28 x 96 22½ 26⅓ 28 32 x 84 12½ 14½ 22 30 x 96 22½ 28 28 36 x 84 12½ 16½ 22 36 x 96 22¼ 28 24 x 96 12¼ 12¾	22	24 x 96	221/2	22	28	28 x 84		1234
22 36 x 96 22 46 33 26 28 24 x 96 12 46 12 4	22		221/2	24 1/4	28		121/2	1334
22 36 x 96 22 4 33 24 28 24 x 96 12 4 12 4	22 22		221/6	20 1/8	28 28		121/2	161
90 40 = 04 9012 9732 90 94 = 04 1912 191.	$\overline{22}$	36 x 96	1 22 1/6	3326	28	24 x 96	121/2	1233
	22	40 x 96	221/2	37 34	11	26 x 96	}	131/2
23	23		2014	18	28		121/2	14 1/2 15 1/2
23	23 23		2012	21	28		1212	161/2
$23 + 30 \times 84 + 20 \frac{1}{2} + 22 \frac{1}{2} = 28 + 36 \times 96 + 12 \frac{1}{2} + 18 \frac{1}{2}$	23	30 x 84	201/2	221/2	28		121/2	181/2
23 32 x 84 20½ 24	23	32 x 84	201/2	24		<u> </u>		<u> </u>

TABLE XIX.

GALVANIZED SHEET IRON PIPE.

Table of weights of Galvanized Iron Pipe, in pounds per lineal foot.

Diameter of Pipe			Nu	mber of Ga	suge.	 	
in Inches.	28	26	24	22	20	18	16
6 7 8 9	1.4	1.75 2.0	2.0 2.25	2.25 2.75	3.0 3.5	3.75 4.5	4.75
8	1.9	2.25	2.75	3.0	4.0	5.25	6.75
9	2 . 2	2.4	3.0	3.25	4.5	5.75	7.0
10	2.4	2.5	3.25	3.5	4.75	6.25	7.75
11		2.75	3.5	3.75	5.25	6.75	8.25
12		3.0	3.75	4.25	5.75	7.5	9.0
13	•	3.25	4.0	4.5	6.25	8.0	10.0
14		3.5	4.25	4.75	6.75	8.5	11.0
15		3.75	4.75	5.25	7.25	9.25	12.0
16		4.0	5.0	5.5	7.75	9.75	13.0
17		4.25	5.25	6.0	8.0	10.25	13.75
18		4.5	5.5	6.25	8.5	10.75	14.25
19		4.75	5.75	6.75	9.0	11.5	15.0
20		5.25	6.0	7.0	9.5	12.0	15.5
• 21		5.5	6.5	7.5	9.75	12.5	16.0
22		5.75	6.75	7.75	10.25	13.25	16.75
23	•	6.0	7.0	8.25	11.0	14.0	17.5
24		6.5	7.5	8.75	11.5	14.75	18.5
26			7.75	9.25	12.5	15.75	20.0
28			8.5	9.75	13.5	16.75	21.5
30			9.0	10.5	14.0	18.0	23.0

TABLE XX.

DIMENSIONS OF REGISTERS (T. & B.)

Size of opening, Inches	Nominal area of opening, Square Inches	Effective area of opening, Square Inches	Tin Box Size Inches	Extreme dimensions of register face, Inches
6 x 10	60	40	6 ₁₅ x 10 ₁₅	7 11 x 11 11
8 x 10	80	53	85% x 105%	9¾ x 11¾
8 x 12	96	64	85% x 125%	9¾ x 13¾
8 x 15	120	80	85/8 x 155/8	9% x 16++
9 x 12	108	72	$9\frac{1}{16} \times 12\frac{1}{16}$	$10\frac{7}{8} \times 13\frac{7}{8}$
9 x 14	126	84	918 x 1418	$10\frac{7}{8} \times 15\frac{7}{8}$
10 x 12	120	80	10 x 12 i	11 18 x 13 18
10 x 14	140	93	1011 x 1411	11 18 x 15 18
10 x 16	160	107	10 x 16 1	$11\frac{1}{18} \times 17\frac{1}{8}$
12 x 15	180	120	$12\frac{3}{4} \times 15\frac{3}{4}$	$14\frac{1}{16} \times 17$
12 x 19	228	152	$12\frac{3}{4} \times 19\frac{3}{4}$	$14\frac{1}{16} \times 21$
14 x 22	308	205	$14\frac{7}{8} \times 22\frac{7}{8}$	$16\frac{1}{4} \times 24\frac{1}{4}$
15 x 25	375	250	$15\frac{7}{8} \times 25\frac{7}{8}$	$17\frac{1}{4} \times 27\frac{1}{4}$
16 x 20	320	213	167/8 x 207/8	$18_{16}^{5} \times 22_{16}^{5}$
16 x 24	384	256	167/8 x 247/8	$18_{16}^{5} \times 26_{16}^{5}$
20 x 20	400	267	20 8 x 20 1	$22\frac{3}{8} \times 22\frac{3}{8}$
20 x 24	480	320	20 5 x 24 5	223/8 x 263/8
20 x 26	520	347	20 \$ x 26 \$	$22\frac{3}{8} \times 28\frac{3}{8}$
21 x 29	609	403	21 8 x 29 8	$23\frac{3}{8} \times 31\frac{3}{8}$
27×27	729	486	27 18 x 27 18	293/8 x 293/8
27 x 38	1026	684	27 § x 38 §	$29\frac{3}{8} \times 40\frac{3}{8}$
30×30	900	600	30 x 30 #	$32\frac{3}{8} \times 32\frac{3}{8}$

Dimensions of different makes of registers vary slightly. The above are for Tuttle & Balley Mfg. Co.'s manufacture.

TABLE XXI.

SQUARE FEET OF EXPOSED GLASS SURFACE IN WINDOWS OF VARIOUS SIZES.

Width of Window		HEIGHT OF WINDOW IN FEET											
Feet.	2	21/2	3	31/2	4	41/2	5	51/2	6	.61/2	7	71/2	8
1.1/2	3	4	41/2	51/2	6	7	71/2	81/2	9	10	101/2	111/2	12
2	4	5	6	7	8	9	10	11		13	14	15	16
$2\frac{1}{2}$	5	61/2	71/2	9	10	111/2	121/2	14	15	161/2	171/2	19	20
3	6	$7\frac{1}{2}$	9	101/2	12	$13\frac{1}{2}$	15	161/2	18	$19\frac{1}{2}$	0.	221/2	24
$3\frac{1}{2}$	7	9	101/2	$12\frac{1}{2}$	14	16	171/2	$19\frac{1}{2}$	21		$24\frac{1}{2}$	261/2	28
4	8	10	12	14	16	18	20	22			28	30	32
$4\frac{1}{2}$	9	$11\frac{1}{2}$	131/2	16	18	$20\frac{1}{2}$	$22\frac{1}{2}$	25	27	$29\frac{1}{2}$	$31\frac{1}{2}$	34	36
5 -	10		15	171/2	20	$22\frac{1}{2}$	25	271/2	30	$32\frac{1}{2}$	35	371/2	40
$5\frac{1}{2}$	11	14	161/2	$19\frac{1}{2}$			271/2	$30\frac{1}{2}$	33	36		$41\frac{1}{2}$	44
6	12	15	18	21	24			33	36	39	42		48
$6\frac{1}{2}$	13	$16\frac{1}{2}$	191/2	23	26	$29\frac{1}{2}$	$32\frac{1}{2}$	36	39	$42\frac{1}{2}$	$45\frac{1}{2}$	49	52
7´-	14				28	$31\frac{1}{2}$	35					$52\frac{1}{2}$	56
$7\frac{1}{2}$	15	19	$22\frac{1}{2}$	$26\frac{1}{2}$				$41\frac{1}{2}$	45	49	$52\frac{1}{2}$	$56\frac{1}{2}$	
8 -	16	20			32			44	48	52	56	60	64

A	В
Page	Page
Accelerated Heating, By Centrif-	Baffler, Kriebel System 173
ugal Pumps 108	
Accelerated Heating, Sizes of	Bishop-Babcock-Becker System
Radiator Tappings 104	of Vacuum Heating156, 157
Accelerated Hot Water Heating 96	Bleeder, From Main 53
Accelerated Hot Water Heating,	Blowing Off Boiler 189
Methods Employed 96	Boiler Construction 23
Accelerated Systems, Details of	Boiler, Method of Blowing Off. 189
Construction104, 105, 106	Boiler, Radiator and Pipe Con-
Adsco System, The 177	nections for Hot Water Heat-
Air, Characteristics of 186	ing 88
Air, Composition of 186	Boiler, Radiator and Pipe Con-
Air Ducts and Registers, Table	nections for Steam Heating 52
of Sizes	Boilers, Cast Iron, How Rated. 24
Air Ducts for Indirect Heating. 38	Boiler Setting 30
Air, Moisture In 186	Boilers for Heating 23
Air, Movement of, Table 196	Boilers, Grate Surface 23
Air, Quantity Discharged per	Boilers, Heating Surface 23
Minute, Table 196	Boilers, Horse Power of 24
Air, Supply for Indirect Radia-	Boilers, Pressure Commonly Al-
tor37, 38	lowed
Air Valves	Boilers, Types of
Air Valves, Automatic.128, 129, 130	Boiler Trimmings and Setting. 25
Air Valves, Compression 131	Boiling Points of Liquids, Table. 192
Air Valves, Purpose of 127	Box Coil
Altitude Gauge, Description of,	Branch or Riser Connection 52
88, 89	British Thermal Unit 12
Altitude Gauge, Location on an	Bronzing and Painting 191
Accelerated System 106	Broomell System of Vapor Heat-
Angle Valve121, 123	ing160, 161
Areas of Circles, Table 193	B. T. U. Required for Heating
Atmospheric and Modulated Sys-	Air, Table 196
tems	
Atmospheric Pressure 134	C
Atmospheric System 177	
Atmospheric System, Sizes of	Capacities of Standard Wrought
Main and Return 178	Iron Pipes, Table 200
Automatic Air Valves, Types	Care of a Heating Apparatus 190
of128, 129	Centrifugal Pumps for Accel-
Automatic Relief Valve, Gorton	erated Heating 108
System 156	Check Valve121, 123
Auxiliary Heaters 116	Chimney, Area Required 17

I	Page		Page
Chimney Flue, Factors of	17	Direct Radiator, Location of	34
Chimney Flues, Dimensions of	18	Divided-circuit System of Steam	
Chimney Flues, Table	194	Heating46,	48
Chimney, Method of Increasing		Domestic Hot Water Heating	116
Draft	17	Domestic Hot Water Supply,	
Chimneys and Fuels	15	Horizontal Boiler	118
Chimneys, Characteristics of	190	Domestic Hot Water Supply,	
Chimneys, Design of	15	Steam Coil in Boiler	119
Circuit System, Details of Con-		Domestic Hot Water Supply,	
struction	83	Vertical Boiler	117
Circuit System of Hot Water		Double Swing Joint	59
Heating	81	Draft Doors, Method of Con-	
Circuit System of Steam Heat-		necting Chains28,	29
ing46,	47	Draw-off Cock	28
Circuit System, Size of Mains.	83	Dripping a Riser, Method of	58
Circuit System, Special Fittings		Drip Pipes from Steam Mains,	
Employed	83	Table of Sizes	54
Circulation Through Radiator,		Drips for Risers	54
Kriebel System	174	Drop-Riser, Definition of	52
Coal, Characteristics of	188	Dunham Air Trap	157
Coal, Composition of	21	Dunham System, Connections	
Coal, Size of	19	to Boiler and Tank	158
Coil, A Box	31	Dunham System of Vacuum	
Coil, A Corner	32	Heating155,	156
	33		
Con, A Minre,	- OO 1		
Coil, A Mitre32, Coil, Return-bend32,	34	E	
Coil, Return-bend		E	
Coil, Return-bend32, Combustion	34	-	55
Coil, Return-bend32, Combustion Combustion of Fuel, How Cal-	34	Eccentric Fittings	55 55
Coil, Return-bend32, Combustion	34 18	Eccentric Fittings Eccentric Reducing Tee	
Coil, Return-bend32, Combustion Combustion of Fuel, How Calculated Comparative Cost of Heating	34 18	Eccentric Fittings Eccentric Reducing Tee Eddy System of Vacuum Heat-	55
Coil, Return-bend32, Combustion	34 18 19 13	Eccentric Fittings Eccentric Reducing Tee Eddy System of Vacuum Heating157,	55
Coil, Return-bend32, Combustion	34 18 19 13 21	Eccentric Fittings Eccentric Reducing Tee Eddy System of Vacuum Heating157, Ejector and Condenser, Moline	55 159
Coil, Return-bend32, Combustion	34 18 19 13 21 23	Eccentric Fittings Eccentric Reducing Tee Eddy System of Vacuum Heating157, Ejector and Condenser, Moline System	55
Coil, Return-bend	34 18 19 13 21 23 174	Eccentric Fittings Eccentric Reducing Tee Eddy System of Vacuum Heating157, Ejector and Condenser, Moline System Equalizing Pipe69,	55 159 171
Coil, Return-bend	34 18 19 13 21 23 174 38	Eccentric Fittings Eccentric Reducing Tee Eddy System of Vacuum Heating	55 159 171 70
Coil, Return-bend	34 18 19 13 21 23 174 38 32	Eccentric Fittings	55 159 171 70 82
Coil, Return-bend	34 18 19 13 21 23 174 38 32	Eccentric Fittings	55 159 171 70 82 44
Coil, Return-bend	34 18 19 13 21 23 174 38 32	Eccentric Fittings	55 159 171 70 82 44 64
Coil, Return-bend	34 18 19 13 21 23 174 38 32	Eccentric Fittings	55 159 171 70 82 44 64
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13	Eccentric Fittings	55 159 171 70 82 44 64 54
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13	Eccentric Fittings	55 159 171 70 82 44 64 54
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13	Eccentric Fittings	55 159 171 70 82 44 64 54
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13	Eccentric Fittings	55 159 171 70 82 44 64 54
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13 27 28 205	Eccentric Fittings	55 159 171 70 82 44 64 54
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13	Eccentric Fittings	55 159 171 70 82 44 64 54 111
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13 27 28 205 200	Eccentric Fittings	55 159 171 70 82 44 64 54 111
Coil, Return-bend	34 18 19 13 21 23 174 38 32 13 27 28 205 200	Eccentric Fittings	55 159 171 70 82 44 64 54 111 110

Page	Page
Expansion Tanks, Rules for	Heating, Domestic Hot Water
Determining Sizes112, 113	Supply 116
Expansion Tanks, Table of Sizes	Heating Feed Water 44
and Capacities 80	Heating Greenhouses 180
- ·	Heating Surface in Tubular
F	Boilers 190
	Heating Surface in Wrought
Fahrenheit Scale	Pipe, Table
False Water Line, How Created,	Heating Systems, Average Life. 13
61, 66	Heating Systems, What is Con-
Fittings, Tapped Eccentric 55	sidered Best
Forty-five Degree Connection,	Heating, Vacuum, Vapor and
55, 56, 58	Vacuo-Vapor
Fuel	Heat, Mechanical Equivalent of. 12
Fuel, Characteristics of 188	Heat, Unit of
Fuel, Combustion of 19	Heat Units in Water, Table 197
Fuel, Economical Firing 21	Heat, What It Is
Fuel, Expense of	Honeywell Generator97, 98, 99
Fuel, Kinds of	Honeywell Generator, Method
Fuel, Rate of Combustion 19	of Connecting
Fuel Required for Heating 22	Horse Power
Fuels and Chimneys 15	Hot Water Circulation, Princi-
•	ples of
G	Hot Water Heating 72
	Hot Water Heating, Accelerated
Galvanized Iron Pipe, Weights	Methods 96
per Lineal Foot, Table 204	Hot Water Heating, Advantages
Galvanized Sheet Iron, Sizes	Claimed for Closed System 72
and Weights, Table 203	Hot Water Heating, Boiler,
Gate Valve121, 122, 124	Radiator and Pipe Connec-
Gate Valve with Yoke 124	tions 88
Glass Surface in Windows, Table 206	Hot Water Heating, Circuit
Globe Valve 120	System
Globe Valve, Improper Use of 121	Hot Water Heating, Expansion
Gorton System of Vacuum Heat-	Tank Connections 109
ing152, 153, 154	Hot Water Heating, Method of
Grate Surface, How Determined 23	Sealing the System 73
Greenhouse Heating 180	Hot Water Heating, Open Tank
Greenhouse Heating, Method	System
of Piping	Hot Water Heating, Radiator
Greenhouse Piping System 184	Connections90, 91, 92, 93
	Hot Water Heating, Radiator
H	Tappings
	Hot Water Heating, Sizes of
Heat, Equalizing of	Mains and Branches 95
Heat, How Measured 11	Hot Water Heating, The Eureka
Heat, How Transferred 11	Fitting 82
Heating Apparatus, Proper Care	Hot Water Heating, The Over-
of	head System 84

Page	Page
Hot Water Heating, The Phelps	Method of Connecting Radia-
Single Main Tee 83	tors for Overhead System . 60, 65
Hot Water Heating, The Two-	Method of Connecting Radia-
Pipe Gravity System 75, 76	
Hot Water Radiator Valve 126	
Hot Water Risers, Method of	Method of Dripping a Riser. 58
Connecting	Method of Supporting Riser,
Hot Water Systems, Details of	
Construction77, 78, 79	36 (1 1 4 77)
Hot Water Systems, How Clas-	Methods of Heating
sified 72	Mills System of Steam Heating,
Hot Water Thermometer, Use	Touting,
of	50, 51 Milwaukee Heat Generator 100
J	3.5: 11
ī	
•	Mitre Coil
Impulse Valve, Gorton System 155	Modulated Systems 177
Indirect Heating, Sizes of Air	Moline System, Method of In-
Ducts and Registers 38	stallation
Indirect Radiation, Amount Re-	Moline System of Vacuum-
quired	Vapor Heating 169, 170, 171, 172
Indirect Radiator, Air Supply, 37, 38	Mouat System of Vapor Heat-
Indirect Radiator, Location of. 36	ing162, 163
Indirect Radiator, Location of. 36 Information, Rules and Tables. 186	Movement of Air, Table 196
imorination, funes and rables. 190	ł.
Internal Areas of Dine Wahle 200	
Internal Areas of Pipe, Table 202	N
_	
Internal Areas of Pipe, Table 202	Ninety Degree Connection, 55, 56, 57
K	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Sys-
K K-M-C System of Vacuum	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K-M-C System of Vacuum Heating151, 152, 153	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of In-	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of Installation175	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of Installation175 Kriebel System of Vacuum-	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of Installation175 Kriebel System of Vacuum-Vapor Heating173, 174, 175	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of Installation175 Kriebel System of Vacuum-	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of Installation175 Kriebel System of Vacuum-Vapor Heating173, 174, 175 Kriebel System, Operation of 176	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of Installation175 Kriebel System of Vacuum-Vapor Heating173, 174, 175	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating151, 152, 153 Kriebel System, Method of Installation175 Kriebel System of Vacuum- Vapor Heating173, 174, 175 Kriebel System, Operation of 176 M	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems
K K-M-C System of Vacuum Heating	Ninety Degree Connection, 55, 56, 57 Non-Mechanical Vacuum Systems

Page	Page
Overhead System of Steam	Radiation Required for Vapor-
Heating	Vacuum Heating 139
,	Radiation, Rules for Estimating,
P	38, 39
D11 17-1 104 107	Radiator, Direct
Packless Valve	Radiator and Pipe Connections
Paul Exhauster, High Pressure. 143	for Hot Water Heating 88
Paul Exhauster, Low Pressure. 142	Radiator and Pipe Connections
Paul System, Down Feed Ex-	for Steam Heating 52
haust	Radiator Connections for Hot
Paul System of Vacuum Heat-	Water Heating . 90, 91, 92, 93
ing142, 143, 144, 145	Radiator, Direct-Indirect or
Paul System, Regular High Pressure	Semi-Direct
Pressure	Radiator Tappings for Acceler-
	ated Heating 104
Phelps Single Main Tee 83 Pipe Coils, Surface In 189	Radiator Tappings, Hot Water
Pipe Connections for Steam	Heating93, 94
Heating	Radiator Valve, Hot Water 126
Pipe, Expansion of 54, 64, 65	Radiator Valve, Simplex Hot
Pipe Risers, Area of 65	Water 131
Pipe, Table Internal Areas and	Radiator Valves, Special Types,
Weights	125, 126, 128
Piping, Method of Crossing I	Radiator Valve, Steam 125
Beam 71	Receiver and Regulator, Broom-
Pop-Safety Valve	ell System164, 165
Pressure for Heating Boilers 25	Receiver, Trane Vapor System. 166
Pressure of Water by Siphon	Registers and Air Ducts, Table
Draft Gauge, Table 194	of Sizes
Properties of Saturated Steam,	Registers for Indirect Heating. 38
Table	Relief System of Steam Heat-
Pump and Condenser, Bishop-	ing
Babcock-Becker System 161	Retainer Valve, K-M-C System. 153
	Return-Bend Coil32, 34 Return Header69, 71
Q	·
	Return Pipe, Definition of 52 Return Pipes, Wet or Dry 61
Quintuple Valve, Broomell Sys-	Riser Connection or Branch 52
tem 162	Riser, Definition of
70	Riser, Expansion of
R	Risers, Size of Drips 54
Radiating Surfaces	Rules for Estimating Radiation,
Radiating Surfaces, Types of, 31, 33	38, 39
Radiation	Rules, Tables and Information. 186
Radiation Required for Green-	
house Heating	s
Radiation Required for Vacuum	_
Heating	Safety Valve
Radiation Required for Vapor	Simplex Hot Water Radiator
Heating	Valve

]	Page	1	Page
Sizes Galvanized Sheet Iron,		Table I, Boiling Points of Fluids,	192
Table	203	Table II, Temperature of Fire	192
Size of Steam Mains, One-Pipe		Table III, Approximate Melting	
System	64	Points of Metals	192
Sizes of Steam Mains, Rules for		Table IV, Areas of Circles	
Determining63,	64	Table V, Chimney Flues	194
Square Feet of Exposed Glass in		Table VI, Pressure in Inches of	
Windows, Table	206	Water by Siphon Draft Gauge	194
Steam, B. T. U. Emitted	187	Table VII, Amount of Vacuum	
Steam, Characteristics of	187	Secured at Different Tem-	
Steam Gauge	26	peratures	195
Steam Header67,	70	Table VIII, Velocity of Flow of	
Steam Heating	42	Water	195
Steam Heating, Boiler, Radiator		Table IX, B. T. U. Required for	
and Pipe Connections	52	Heating Air	
Steam Heating, Circuit System,		Table X, Ventilation	
46,	47	Table XI, Heat Units in Water.	197
Steam Heating, Divided-Circuit		Table XII, Properties of Satu-	
System46,	48	rated Steam	198
Steam Heating, Exhaust43,	44	Table XIII, Number of U. 8.	
Steam Heating, Gravity Return,	42	Gallons in Tanks	199
Steam Heating, High Pressure		Table XIV, Dimensions and	
42,	43	Capacities of Standard	
Steam Heating, Low Pressure.	42		200
Steam Heating, Methods of In-	40	Table XV, Heating Surface in	
stallation	42	Wrought Pipe	201
Steam Heating, One-Pipe Meth-		Table XVI, Internal Areas of	
od	44	Different Sizes and Weights	
Steam Heating, Overhead or	21	of Pipe	202
Mills System50,	51	Table XVII, Capacities and	
Steam Heating, Relief System, 44.	45	Threads of Standard Wrought Iron Pipe	900
_ •	460	Table XVIII, Galvanized Sheet	202
Steam Heating, Systems in General Use	42	Iron—Sizes and Weights	203
Steam Heating, Two-Pipe Sys-	44	Table XIX, Galvanized Sheet	203
tems49,	50	Iron Pipe	204
Steam Main	52	Table XX, Dimensions of Regis-	201
Steam Main, Method of Cross-	02	ters	205
ing Beam	71	Table XXI, Square Feet of Ex-	200
Steam Radiator Valve	125	posed Glass Surface in Win-	
Strength of Tubular Boilers	190	dows of Various Sizes	206
Surface in Pipe Coils	189	Table, Drip Pipes for Steam	
Swing Joint58,	59	Mains	54
Systems of Steam Heating	42	Table, Expansion of Wrought	
		Pipe	54
T		Table, Radiation Required for	
_		Greenhouse Heating	182
Table. Boiling Point of Water,		Table, Radiator Tappings for	
	138	Hot Water	94

INDEX

Page	Page
Table, Size of Drips for Risers 54	1
Table, Size of Mains for Circuit	Unique Radiator Valve Closed,
System 83	· · · · · · · · · · · · · · · · · · ·
Table, Size of Mains, One-Pipe	Unique Radiator Valve Open,
System 64	1
Table, Sizes and Capacities of	U. S. Gallons in Tanks, Table . 199
Expansion Tanks 80	
Table, Sizes of Main and Return	v
for Atmospheric System 178	
Table, Sizes of Mains and	Vacuo-Vapor Heating 133
Branches for Hot Water Heat-	Vacuum Heating, Bishop-Bab-
ing 95	•
Table, Sizes of Supply and Re-	Vacuum Heating, Eddy System,
turn Pipes for Vapor Heating. 170	1
Table, Temperatures and Pres-	Vacuum Heating, Dunham Sys-
sures of Water 73	= -
Tables, Information and Rules. 186	I
Tank Circulator, Method of	tem152, 153, 154
Connecting 107	Vacuum Heating, K-M-C Sys-
Tank Circulator, The Honeywell 107	tem151, 152, 153
Tank Heaters, How Rated 117	Vacuum Heating, Mechanical
Tanks, Capacities of 189	Systems
Tee, Used "Bull-Head"56, 57	Vacuum Heating, Paul System,
Temperature of Fire, Table 192	142, 143, 144, 145
Theory and Laws of Heat 11	Vacuum Heating, Principles of,
To Clean a Water Gauge 190	——————————————————————————————————————
Trane Mercury Seal 149	Vacuum Heating, Principles of
Trane-Paul Air Valve 150	
Trane System of Vapor Heating,	Vacuum Heating, Radiation Re-
163, 164, 165, 166	
Trane Vacuum System 148, 149, 150	
Trane Vapor System, Method	148, 149, 150
of Installation 167	Vacuum Heating, Van Auken
Tubular Boilers, Heating Sur-	System 146
face In	
Tubular Boilers, Strength of 190	
Two-Pipe Gravity Hot Water	Vacuum, How Measured 137
Heating, Method Employed,	Vacuum, How Produced 135
75, 76	
Two-Pipe System, Method of	Temperatures, Table 195
Connecting Radiators, 59, 61,	Vacuum Systems, Non-Mechani-
62, 63	
Two-Pipe System of Steam	Vacuum, Vapor and Vacuo-
Heating49, 50	
Types of Radiator Surfaces 31	Vacuum-Vapor Heating, Kriebel
	System
U	Vacuum-Vapor Heating, Moline
•	System169, 170, 171, 172
Union Elbow, Broomell System. 163	

INDEX

Page	Page
Valves and Air Valves 120	Vertical Checks, K-M-C System.
Valves, Types Employed on	151, 152
Heating Apparatus 120	-
Van Auken System of Vacuum	W
Heating 146	
Vapor and Vacuo-Vapor Heat-	Water, Boiling Point of 137, 138, 187
ing 133	
Vapor Heating, Broomell Sys-	Water Column and Gauge 26
tem160, 161	Water, Expansion of 187
Vapor Heating, Mouat System,	Water, Gallons per Cubic Foot. 186
162, 163	Water Gauge, How to Clean 190
Vapor Heating, Radiation Re-	Water Hammer, Reason for 60
quired40, 41, 139	Water Line, Distance Required,
Vapor Heating, Sizes of Supply	62, 63
and Return Pipes 170	Water, Pounds per Cubic Foot. 186
Vapor Heating, Trane System,	Water, Pressure of 187
163, 164, \ 165, 166	Water, Table of Temperatures
Vapor Heating, Vapor Regula-	and Pressures
tor Co168, 169	
Vapor Heating, What It Is. 138, 139	178, 179
Vapor Regulator Co's. Special-	Webster Motor Valve 141
ties 168	Webster System of Vacuum
Vapor Regulator Co's. System,	Heating 141
Method of Installing 169	Weights and Areas of Pipe,
Vapor Regulator Co's. System	Table
of Vapor Heating168, 169	Weights of Galvanized Sheet
Vapor Systems 160	Iron, Table 203
Vapor-Vacuum Heating, Radia-	Wrought Iron Pipe, Table of
tion Required 139	
Velocity of Flow of Water, Table 195	Wrought Pipe, Heating Surface
Ventilation, Table 196	In, Table 201





EACH BOOK IN THIS CATALOGUE IS WRITTEN
BY AN EXPERT AND IS WRITTEN SO
YOU CAN UNDERSTAND IT

PUBLISHED BY

THE NORMAN W. HENLEY PUBLISHING CO.

Publishers of Scientific and Practical Books

132 NASSAU STREET, NEW YORK, U. S. A.

Any Book in this Catalogue sent prepaid on receipt of price

SUBJECT INDEX

PAGE	PAGE
Accidents 20	Marine Engines
Air Brakes	Marine Steam Turbines 30
Arithmetics	Mechanical Movements 22
Automobiles	Metal Turning
Balloons 5	Milling Machines
Bevel Gears	Mining 24
Boilers	Oil Engines 15
Brazing 6	Patents 17
Cams	Patternmaking
Change Gears	Perfumery
Charts 6	Pipes
Chemistry	Plumbing
Coal Mining	Producer Gas
Coke7	Punches 10
Compressed Air 7	Railroad Accidents 20
Concrete	Recipe Book
Cyclopedia	Refrigeration
Dictionaries	Rope Work
Dies	Rubber Stamps
Drawing	Saws
Drop Forging	Sheet Metal Working
Dynamo	Shop Tools
Electricity	Shop Construction
Engines and Boilers	Shop Management
Factory Management 14	Sketching Paper
Flying Machines	Smoke Prevention 14
Fuel	Soldering
Gas Engines	Splices
Gas Tractor	Steam Engineering
Gears	Steam Heating
Heating, Electric	Steam Pipes
Hot Water Heating	Steel
Horse-Power Chart 6	Suberheated Steam
Hydraulics	Switchboards
Ice Making	Tapers
India Rubber	Telephone
Interchangeable Manufacturing	Threads
Inventions	Tools
Knots	Tractor. Gas
Lathe Work	Turbines
Lighting (Electric) 11	Ventilation
Link Motion	Valve Gear
Liquid Air	Valve Setting 19
Locomotive Boilers	Walschaert Valve Gear 20
Locomotive Engineering	Watchmaking
Machinists' Books	Wiring
Manual Training 23	Wireless Telephones and Telegraphy 13
Mission Itsimik	м и отсяза теперионся япи телейстрий 12

TANY OF THESE BOOKS PROMPTLY SENT PREPAID TO ANY ADDRESS IN THE WORLD ON RECEIPT OF PRICE.

THOW TO REMIT.—By Postal Money Order, Express Money Order, Bank Draft or Registered Letter.

150 Pages of New Matter and Just Published! 1914 Revised Edition! Contains Up-to-the-minute Information. Engravinge Added.

The MODERN GASOLINE *AUTOMOBILE*

Its Construction, Operation, Maintenance and Repair.

By VICTOR W. PAGÉ, M. E.

575 Illustrations-Over 850 Pages-Eleven Large Folding Plates

PRICE \$2.50

A COMPLETE AUTOMOBILE BOOK, SHOWING EVERY RECENT IMPROVEMENT

By a careful study of the pages of this book one can gain practical knowledge of the automobile that will save time, money, and worry. The book tells you just what to do, how and when to do it. Nothing has been omitted, no detail has been slighted. Every part of the automobile, its equipment, accessories, tools, supplies, spare parts necessary, etc., have been discussed comprehensively. If you are or intend to become a motorist, or are in any way interested in the modern Gasoline Automobile, this is a book you cannot afford to be without.

COVERS EVERY PHASE OF UP-TO-DATE AUTOMOBILE PRACTICE AND IS SUPERIOR TO ANY TREATISE HERETOFORE PUBLISHED

Written in simple language by a recognized authority, familiar with every branch of the automobile industry. Free from technical terms. Everything is explained as simply that anyone of average intelligence may gain a comprehensive knowledge of the gasoline automobile. The information is up to date and includes, in addition to an exposition of principles of construction and description of all types of automobiles and their parts, valuable money-saving hints on the care and operation of motor cars pro-pelled by internal combustion engines.

Motorists, students, salesmen, demonstrators, repairmen, chauffeurs, garage owners, and even designers or engineers need this work because it is complete, authoritative and thoroughly up-to-date. Other works dealing with automobile construction published in the past make no reference to modern improvements because of their recent development. All are fully discussed and illustrated in this volume.

CONTAINS SPECIAL CHAPTERS ON

I. Types of Modern Automobiles. II. How Power is Generated. III. Principal Parts of Gasoline Engines, Their Design, Construction, and Application. IV. Constructional Details of Pistons. V. Liquid Fuels Used and Methods of Vaportsing to Obtain Explosive Gas. VI. Automobile Power-Plant Ignition Systems Outlined. VII. Reasons for Lubrication of Mechanism. VIII. Utility of Clutches and Genreets. IX. The Chassis and Its Parts. X. Wheels, Rims, and Tires. XI. Motor Car Equipment and Accessories. XII. Operating Advice and Explanation of Automobile Control Methods. XIII. Hints to Assist in Locating Power-Plant Troubles. XIV. Keeping Up the Motor-Car Chassis.

WHAT IS SAID OF THIS BOOK:

- "It is the best book on the Automobile seen up to date."—J. H. Pile, Associate Editor, Automobile seen up to date."—J. H. Pile, Associate Editor, Automobile Trade Journal.

 "Every Automobile Owner has use for a book of this character."—The Tradesmon.

 "This book is superior to any treatise heretofore published on the subject."—The Invention Age.

 "We know of no other volume that is so complete in all its departments, and in which the wide field of sutemobile construction with its mechanical intricacies is so plainly handled, both in the text and in the matter of illustrations."—The Motoriet.

 "The book is very thorough, a careful examination falling to disclose any point in connection with the sutemobile, its care and repair, to have been overlooked."—Iron Age.

 "Mr. Pagé has done a great work, and benefit to the Automobile field."—W. C. Hasford, Mgr. Y. M. C. A. Automobile School, Boston, Mass.

 "It is just the kind of a book a motorist needs if he wants to understand his car."—Associon Threshermon.

JUST PUBLISHED!

QUESTIONS AND ANSWERS

RELATING TO MODERN

AUTOMOBILE DESIGN. CONSTRUCTION AND REPAIR

By VICTOR W. PAGÉ, M. E.,

Author of "The Modern Gasoline Automobile", "The Modern Gas Tractor", Etc., Etc.

600 (6x9) Pages.

350 Illustrations.

PRICE \$1.50.



'HIS practical treatise consists of a series of thirty-six lessons, covering with nearly 2000 questions and their answers—the automobile, its construction, operation and repair. The subject matter is absolutely correct and explained in simple language. If you can't answer all of the following questions, you need this work. The answers to these and nearly 2000 more are to be found in its pages.

Give the name of all important parts of an automobile and describe their functions. Describe action of latest types of kerosene carburetors. What is the difference between a "Double" ignition system and a "dual" ignition system? Name parts of an induction coil? How are valves timed? What is an electric motor starter and how does it

work? What is an electric motor starter and how does it work? What are advantages of worm drive gearing? Name all important types of ball and roller bearings? What is a "Three-quarter" floating axle? What is a two-speed axle? What is the Vulcan electric gear shift? Name the causes of lost power in automobiles. Describe all noises due to deranged mechanism and give causes? How can you adjust a carburetor by the color of the exhaust gases? What causes "popping" in the carburetor? What tools and supplies are needed to equip a car? How do you drive various makes of cars? What is a differential lock and where is it used? Name different waters of wire wheel construction at a set. systems of wire wheel construction, etc., etc.

A popular work at a popular price. Answers every question you may ask relating to the modern automobile.

SYNOPSIS OF THE 36 LESSONS

- 1. The Modern Gasoline Automobile and Its Principal Parts.
 Action of Two and Four Stroke Cycle Motors.
 Parts of Gasoline Motors and Their Function.

- Fuels for Automobile Motors.
 Theory of Carburetion and Its Application.
 Types of Carburetors and Their Action. How Gas is Exploded in Cylinder to Produce Power.
- Parts of Ignition Systems and Their Purpose. Current Producers, Batteries, Dynamos and
- Magnetos.

 10. Low Tension Ignition Systems.

 11. High Tension Ignition Systems.
- 12. Methods of Lubricating the Automobile Power Plant.
- 13. Cooling the Gasoline Engine by Air.
- 14. Typical Water Cooling Systems.
- Use of Clutch and Various Types Described.
- The Friction Transmission.
- 17. The Individual Clutch Change Speed Gear.

- Action of Sliding Gear Transmissions.

 Methods of Drive to Rear Wheels.

 Differential Gear Construction and Opera-19. 20. tion.

- tion.
 Rear Axle Types.
 Automobile Frames and Springs.
 The Steering Gear and Front Axle.
 Wheels, Rims and Tires.
 Automobile Bearings and Their Care. 23.
- How to Start and Control Automobile Power Plants.
- Methods of Speed Changing Outlined.
 Utility of Brakes and Their Use.
 General Driving Instructions.
- 29.

- Oiling the Automobile Chassis,
 Road Troubles and Their Symptoms,
 Repairing Power Plant Group,
 Troubles With Power Transmission Mechanism.
- Chassis Troubles and Their Elimination.
 Fixing Tire Defects.
- Equipment and Accessories.

AUTOMOBILE

THE MODERN GASOLINE AUTOMOBILE—ITS DESIGN, CONSTRUCTION, MAINTENANCE AND REPAIR. By Victor W. Page, M. E.

The latest and most complete treatise on the Gasoline Automobile ever issued. Written is simple language by a recognized authority, familiar with every branch of the automobile industry. Free from technical terms. Everything is explained so simply that anyone of average intelligence may gain a comprehensive knowledge of the gasoline automobile. The information is up-to-date and includes, in addition to an exposition of principles of construction and description of all types of automobiles and their components, valuable money-saving hints on the care and operation of motorcars propelled by internal combustion engines. Among some of the subjects treated might be mentioned: Torpedo and other symmetrical body forms designed to reduce air resistance; sleeve valve, rotary valve and other types of silent motors; increasing tendency to favor worm-gear power-transmission: universal application of magneto ignition; development of automobile electric-lighting systems; block motors; underslung chassis; application of practical self-starters; long stroke and offset cylinder motors; latest automatic lubrication systems; silent chains for valve operation and change-speed gearing; the use of front wheel brakes and many other detail refinements. By a careful study of the pages of this book one can gain practical knowledge of automobile construction that will save time, money and worry. The book tells you just what to do, how and when to do it. Nothing has been omitted, no detail has been slighted. Every part of the automobile, its equipment, accessories, tools, supplies, spare pasts necessary, etc., have been discussed comprehensively. If you are or intend to become a motorist, or are in any way interested in the modern Gasoline Automobile, this is a book you cannot afford to be without. Over 800 6x9 pages—and more than 575 new and specially made netal illustrations, as well as many full pace and double page paires, showing all parts of the automobile. Including 11 large folding plates. 1914 edition just issued. (See page 3 for

QUESTIONS AND ANSWERS ON AUTOMOBILE DESIGN, CONSTRUCTION AND REPAIR. By Victor W. Pagé, M. E.

This practical treatise consists of thirty-six lessons covering with nearly 2000 questions and their answer—the automobile, its construction, operation and repair. The subject matter is absolutely correct and explained in simple language. The book is copiously illustrated with drawings and photographs, showing the latest domestic and foreign practice. 639 pages, 329 illustrations and plates. (See page k for full description.)

Proc \$1.50

WHAT IS SAID OF THIS BOOK: "If you own a car-Get this book."—The Glassworker.

GASOLINE ENGINE TROUBLES MADE EASY—A CHART SHOWING SECTIONAL VIEW OF GASOLINE ENGINE. Compiled by Victor W. Page.

It shows clearly all parts of a typical four cylinder gasoline engine of the four-cycle type. It outlines distinctly all parts liable to give trouble and also details the derangements apt to interfere with smooth engine operation.

Valuable to students, motorists, mechanics, repairmen, garagemen, automobile salesmen, chaufieurs, motorboat owners, motor truck and tractor drivers, aviators, motorcyclists, and all others who have to do with gasoline power plants.

It simplifies location of all engine troubles, and while it will prove invaluable to the novice, it can be used to advantage by the more expert. It should be on the walls of every public and private garage, automobile repair shop, club house or school. It can be carried in the automobile or pocket with ease, and will insure against loss of time when engine trouble manifests itself.

This sectional view of engine is a complete review of all motor troubles. It is prepared by a practical motorist for all who motor. More information for the money than ever before offered. No details omitted. Size 25x38 inches. Securely mailed on receipt of

BALLOONS AND FLYING MACHINES

MODEL BALLOONS AND FLYING MACHINES, WITH A SHORT ACCOUNT OF THE PROGRESS OF AVIATION. By J. H. Alexander.

This book has been written with a view to assist those who desire to construct a model airship or flying machine. It contains five folding plates of working drawings, each sheet containing a different sized machine. Much instruction and amusement can be obtained from the making and flying of these models.

A short account of the progress of aviation is included, which will render the book of greater interest. Several illustrations of full sized airship and flying machines of the

[&]quot;Mr. Page has the faculty of making difficult subjects plain and understandable."

[&]quot;We can name no writer better qualified to prepare a book of instruction on automobiles than Mr. Victor W. Pagé."—Scientific American.

[&]quot;The best automobile catechism that has appeared."-Automobile Topics.

BRAZING AND SOLDERING

BRAZING AND SOLDERING. By JAMES F. HOBART.

The only book that shows you just how to handle any job of brazing or soldering that comes along; it tells you what mixture to use, how to make a furnace if you need one. Full of valueble kinks. The fifth edition of this book has just been published, and to it much new matter and a large number of tested formulas for all kinds of solders and fluxes have been added. Illustrated. \$5 cents

CHARTS

GASOLINE ENGINE TROUBLES MADE EASY—A CHART SHOWING SECTIONAL VIEW OF GASOLINE ENGINE. Compiled by Victor W. Page. It shows clearly all parts of a typical four-cylinder gasoline engine of the four-cycle type. It outlines distinctly all parts liable to give trouble and also details the derangements apt to interfere with smooth engine operation. Valuable to students, motorists, mechanics, repairmen, garagemen, automobile salesmen, chauffeurs, motorboat owners, motor-truck and tractor drivers, aviators, motor-cyclists, and all others who have to do with gasoline power plants. It simplifies location of all engine troubles, and while it will prove invaluable to the novice, it can be used to advantage by the more expert. It should be on the walls of every public and private garage, automobile repair shop, club house or school. It can be carried in the automobile or pocket with ease and will insure against loss of time when engine trouble manifests itself. This sectional view of engine is a complete review of all motor troubles. It is prepared by a practical motorist for all who motor. No details omitted. Size 25x38 inches. MOTORCYCLE TROUBLES MADE EASY—A CHART SHOWING SECTIONAL VIEW OF TWIN CYLINDER GASOLINE ENGINE. Com-

TIONAL VIEW OF TWIN CYLINDER GASOLINE ENGINE. piled by Victor W. Pagg.

NAMED

NAMELU

A cross-section view, showing clearly and distinctly all the interior of a Submarine of the latest type. You get more information from this chart, about the construction and operation of a Submarine, than in any other way. No details omitted—everything is accurate and to scale. It is absolutely correct in every detail, having been approved by Naval Engineers. All the machinery and devices fitted in a modern Submarine Boat are shown, and to make the engraving more readily understood, all the features are shown in operative form, with Officers and Men in the act of performing the duties assigned to them in service conditions. This CHART IS REALLY AN ENCYCLOPEDIA OF A SUBMARINE.

GONDOLA CAR CHART.

PASSENGER CAR CHART.

STEEL HOPPER BOTTOM COAL CAR.

200 parts being given.

TRACTIVE POWER CHART.

A chart whereby you can find the tractive power or drawbar bull of any locomotive without making a figure. Shows what cylinders are equal, how driving wheels and steam pressure affect the power. What sized engine you need to exert a given drawbar pull or anything you desire in this line.

HORSE POWER CHART.

Shows the horse power of any stationary engine without calculation. No matter what the cylinder diameter of stroke, the steam pressure or cut-off, the revolutions, or whether condensing or non-condensing, it's all there. Easy to use, accurate, and saves time and calculations. Especially useful to engineers and designers. 50 cents

BOILER ROOM CHART. By GEO. L. FOWLER. ER ROOM CHART. By CFO. L. FOWLER.

A chart—size 14x28 inches—showing in isometric perspective the mechanisms. Jolonging in a modern boiler room. The various parts are shown broken or removed,
so that the internal construction is fully illustrated. Each part is given a reference
number, and these, with the corresponding name, are given in a glossary printed at
the sides. This chart is really a dictionary of the boiler room—the names of more than

CIVIL ENGINEERING

HENLEY'S ENCYCLOPEDIA OF PRACTICAL ENGINEERING AND ALLIED TRADES. Edited by Joseph G. Horner, A.M.I.M.E.

TRADES. Edited by JOSEPH G. HORNER, A.M.I.M.E. This set of five volumes contains about 2.500 pages with thousands of illustrations, including diagrammatic and sectional drawings with full explanatory details. This work covers the entire practice of Civil and Mechanical Engineering. The best-known experts in all branches of engineering have contributed to these volumes. The Cyclopedia is admirably well adapted to the needs of the beginner and the self-taught, practical man, as well as the mechanical engineer, designer, draftsman, shop superintendent, foreman, and machinist. The work will be found a means of advancement to any progressive man. It is encyclopedic in scope, thorough and practical in its treatment of technical subjects, simple and clear in its descriptive matter, and without unnecessary technicalities or formules. The articles are as brief as may be and yet give a reasonably clear and explicit statement of the subject, and are written by men who have had ample practical experience in the matters of which they write. It tells you all you want to know about engineering, and tells it so simply, so clearly, so concisely that one cannot help but understand. As a work of reference it is without a peer. \$6.00 per single volume. For complete set of five volumes, price, \$35.00 WHAT IS SAID OF THIS SET OF BOOKS:

WHAT IS SAID OF THIS SET OF BOOKS:
"This new Encyclopedia is a commendable work."—Engineering News.
"This work is a great help to men engaged in mechanical occupations and those persons having need of a ready reference work."—Southern Machinery.

COKE

COKE—MODERN COKING PRACTICE; INCLUDING THE ANALYSIS OF MATERIALS AND PRODUCTS. By T. H. Byrom and J. E. Christopher.

A handbook for those engaged in Coke manufacture and the recovery of By-products. Fully illustrated with folding plates. It has been the aim of the authors, in preparing this book, to produce one which shall be of use and benefit to those who are associated with, or interested in, the modern developments of the industry. Contents: I. Introductory. II. General Classification of Fuels. III. Coal Washing. IV. The Sampling and Valuation of Coal, Coke, etc. V. The Calorific Power of Coal and Coke. VI. Coke Ovens. VII. Coke Ovens, continued. IX. Charging and Discharging of Coke Ovens. X. Cooling and Condensing Plant. XI. Gase Exhausters. XII. Composition and Analysis of Ammoniacal Liquor. XIII. Working-up of Ammoniacal Liquor. XIV. Treatment of Waste Gases from Sulphate Plants. XV. Valuation of Ammonium Sulphate. XVI. Direct Recovery of Ammonia from Coke Oven Gases. XVII. Surplus Gas from Coke Oven. Useful Tables. Very fully illustrated. Price.

COMPRESSED AIR

COMPRESSED AIR IN ALL ITS APPLICATIONS. By GARDNER D. HISCOX.

CONCRETE

JUST PUBLISHED—CONCRETE WORKERS' REFERENCE BOOKS. A SERIES OF TWELVE POPULAR HANDBOOKS FOR CONCRETE USERS. Prepared by A. A. Houghton. Each 50c.

The author, in preparing this Series, has not only treated on the usual types of construction, but explains and illustrates molds and systems that are not patented, but which are equal in value and often superior to those restricted by patents. These molds are very easily and cheaply constructed and embody simplicity, rapidity of operation, and the most successful results in the molded concrete. Each of these Twelve books is fully illustrated, and the subjects are exhaustively treated in plain English.

CONCRETE WALL FORMS. By A. A. HOUGHTON.

CONCRETE FLOORS AND SIDEWALKS. By A. A. HOUGHTON.

The molds for molding squares, hexagonal and many other styles of mosaic floor and sidewalk blocks are fully illustrated and explained. (No. 2 of Series) . . . 50 cents

PRACTICAL CONCRETE SILO CONSTRUCTION. By A. A. HOUGHTON.

Complete working drawings and specifications are given for several styles of concrete silos, with illustrations of moles for monolithic and block silos. The tables, data, and information presented in this book are of the utmost value in planning and constructing all forms of concrete silos. (No. 3 of Series.) 50 cents

MOLDING CONCRETE CHIMNEYS, SLATE AND ROOF TILES. By A. A.

MOLDING AND CURING ORNAMENTAL CONCRETE. By A. A. Houghton.

CONCRETE MONUMENTS, MAUSOLEUMS AND BURIAL VAULTS. By A. A. HOUGHTON

The molding of concrete monuments to imitate the most expensive cut stone is explained in this treatise, with working drawings of easily built molds. Cutting inscriptions and designs is also fully treated. (No. 6 of Series) 50 cents

MOLDING CONCRETE BATH TUBS, AQUARIUMS AND NATATORIUMS. By A. A. HOUGHTON.

CONCRETE BRIDGES, CULVERTS AND SEWERS. By A. A. HOUGHTON.

CONSTRUCTING CONCRETE PORCHES. By A. A. HOUGHTON.

MOLDING CONCRETE FLOWER POTS, BOXES, JARDINIERES, ETC. By A. A. HOUGHTON.

MOLDING CONCRETE FOUNTAINS AND LAWN ORNAMENTS. By A. A. HOUGHTON.

CONCRETE FOR THE FARM AND SHOP. By A. A. HOUGHTON.

The molding of drain tile, tanks, cisterns, fence posts, stable floors, hog and poultry houses and all the purposes for which concrete is an invaluable aid to the farmer are numbered among the contents of this handy volume. (No. 12 of Series) . 50 cents

CONCRETE FROM SAND MOLDS. By A. A. HOUGHTON.

A Practical Work treating on a process which has heretofore been held as a trade secret by the few who possessed it, and which will successfully mold every and any class of ornamental concrete work. The process of molding concrete with sand molds is of the utmost practical value, possessing the manifold advantages of a low cost of molds, the ease and rapidity of operation, perfect details to all ornamental designs, density and increased strength of the concrete, perfect curing of the work without attention and the easy removal of the molds regardless of any undercutting the design may have.

192 pages. Fully illustrated. Price

ORNAMENTAL CONCRETE WITHOUT MOLDS. By A. A. HOUGHTON.

The process for making ornamental concrete without molds has long been held as a secret, and now, for the first time, this process is given to the public. The book reveals the secret and is the only book published which explains a simple, practical method whereby the concrete worker is enabled, by employing wood and metal templates of different designs, to mold or model in concrete any Cornice, Archivols

CATALOGUE OF GOOD, PRACTICAL BOOKS

Column, Pedestal, Base Cap, Urn or Pier in a monolithic form—right upon the job. These may be molded in units or blocks, and then built up to suit the specifications demanded. This work is fully illustrated, with detailed engravings. Price . \$3.00

POPULAR HANDBOOK FOR CEMENT AND CONCRETE USERS. By Myron H. LEWIS.

This is a concise treatise of the principles and methods employed in the manufacture and use of cement in all classes of modern works. The author has brought together in this work all the salient matter of interest to the user of concrete and its many diversified products. The matter is presented in logical and systematic order, clearly written, fully illustrated and free from involved mathematics. Everything of value to the concrete user is given, including kinds of cement employed in construction, concrete architecture, inspection and testing, waterproofing, coloring and painting, rules, tables, working and cost data. The book comprises thirty-three chapters, as follows:

working and cost data. The book comprises thirty-three chapters, as follows:
Introductory. Kinds of Cements and How They are Made. Properties. Testing and Requirements of Hydraulic Cement. Concrete and its Properties. Sand. Broken Stone and Gravel for Concrete. How to Proportion the Materials. How to Mix and Place Concrete. Forms of Concrete Construction. The Architectural and Artistic Possibilities of Concrete. Concrete Residences. Mortars, Plasters and Stucco and How to Use Them. The artistic Treatment of Concrete Surfaces. Concrete Building Blocks. The Making of Ornamental Concrete. Concrete Pipes, Fences, Posts, etc. Essential Features and Advantages of Reenforced Concrete. How to Design Reenforced Concrete Beams, Slabs and Columns. Explanations of the Methods and Principles in Designing Reenforced Concrete Beams and Slabs. Systems of Reenforcement Employed. Reenforced Concrete Beams and Slabs. Systems of Reenstruction. Concrete in Foundation Work. Concrete Retaining Walls, Abutments and Bulkheads. Concrete Arches and Arch Bridges. Concrete Beam and Girder Bridges. Concrete in Sewerage and Drainage Works. Concrete Tanks, Dams and Reservoirs. Concrete Sidewalks, Curbs and Pavements. Concrete Work. Destructions. The Utility of Concrete on the Farm. The Waterproofing of Concrete Structure. Grout or Liquid Concrete and its Use. Inspection of Concrete Work. Cost of Concrete Work. Some of the special features of the book are: 1. The Attention Paid to the Artistic and Architectural Side of Concrete Work. 2. The Authoritative Treatment of the Problem of Waterproofing Concrete. 3. An Excellent Summary of the Rules to be Followed in Concrete Construction. 4. The Valuable Cost Data and Concrete User. Price

WHAT IS SAID OF THIS BOOK:

- "The field of Concrete Construction is well covered and the matter contained is well within the understanding of any person."—Engineering-Contracting.
- "Should be on the bookshelves of every contractor, engineer and architect in the '-National Builder.

WATERPROOFING CONCRETE. By Myron H. Lewis.

Modern Methods of Waterproofing Concrete and Other Structures. A condensed statement of the Principles, Rules, and Precautions to be Observed in Waterproofing and Dampproofing Structures and Structural Materials. Paper binding. Illustrated.

DICTIONARIES

STANDARD ELECTRICAL DICTIONARY. By T. O'CONOR SLOANE.

An indispensable work to all interested in electrical science. Suitable alike for the student and professional. A practical handbook of reference containing definitions of about 5000 distinct words, terms and phrases. The definitions are terse and concise and include every term used in electrical science. Recently issued. An entirely new edition. Should be in the possession of all who desire to keep abreast with the progress of this branch of science. Complete, concise and convenient. 682 pages. 393 illustrations. Price

DIES-METAL WORK

DIES: THEIR CONSTRUCTION AND USE FOR THE MODERN WORKING OF SHEET METALS. By J. V. Woodworth.

A most useful book, and one which should be in the hands of all engaged in the press working of metals; treating on the Designing, Constructing, and Use of Tools, Fixtures and Devices, together with the manner in which they should be used in the Power Press, for the cheap and rapid production of the great variety of sheet-metal articles now in use. It is designed as a guide to the production of sheet-metal parts at the minimum of cost with the maximum of output. The hardening and tempering of Press tools and the classes of work which may be produced to the best advantage by the use of dies in the power press are fully treated. Its 505 illustrations show dies, press fixtures and sheet-metal working devices, the descriptions of which are so clear and practical that all metal-working mechanics will be able to understand how to design, construct and use them. Many of the dies and press fixtures treated were either constructed by the author or under his supervision. Others were built by skilful mechanics and are in use in large sheet-metal establishments and machine shops. A most useful book, and one which should be in the hands of all engaged in the press

PUNCHES, DIES AND TOOLS FOR MANUFACTURING IN PRESSES. J. V. WOODWORTH. B▼

This work is a companion volume to the author's elementary work entitled "Dies. Their Construction and Use." It does not go into the details of die making to the extent of the author's previous book, but gives a comprehensive review of the field of operations carried on by presses. A large part of the information given has been drawn from the author's personal experience. It might well be termed an Encyclopedia of Die Making, Punch Making, Die Sinking, Sheet Metal Working, and Making of Special Tools, Subpresses, Devices and Mechanical Combinations for Punching, Cutting, Bending, Forming, Plercing, Drawing, Compressing and Assembling Sheet Metal Parts, and also Articles of other Materials in Machine Tools. 2d Edition. Price . . . \$4.00

DROP FORGING, DIE-SINKING AND MACHINE-FORMING OF STEEL. By J. V. WOODWORTH.

J. V. Woodworth.

This is a practical treatise on Modern Shop Practice, Processes, Methods, Machines, Tools, and Details treating on the Hot and Cold Machine-Forming of Steel and Iron into Finished shapes; Together with Tools, Dies, and Machinery involved in the manufacture of Duplicate Forgings and Interchangeable Hot and Cold Pressed Parts from Bar and Sheet Metal. This Book fills a demand of long standing for information regarding drop forgings, die-sinking and machine-forming of steel and the shop practice involved, as it actually exists in the modern drop-forging shop. The processes of die-sinking and force-making, which are thoroughly described and illustrated in this admirable work, are rarely to be found explained in such a clear and concise manner as is here set forth. The process of die-sinking relates to the engraving or sinking of the female or lower dies, such as are used for drop forgings, hot and cold machine forging, swedging and the press working of metals. The process of force-making relates to the engraving or raising of the male or upper dies used in producing the lower dies for the press-forming and machine-forging of duplicate parts of metal.

In addition to the arts above mentioned the book contains explicit information re-

In addition to the arts above mentioned the book contains explicit information regarding the drop forging and hardening plants, designs, conditions, equipment, drop hammers, forging machines, etc., machine forging, hydraulic forging, autogenous welding and shop practice. The book contains eleven chapters, and the information contained in these chapters is just what will prove most valuable to the forged-metal worker. All operations described in the work are thoroughly illustrated by means of perspective half-tones and outline sketches of the machinery employed. 300 detailed illustrations. Price

DRAWING—SKETCHING PAPER

LINEAR PERSECTIVE SELF-TAUGHT. By HERMAN T. C. KRAUS.

This work gives the theory and practice of linear perspective, as used in architectural engineering and mechanical drawings. Persons taking up the study of the subject by themselves will be able, by the use of the instruction given, to readily grasp the subject, and by reasonable practice become good perspective draftenen. The arrangement of the book is good; the plate is on the left-hand, while the descriptive text follows on the opposite page, so as to be readily referred to. The drawings are on sufficiently large scale to show the work clearly and are plainly figured. The whole work makes a very complete course on perspective drawing, and will be found of great value to architects, civil and mechanical engineers, patent attorneys, art designers, engravers, and draftsmen.

PRACTICAL PERSPECTIVE. By Richards and Colvin.

Shows just how to make all kinds of mechanical drawings in the only practical perspective isometric. Makes everything plain so that any mechanic can understand a sketch or drawing in this way. Saves time in the drawing room, and mistakes in the shops. Contains practical examples of various classes of work. 3rd Edition. 50 cents

SELF-TAUGHT MECHANICAL DRAWING AND ELEMENTARY MACHINE DESIGN. By F. I. SYLVESTER, M.E., Draftsman, with additions by Erik Oberg, associate editor of "Machinery."

OBERG, associate editor of "Machinery."

This is a practical treatise on Mechanical Drawing and Machine Design, comprising the first principles of geometric and mechanical drawing, workshop mathematics, mechanics, strength of materials and the calculations and design of machine details. The author's aim has been to adapt this treatise to the requirements of the practical mechanic and young draftsman and to present the matter in as clear and concise a manner as possible. To meet the demands of this class of students, practically all the important elements of machine design have been dealt with, and in addition algebraic formulas have been explained, and the elements of trigonometry treated in the manner best suited to the needs of the practical man. The book is divided into 20 chapters, and in arranging the material, mechanical drawing, pure and simple, has been taken up first, as a thorough understanding of the principles of representing objects facilitates the further study of mechanical subjects. This is followed by the mathematics necessary for the solution of the problems in machine design which are presented later, and a practical introduction to theoretical mechanics and the strength of materials. The various elements entering into machine design, such as cams, gears, sprocket wheels, cone pulleys, bolts, acrews, couplings, clutches, shafting and fly-wheels have been treated in such a way as to make possible the use of the work as a text-book for a continuous course of study. It is easily comprehended and assimilated even by students of limited previous training. 330 pages, 215 engravings. Price . \$2.00

A NEW SKETCHING PAPER.

ELECTRICITY

ARITHMETIC OF ELECTRICITY. By Prof. T. O'CONOR SLOANE.

COMMUTATOR CONSTRUCTION. By Wm. Baxter, Jr.

The business end of any dynamo or motor of the direct current type is the commutator. This book goes into the designing, building, and maintenance of commutators, shows how to locate troubles and how to remedy them; everyone who fusses with dynamos needs this. 4th Edition. 95 cents

DYNAMO BUILDING FOR AMATEURS, OR HOW TO CONSTRUCT A FIFTY-WATT DYNAMO. By ARTHUR J. WEED, Member of N. Y. Electrical Society.

WATT DYNAMO. By ARTHUR J. WEED, Member of N. Y. Electrical society. A practical treatise showing in detail the construction of a small dynamo or motor, the entire machine work of which can be done on a small foot lathe. Dimensioned working drawings are given for each piece of machine work, and each operation is clearly described. This machine, when used as a dynamo, has an output of fifty watts; when used as a motor it will drive a amall drill press or lathe. It can be used to drive a sewing machine on any and all ordinary work. The book is illustrated with more than sixty original engravings showing the actual construction of the different parts. Among the contents are chapters on: 1. Fifty-Watt Dynamo. 2. Side Bearing Rods. 3. Field Punching. 4. Bearings. 5. Commutator. 6. Pulley. 7. Brush Holders. 8. Connection Board. 9. Armature Shaft. 10. Armature. 11. Armature Winding. 12. Field Winding. 13. Connecting and Starting. Price, paper, 50 cents. Cloth

ELECTRIC FURNACES AND THEIR INDUSTRIAL APPLICATION. By J.

...WRIGHT.

This is a book which will prove of interest to many classes of people; the manufacturer who desires to know what product can be manufactured successfully in the electric furnace, the chemist who wishes to post himself on the electro-chemistry, and the student of science who merely looks into the subject from curiosity. The book is not so scientific as to be of use only to the technologist nor so unscientific as to suit only the tyro in electro-chemistry; it is a practical treatise of what has been done, and of what is being done, both experimentally and commercially, with the electric furnace. In important processes not only are the chemical equations given, but complete thermal data are set forth, and both the efficiency of the furnace and the cost of the product are worked out, thus giving the work a solid commercial value aside from its efficacy as a work of reference. The practical features of furnace building are given the space that the subject deserves. The forms are refractory materials used in the linings, the arrangement of the connections to the electrodes, and other important details are explained. 288 pages. New Revised Edition. Fully illustrated. Price . \$8.00

ELECTRIC LIGHTING AND HEATING POCKET-BOOK. By Sydney F. Walker.

. This book puts in convenient form useful information regarding the apparatus which is likely to be attached to the mains of an electrical company. Tables of units and equivlikely to be attached to the mains of an electrical company. Tables of alents are included and useful electrical laws and formulas are stated.

One section is devoted to dynamos, motors, transformers and accessory apparatus One section is devoted to dynamos, motors, transformers and accessory apparatus another to accumulators, another to switchboards and related equipment, a fourth ta description of various systems of distribution, a fifth section to a discussion of instruments both for portable use and switchboards; another section deals with electric lamp of various types and accessory appliances, and the concluding section is given up telectric heating apparatus. In each section a large number of commercial types are described, frequent tables of dimensions being included. A great deal of detail information of each line of apparatus is given, and the illustrations shown give a good idea of the general appearance of the apparatus under discussion. The book also contains much valuable information for the central station engineer.

438 pages. 300 engravings. Bound in leather pocket-book form. Price

ELECTRIC WIRING, DIAGRAMS AND SWITCHBOARDS. By Newton HARRISON.

A thoroughly practical treatise covering the subject of Electric Wiring in all its branches, including explanations and diagrams which are thoroughly explicit and greatly simplify the subject. Practical, every-day problems in wiring are presented and the method of obtaining intelligent results clearly shown. Only arithmetic is used. Ohm's law is given a simple explanation with reference to wiring for direct and alternating currents. The fundamental principle of drop of potential in circuits is shown with its

various applications. The simple circuit is developed with the position of mains, feeders and branches; their treatment as a part of a wiring plan and their employment in house wiring clearly illustrated. Some simple facts about testing are included in connection with the wiring. Molding and conduit work are given careful consideration; and switchboards are systematically treated, built up and illustrated, showing the purpose they serve, for connection with the circuits, and to shunt and compound wound machines. The simple principles of switchboard construction, the development of the switchboard, the connections of the various instruments, including the lightning arrester, are also plainly set forth.

ELECTRIC TOY MAKING, DYNAMO BUILDING, AND ELECTRIC MOTOR CONSTRUCTION. By Prof. T. O'CONOR SLOAME.

This work treats of the making at home of electrical toys, electrical apparatus, motors, dynamos and instruments in general, and is designed to bring within the reach of young and old the manufacture of genuine and useful electrical appliances. The work is especially designed for amateurs and young folks.

Thousands of our young people are daily experimenting, and busily engaged in making electrical toys and apparatus of various kinds. The present work is just what is wanted to give the much needed information in a plain, practical manner, with illustrations to make easy the carrying out of the work. 20th Edition, enlarged. Price \$1.00

PRACTICAL ELECTRICITY. By Prof. T. O'CONOR SLOANE.

This work of 768 pages was previously known as Sloane's Electricians' Hand Book, and is intended for the practical electrician who has to make things go. The entire field of electricity is covered within its pages. Among some of the subjects treated are: The Theory of the Electric Current and Circuit, Electro-Chemistry, Primary Batteries, Storage Batteries, Generation and Utilization of Electric Powers, Alternating Current, Armature Winding, Dynamos and Motors, Motor Generators, Operation of the Central Station Switchboards, Safety Appliances, Distribution of Electric Light and Power, Street Mains, Transformers, Arc and Incandescent Lighting, Electric Measurements, Photometry, Electric Railways, Telephony, Bell-Wiring, Electric-Plating, Electric Heating, Wireless Telegraphy, etc. It contains no useless theory: everything is to the point. It teaches you just what you want to know about electricity. It is the standard work published on the subject. Forty-one chapters, 556 engravings. Price

ELECTRICITY SIMPLIFIED. By Prof. T. O'CONOR SLOANE.

HOUSE WIRING. By THOMAS W. POPPE.

WHAT IS SAID OF THIS BOOK:

"The information given is exact and exhaustive without being too technical or overladen with details."—Druggists' Circular.

HOW TO BECOME A SUCCESSFUL ELECTRICIAN. By Prof. T. O'CONOR SLOANE.

Every young man who wishes to become a successful electrician should read this book. It tells in simple language the surest and easiest way to become a successful electrician. The studies to be followed, methods of work, field of operation and the requirements of the successful electrician are pointed out and fully explained. Every young engineer will find this an excellent stepping stone to more advanced works on electricity which he must master before success can be attained. Many young men become discouraged at the very outstart by attempting to read and study books that are far

MANAGEMENT OF DYNAMOS. By LUMMIS-PATERSON.

A handbook of theory and practice. This work is arranged in three parts. The first part covers the elementary theory of the dynamo. The second part, the construction and action of the different classes of dynamo in common use, are described; while the third part relates to such matters as affect the practical management and working of dynamos and motors. The following chapters are contained in the book: Electrical Units; Magnetic Principle; Theory of the Dynamo; Armature; Armature in Practice; Field Magnets; Field Magnets in Practice; Regulating Dynamos; Coupling Dynamos; Installation, Running, and Maintenance of Dynamos; Faults in Dynamos; Faults in Armatures; Motors. 292 pages. 117 illustrations. Price . . \$1.50

STANDARD ELECTRICAL DICTIONARY. By T. O'CONOR SLOANE.

SWITCHBOARDS. By WILLIAM BAXTER, JR.

TELEPHONE CONSTRUCTION, INSTALLATION, WIRING, OPERA AND MAINTENANCE. By W. H. RADCLIFFE and H. C. CUSHING.

This book is intended for the amateur, the wireman, or the engineer who desires to establish a means of telephonic communication between the rooms of his home, office, or shop. It deals only with such things as may be of use to him rather than with or shop. theories.

Gives the principles of construction and operation of both the Bell and Independent instruments; approved methods of installing and wiring them; the means of protecting them from lightning and abnormal currents; their connection together for operation as series or bridging stations; and rules for their inspection and maintenance. Line wiring and the wiring and operation of special telephone systems are also treated.

WIRELESS TELEGRAPHY AND TELEPHONY SIMPLY EXPLAINED. By ALFRED P. MORGAN.

ALFRED P. MORGAN.

This is undoubtedly one of the most complete and comprehensible treatises on the subject ever published, and a close study of its pages will enable one to master all the details of the wireless transmission of messages. The author has filled a long-felt want and has succeeded in furnishing a lucid, comprehensible explanation in simple language of the theory and practice of wireless telegraphy and telephony.

Among the contents are: Introductory; Wireless Transmission and Reception—The Aerial System, Earth Connections—The Transmitting Apparatus, Spark Colls and Transformers, Condensers, Helixes, Spark Gaps, Anchor Gaps, Aerial Switches—The Receiving Apparatus, Detectors, etc.—Tuning and Coupling, Tuning Colls, Loose Couplers, Variable Condensers, Directive Wave Systems—Miscellaneous Apparatus, Telephone Receivers, Range of Stations, Static Interference—Wireless Telephone, How Sounds Are Changed into Electric Waves—Wireless Telephone, How Sounds Are Changed into Electric Waves—Wireless Telephones, The Apparatus—Summarv.

164 pages. 185 engrav ngs. Price 154 pages. 156 engrav ngs. Price

WHAT IS SAID OF THIS BOOK:

"This book should be in both the home and school library."—The Youths' Instructor:

CATALOGUE OF GOOD, PRACTICAL BOOKS

WIRING A HOUSE. By HERBERT PRATT.

Shows a house already built; tells just how to start about wiring it; where to begin; what wire to use; how to run it according to Insurance Rules; in fact, just the information you need. Directions apply equally to a shop. Fourth edition. . . . 25 cents

FACTORY MANAGEMENT, ETC.

MODERN MACHINE SHOP CONSTRUCTION, EQUIPMENT AND MANAGE-MENT. By O. E. Perrigo, M.E.

The only work published that describes the modern machine shop or manufacturing plant from the time the grass is growing on the site intended for it until the finished product is shipped. By a careful study of its thirty-two chapters the practical man may economically build, efficiently equip, and successfully manage the modern machine shop or manufacturing establishment. Just the book needed by those contemplating the erection of modern shop buildings, the rebuilding and reorganization of old ones, or the introduction of modern shop methods, time and cost systems. It is a book written and illustrated by a practical shop man for practical shop men who are too busy to read theories and want facts. It is the most complete all around book of its kind ever published. It is a practical book for practical men, from the apprentice in the shop to the president in the office. It minutely describes and illustrates the most simple and yet the most efficient time and cost system yet devised. Price : \$5.00

COMBUSTION OF COAL AND THE PREVENTION OF SMOKE. By WM. M.

This book has been prepared with special reference to the generation of heat by the combustion of the common fuels found in the United States, and deals particularly with the conditions necessary to the economic and smokeless combustion of bituminous coals in Stationary and Locomotive Steam Bollers.

SMOKE PREVENTION AND FUEL ECONOMY. By Booth and Kershaw.

A complete treatise for all interested in smoke prevention and combustion, being based on the German work of Ernst Schmatolla, but it is more than a mere translation of the German treatise, much being added. The authors show as briefly as possible the principles of fuel combustion, the methods which have been and are at present in use, as well as the proper scientific methods for obtaining all the energy in the coal and burning it without smoke. Considerable space is also given to the examination of the waste gases, and several of the representative English and American mechanical stoker and similar appliances are described. The losses carried away in the waste gases are thoroughly analyzed and discussed in the Appendix, and abstracts are also here given of various patents on combustion apparatus. The book is complete and contains much of value to all who have charge of large plants. 194 pages. Illustrated. Price

GAS ENGINES AND GAS

THE GASOLINE ENGINE ON THE FARM: ITS OPERATION, REPAIR AND USES. By XENO W. PUTNAM.

This is a practical treatise on the Gasoline and Kerosene Engine intended for the man who wants to know just how to manage his engine and how to apply it to all kinds of farm work to the best advantage.

farm work to the best advantage.

This book abounds with hints and helps for the farm and suggestions for the home and housewife. There is so much of value in this book, that it is impossible to adequately describe it in such small space. Suffice to say that it is the kind of a book every farmer will appreciate and every farm home ought to have. Includes selecting the most suitable engine for farm work, its most convenient and efficient installation, with chapters on troubles, their remedies, and how to avoid them. The care and management of the farm tractor in plowing, harvesting and road grading are fully covered; also plain directions are given for handling the tractor on the road. Special attention is given to relieving farm life of its drudgery by applying power to the disagreeable small tasks which must otherwise be done by hand. Many home-made contrivances for cutting wood, supplying kitchen, garden, and barn with water, loading, hauling and unloading hay, delivering grain to the bins or the feed trough are included; also full directions for making the engine milk the cows, churn, wash, sweep the house and clean the windows, etc. Very fully illustrated with drawings of working parts and cuts showing Stationary. Portable and Tractor Engines doing all kinds of farm work. All money-making farms utilize power. Learn how to utilize power by reading the pages of this book. It is an aid to the result getter, invaluable

WHAT IS SAID OF THIS BOOK:

"Am much pleased with the book and find it to be very complete and up-to-date. I will heartly recommend it to students and farmers whom I think would stand in need of such a work, as I think it is an exceptionally good one."—N. S. Gardiner, Prof. in Charge, Clemson Agr. College of S. C.; Dept. of Agri. and Agri. Exp. Station, Clemson College, S. C.

"I feel that Mr. Putnam's book covers the main points which a farmer should know."

—R. T. Burdick, Instructor in Agronomy, University of Vermont, Burlington, Vt. "It will be a valuable addition to our library upon Farm Machinery."-Farra, Inst. in Agri. Engineering, State University of Ky., Lexington, Ky. -James A.

GASOLINE ENGINES: THEIR OPERATION, USE AND CARE. By A. HYATT VERRILL.

VERRILL.

The simplest, latest and most comprehensive popular work published on Gasoline Engines, describing what the Gasoline Engine is; its construction and operation; how to install it; how to select it; how to use it and how to remedy troubles encountered. Intended for Owners, Operators and Users of Gasoline Motors of all kinds. This work fully describes and illustrates the various types of Gasoline Engines used in Motor Boats, Motor Vehicles and Stationary Work. The parts, accessories and appliances are described, with chapters on ignition, fuel, lubrication, operation and engine troubles. Special attention is given to the care, operation and repair of motors, with useful hints and suggestions on emergency repairs and makeshifts. A complete glossary of technical terms and an alphabetically arranged table of troubles and their symptoms form most valuable and unique features of this manual. Nearly every illustration in the book is original, having been made by the author. Every page is full of interest and value. A book which you cannot afford to be without. 275 pages. 152 specially made engravings. (See page 16 for full description.) Price . \$1.50

GAS, GASOLINE AND OIL ENGINES. By GARDNER D. HISCOX. Revised By Victor W. Pagé.

By Victor W. Pagé.

Just issued, 1915 revised and enlarged edition. Every user of a gas engine needs this book. Simple, instructive and right up to date. The only complete work on the subject. Tells all about internal combustion engineering, treating exhaustively on the design, construction and practical application of all forms of gas, gasoline, kerosene, and crude petroleum-oil engines. Describes minutely all auxiliary systems, such as lubrication, carburetion and ignition. Considers the theory and management of all forms of explosive motors for stationary and marine work, automobiles, aeroplanes and motor-cycles. Includes also Producer Gas and Its Production. Invaluable instructions for all students, gas-engine owners, gas-engineers, patent experts, designers, mechanics, draftsmen, and all having to do with the modern power. Illustrated by over 400 engravings, many specially made from engineering drawings, all in correct proportion. 650 pages, 435 engravings. Price.

GAS ENGINE CONSTRUCTION, OR HOW TO BUILD A HALF-HORSE-POWER GAS ENGINE. By Parsell and Weed.

A practical treatise of 300 pages describing the theory and principles of the action of Gas Engines of various types and the design and construction of a half-horse power Gas Engine, with illustrations of the work in actual progress, together with the dimensioned working drawings, giving clearly the sizes of the various details; for the student, the scientific investigator, and the amateur mechanic. This book treats of the subject more from the standpoint of practice than that of theory. The principles of operation of Gas Engines are clearly and simply described, and then the actual construction of a half-horse power engine is taken up, step by step, showing in detail the making of the Gas Engine. 3d Edition. 300 pages. Price

MODERN GAS ENGINES AND PRODUCER GAS PLANTS. By R. E. MATHOT.

A guide for the gas engine designer, user, and engineer in the construction, selection, purchase, installation, operation, and maintenance of gas engines. More than one book on gas engines has been written, but not one has thus far even encroached on the field covered by this book. Above all Mr. Mathot's work is a practical guide. Recognizing the need of a volume that would assist the gas engine user in understanding thoroughly the motor upon which he depends for power, the author has discussed his subject without the help of any mathematics and without elaborate theoretical explanations. Every part of the gas engine is described in detail, tersely, clearly, with a thorough understanding of the requirements of the mechanic. Helpful suggestions as to the purchase of an engine, its installation, care, and operation, form a most valuable feature of the work. 320 pages. 175 detailed illustrations. Price . \$2.50

THE MODERN GAS TRACTOR. By Victor W. Page.

A complete treatise describing all types and sizes of gasoline kerosene and oil tractors. Considers design and construction exhaustively, gives complete instructions for care, operation and repair, outlines all practical applications on the road and in the field. The best and latest work on farm tractors and tractor power plants. A work needed by farmers, students, blacksmiths, mechanics, salesmen, implement dealers, designers and engineers. 500 pages. Nearly 300 illustrations and folding plates. Price \$2.00



GASOLINE ENGINES

Their Operation, Use and Care.

By A. HYATT VERRILL,

The Simplest, Latest and Most Comprehensive Popular work published on Gasoline Engines

275 (5 x 7) PAGES.

152 ILLUSTRATIONS.

PRICE. \$1.50

This book describes what the Gasoline Engine is; its construction and operation; how to install it; how to select it; how to use it and how to remedy troubles encountered. Intended for Owners, Operator and Users of Gasoline Motors of all kinds.

A complete glossary of technical terms and an alphabetically arranged table of troubles and their symptoms form most valuable and unique features of this manual. Nearly every illustration in the book is original, having been made by the author. Every page is full of interest and value. A book which you cannot afford to be without.

CONTAINS SPECIAL CHAPTERS ON

Types of Motors—Operation of Two-cycle Motor—Operation of Four-cycle Motor—Various Designs, Makes and Forms of Two-cycle Motors—Three-port Motors—Combination and Four-port Motors—Open-base and Distributor-valve Motors—Multiple-cyclinder Two-cycle Motors—Various Forms, Designs, and Variations of Four-cycle Motors—Valves and their Operation—Valve Mechanisms and Motions—Automatic and Mechanically operated Valves—Sleeve-valve and Rotary-valve Motors—Opposed-cylinder and Offset-crank Motors, Freak Motors, and Horizontal Motors—Parts of Two-cycle Motors—Parts of Four-cycle Motors—Design and Construction of Motor Parts—Cylinders, Pistons, Crank-cases, Rings, Pins, Jackets, Shafts, Connecting-rods, Rearings, Cams and Gears—Cooling Methods—Water and Air-cooled Systems—Motor Accessories—Vaporizers and Carburetors—Pumps, Fans and Water Circulation—Lubrication—Gravity and Force-feed Oiler, Grease Cups and Oiling Methods—Principles of Electrical Ignition—Dynamos and Magnetos—High and Low-tension Magnetos—The Wico Igniters—Operation of Igniters—Operation of Igniters—The Delco System—Make-and-break Ignition—igniters—Operation of Igniters—Comparsion of Make-and-break and Jump Spark—Altering Make-and-break to Jump Spark—Mufflers and Exhaust Devices—Governors—Puel and Fuel Consumption—Oils and Greases—Installation—Piping and Wiring—Gaskets and Rackings—Adjustments—General Care of Motors—Table of Motor Troubles with Causes and Remedies—Tools—Emergency Repairs and Makeshifts—Grinding Compounds, Polishes, Enamels, Paints, etc—Carbon Removers and Cleansers—Belts and Belt Dressings—Anti-freezing Mixtures—Glossary of Alphabetically Arranged Technical Terms with Explanations—Heat Values of, Fuels—Size and Capacity of Tanks—Iron Pipe Table—U. S. Standard Screw Threads—Cap-Screw Sizes—Drills for Screw Holes—Surface and Volume Tables.

JUST PUBLISHED

MOTORCYCLES, SIDE CARS and CYCLECARS

Their Construction, Management and Repair

By VICTOR W. PAGÉ,

Author of "The Modern Gasoline Automobile," Etc., Etc.

Contains over 350 illustrations showing the most valuable series of drawings pertaining to motorcycle design and construction ever published.

550 PAGES

PRICE \$1.50

The material contained within the pages of this book is of a practical nature that can easily be assimilated and understood by anyone. The instructions given for control, maintenance and repair will be valuable for the novice rider, while the discussions of mechanical principles will undoubtedly appeal to the more experienced riders, dealers and others in the trade.

GEARING AND CAMS

BEVEL GEAR TABLES. By D. Ag. ENGSTROM.

CHANGE GEAR DEVICES. By OSCAR E. PERRIGO.

A practical book for every designer, draftsman, and mechanic interested in the invention and development of the devices for feed changes on the different machines requiring such mechanism. All the necessary information on this subject is taken up, analyzed, classified, sifted, and concentrated for the use of busy men who have not the time to go through the masses of irrelevant matter with which such a subject is usually encumbered and select such information as will be useful to them.

DRAFTING OF CAMS. By Louis Rouillion.

HYDRAULICS

HYDRAULIC ENGINEERING. By GARDNER D. HISCOX.

A treatise on the properties, power, and resources of water for all purposes. Including the measurement of streams, the flow of water in pipes or conduits, the horse-power of falling water, turbine and impact water-wheels, wave motors, centrifugal, reciprocating, and air-lift pumps. With 300 figures and diagrams and 36 practical tables. All who are interested in water-works development will find this book a useful one, because it is an entirely practical treatise upon a subject of present importance, and cannot fail in having a far-reaching influence, and for this reason should have a place in the working library of every engineer. Among the subjects treated are: Historical Hydraulics, Properties of Water, Measurement of the Flow of Streams; Flow from Sub-surface Orifices and Nozzles; Flow of Water in Pipes; Siphons of Various Kinds; Dams and Great Storage Reservoirs; City and Town Water Supply; Wells and Their Reinforcement; Air Lift Methods of Raising Water; Artesian Wells; Irrigation of Arid Districts; Water Power; Water Wheels; Pumps and Pumping Machinery; Reciprocating Pumps; Hydraulic Power Transmission; Hydraulic Mining; Oanals; Ditches; Conduits and Pipe Lines; Marine Hydraulics; Tidal and Sea Wave Power, etc. 320 pages. Price

ICE AND REFRIGERATION

POCKET-BOOK OF REFRIGERATION AND ICE MAKING. By A. J. WALLIS-

INVENTIONS—PATENTS

INVENTORS' MANUAL, HOW TO MAKE A PATENT PAY.

This is a book designed as a guide to inventors in perfecting their inventions, taking cut their patents and disposing of them. It is not in any sense a Patent Solictor's Circular nor a Patent Broker's Advertisement. No advertisements of any description appear in the work. It is a book containing a quarter of a century's experience of a successful inventor, together with notes based upon the experience of many other inventors.

Among the subjects treated in this work are: How to Invent. How to Secure a Good Patent. Value of Good Invention. How to Exhibit an Invention. How to Interest Capital. How to Estimate the Value of a Patent. Value of Design Patents. Value of Foreign Patents, Value of Small Inventions. Advice on Selling Patents. Advice on the Formation of Stock Companies. Advice on the Formation of Limited Liability Companies. Advice on Disposing of Old Patents. Advice as to Patent Attorneys. Advice as to Selling Agents. Forms of Assignments. License and Contracts. State Laws Concerning Patent Rights. 1900 Census of the United States by Counts of Over 10,000 Population. Revised edition. 120 pages. Price. \$1.00

KNOTS

KNOTS, SPLICES AND ROPE WORK. By A. HYATT VERRILL.

IS, SPLICES AND ROPE WORK. By A. HYATT VERRILL.

This is a practical book giving complete and simple directions for making all the most useful and ornamental knots in common use, with chapters on Splicing, Pointing, Seizing, Serving, etc. This book is fully illustrated with one hundred and fifty original engravings, which show how each knot, the or splice is formed, and its appearance when finished. The book will be found of the greatest value to Campers, Yachtsmen, Travelers, Boy Scouts, in fact, to anyone having occasion to use or handle rope or knots for any purpose. The book is thoroughly reliable and practical, and is not only a guide but a teacher. It is the standard work on the subject. Among the contents are: 1. Cordage, Kinds of Rope. Construction of Rope, Parts of Rope Cable and Bott Rope. Strength of Rope, Weight of Rope. 2. Simple Knots and Bends. Terms Used in Handling Rope. Seizing Rope. 3. Ties and Hitches. 4. Noose, Loops and Mooring Knots. 5. Shortenings, Grommers and Salvages. 6. Lashings, Seizings and Splices. 7. Fancy Knots and Rope Work. 128 pages. 150 original engravings. Price

LATHE WORK

LATHE DESIGN, CONSTRUCTION AND OPERATION, WITH PRACTICAL EXAMPLES OF LATHE WORK. By Oscar E. Perrigo.

RACTICAL METAL TURNING. By Joseph G. Horner.

This important and practical subject is treated in a full and exhaustive manner, and nothing of importance is omitted. The principles and practice and all the different branches of Turning are considered and well illustrated. All the different kinds of Chucks of usual forms, as well as some unusual kinds, are shown. A feature of the book is the important section devoted to modern Turret practice; Boring is another subject which is treated fully; and the chapter on Tool Holders illustrates a large number of representative types. Thread Cutting is treated at reasonable length; and the last chapter contains a good deal of information relating to the High-Speed Steels and their work. The numerous tools used by machinists are illustrated, and also the adjuncts of the lathe. In fact, the entire subject is treated in such a thorough manner as to make this book the standard one on the subject. It is indispensable to the manager, engineer, and machinist as well as to the student, amateur, and experimental man who desires to keep up-to-date. 400 pages, fully illustrated.

lURNING AND BORING TAPERS. By FRED H. COLVIN.

LIQUID AIR

LIQUID AIR AND THE LIQUEFACTION OF GASES. By T. O'CONOR SLOANE.

This book gives the history of the theory, discovery, and manufacture of Liquid Air, and contains an illustrated description of all the experiments that have excited the wonder of audiences all over the country. It shows how liquid air, like water, is carried hundreds of miles and is handled in open buckets. It tells what may be expected from it in the near future.

A book that renders simple one of the most perplexing chemical problems of the century. Startling developments illustrated by actual experiments.

It is not only a work of scientific interest and authority, but is intended for the general reader, being written in a popular style—easily understood by every one. Second edition. 365 pages. Price \$2.00

LOCOMOTIVE ENGINEERING

AIR-BRAKE CATECHISM. By Robert H. Blackall.

This book is a standard text book. It covers the Westinghouse Air-Brake Equipment, including the No. 5 and the No. 6 E. T. Locomotive Brake Equipment: the K (Quick-Service) Triple Valve for Freight Service; and the Cross-Compound Pump. The operation of all parts of the apparatus is explained in detail, and a practical way of finding their peculiarities and defects, with a proper remedy, is given. It contains 2,000 questions with their answers, which will enable any railroad man to pass any examination on the subject of Air Brakes. Endorsed and used by air-brake instructors and examiners on nearly every railroad in the United States. 25th Edition. 350 pages, fully illustrated with colored plates and diagrams. \$2.00

AMERICAN COMPOUND LOCOMOTIVES. By Fred. H. Colvin.

The only book on compounds for the engineman or shopman that shows in a plain, practical way the various features of compound locomotives in use. Shows how they are made, what to do when they break down or balk. Contains sections as follows:—A Bit of History. Theory of Compounding Steam Cylinders. Baldwin Two-Cylinder Compound. Pittsburg Two-Cylinder Compound. Rhode Island Compound. Richmond Compound, Rogers Compound. Schenectady Two-Cylinder Compound, Vauciain Compound. Tandem Compounds. Baldwin Tandem. The Colvin-Wightman Tandem. Schenectady Tandem. Balanced Locomotives. Baldwin Balanced. Compound. Plans for Balancing. Locating Blows. Break-downs. Reducing Valves. Drifting. Valve Motion. Disconnecting. Power of Compound Locomotives. Practical Notes.

APPLICATION OF HIGHLY SUPERHEATED STEAM TO LOCOMOTIVES. By ROBERT GARBE.

By ROBERT GARBE.

A practical book which cannot be recommended too highly to those motive-power men who are anxious to maintain the highest efficiency in their locomotives. Contains special chapters on Generation of Highly Superheated Steam; Superheated Steam and the Two-Cylinder Simple Engine; Compounding and Superheating; Designs of Locomotive Superheaters; Constructive Details of Locomotives using Highly Superheated Steam. Experimental and Working Results. Illustrated with folding plates and tables. Price \$2.50

COMBUSTION OF COAL AND THE PREVENTION OF SMOKE. By WM. M. BARR.

This book has been prepared with special reference to the generation of heat by the combustion of the common fuels found in the United States, and deals particularly with the conditions necessary to the economic and smokeless combustion of bituminous coal in Stationary and Locomotive Steam Boilers.

DIARY OF A ROUND-HOUSE FOREMAN. By T. S. REILLY.

LINK MOTIONS, VALVES AND VALVE SETTING. By Fred H. Colvin, Associate Editor of American Machinist.

A handy book for the engineer or machinist that clears up the mysteries of valve setting. Shows the different valve gears in use, how they work, and why. Piston and slide valves of different types are illustrated and explained. A book that every railroad man in the motive power department ought to have. Contains chapters on Locomotive Link Motion. Valve Movements, Setting Slide Valves, Analysis by Diagrams, Modern Practice, Slip of Block, Slide Valves, Piston Valves, Setting Piston Valves, Joy-Allen Valve Gear, Walschaert Valve Gear, Gooch Valve Gear, Alfree-Hubbell Valve Gear, etc., etc. Fully illustrated. Price

LOCOMOTIVE BOILER CONSTRUCTION. By Frank A. Kleinhans.

The construction of boilers in general is treated, and, following this, the locomotive boiler is taken up in the order in which its various parts go through the shop. Shows all types of boilers used: gives details of construction; practical facts, such as life of riveting, punches and dies; work done per day, allowance for bending and flanging sheets, and other data. Including the recent Locomotive Boiler Inspection Laws and Examination Questions with their answers for Government Inspectors. Contains chapters on Laying Out Work: Flanging and Forging; Punching: Shearing: Plate Planing: General Tables; Finishing Parts; Bending; Machinery Parts: Riveting; Boiler Details; Smoko Box Details; Assembling and Calking; Boiler Shop Machinery, etc., etc.

LOCOMOTIVE BREAKDOWNS AND THEIR REMEDIES. By Geo. L. FOWLER. Revised by Wm. W. Wood, Airbrake Instructor. Just issued. Revised pocket edition.

It is out of the question to try and tell you about every subject that is covered in this pocket edition of Locomotive Breakdowns. Just imagine all the common troubles that an engineer may expect to happen some time, and then add all of the unexpected ones, troubles that could occur, but that you had never thought about, and you will find that they are all treated with the very best methods of repair. Walschaert Locomotive Valve Gear Troubles, Electric Headlight Troubles, as well as Questions and Answers on the Troubles, Electric Headlight Troubles, The Revised Edition. Fully illustrated

LOCOMOTIVE CATECHISM. By Robert Grimshaw.

The revised edition of "Locomotive Catechism," by Robert Grimshaw, is a New Book from Cover to Cover. It contains twice as many pages and double the number of illustrations of previous editions. Includes the greatest amount of practical information ever published on the construction and management of modern locomotives. Specially Prepared Chapters on the Walschaert Locomotive Valve Gear, the Air-Brake Equipment and the Electric Head Light are given.

It commends itself at once to every Engineer and Fireman, and to all who are going in for examination or promotion. In plain language, with full, complete answers, not only all the questions asked by the examining engineer are given, but those which the young and less experienced would ask the veteran, and which old hands ask as "stickers." It is a veritable Encyclopedia of the Locomotive, is entirely free from mathematics, easily understood and thoroughly up-to-date. Contains over 4.000 Examination Questions with their Answers. 825 pages, 437 illustrations and three folding plates.

PRACTICAL INSTRUCTOR AND REFERENCE BOOK FOR LOCOMOTIVE FIREMEN AND ENGINEERS. By Chas. F. LOCKHART.

PREVENTION OF RAILROAD ACCIDENTS, OR SAFETY IN RAILROADING. By George Bradshaw.

This book is a heart-to-heart talk with Railroad Employees, dealing with facts, not theories, and showing the men in the ranks, from every-day experience, how accidents occur and how they may be avoided. The book is illustrated with seventy original photographs and drawings showing the safe and unsafe methods of work. No visionary schemes, no ideal pictures. Just plain facts and Practical Suggestions are given. Every railroad employee who reads the book is a better and safer man to have in railroad service. It gives just the information which will be the means of preventing many injuries and deaths. All railroad employees should procure a copy; read it, and do your part in preventing accidents. 169 pages. Pocket size. Fully illustrated. . 50 cents

TRAIN RULE EXAMINATIONS MADE EASY. By G. E. Collingwood.

N RULE EXAMINATIONS MADE EASY. By G. E. Collingwood. This is the only practical work on train rules in print. Every detail is covered, and puzzling points are explained in simple, comprehensive language, making it a practical treatise for the Train Dispatcher, Engineman, Trainman, and all others who have to do with the movements of trains. Contains complete and reliable information of the Standard Code of Train Rules for single track. Shows Signals in Colors, as used on the different roads. Explains fully the practical application of train orders, giving a clear and definite understanding of all orders which may be used. The meaning and necessity for certain rules are explained in such a manner that the student may know beyond a doubt the rights conferred under any orders he may receive or the action required by certain rules. As nearly all roads require trainmen to pass regular examinations, a complete set of examination questions, with their answers, are included. These will enable the student to pass the required examinations with credit to himself and the road for which he works. 256 pages. Fully illustrated with Train Signals in Colors. Price

THE WALSCHAERT AND OTHER MODERN RADIAL VALVE GEARS FOR LOCOMOTIVES. By Wm. W. Wood.

If you would thoroughly understand the Walschaert Valve Gear you should possess a copy of this book, as the author takes the plainest form of a steam engine—a stationary

CATALOGUE OF GOOD, PRACTICAL BOOKS

engine in the rough, that will only turn its crank in one direction—and from it builds up—with the reader's help—a modern locomotive equipped with the Walschaert Valve Gear, complete. The points discussed are clearly illustrated; two large folding plates that show the positions of the valves of both inside or outside admission type, as well as the links and other parts of the gear when the crank is at nine different points in its revolution, are especially valuable in making the movement clear. These employ sliding cardboard models which are contained in a pocket in the cover.

The book is divided into five general divisions, as follows: 1. Analysis of the gear.

2. Designing and erecting the gear. 3. Advantages of the gear. 4. Questions and answers relating to the Walschaert Valve Gear. 5. Setting valves with the Walschaert Valve Gear; the three primary types of Jocomotives valve motion; modern radial valve gears other than the Walschaert; the Hobart All-free Valve and Valve Gear, with questions and answers on breakdowns; the Baker-Pilliod Valve Gear: the Improved Baker-Pilliod Valve Gear, with questions and answers on breakdowns.

WESTINGHOUSE E-T AIR-BRAKE INSTRUCTION POCKET BOOK. By Wm. W. Wood, Air-Brake Instructor.

WM. W. WOOD, AIT-DIRKE INSTRUCTOR.

Here is a book for the railroad man, and the man who aims to be one. It is without doubt the only complete work published on the Westinghouse E-T Locomotive Brake Equipment. Written by an Air Brake Instructor who knows just what is needed. It covers the subject thoroughly. Everything about the New Westinghouse Engine and Tender Brake Equipment, including the Standard No. 5 and the Perfected No. 6 style of brake, is treated in detail. Written in plain English and profusely illustrated with Colored Plates, which enable one to trace the flow of pressures throughout the entire equipment. The best book ever published on the Air Brake. Equally good for the beginner and the advanced engineer. Will pass any one through any examination. It informs and enlightens you on every point. Indispensable to every engineman and trainman.

MACHINE-SHOP PRACTICE

AMERICAN TOOL MAKING AND INTERCHANGEABLE MANUFACTURING. By J. V. Woodworth.

HENLEY'S ENCYCLOPEDIA OF PRACTICAL ENGINEERING AND ALLIED TRADES. Edited by Joseph G. Horner, A.M.I., M.E.

TRADES. Edited by Joseph G. Horner, A.M.I., M.E.

This set of five volumes contains about 2.500 pages with thousands of illustrations, including diagrammatic and sectional drawings with full explanatory details. This work covers the entire practice of Civil and Mechanical Engineering. The best known experts in all branches of engineering have contributed to these volumes. The Cyclopedia is admirably well adapted to the needs of the beginner and the self-taught practical man, as well as the mechanical engineer, designer, draftsman, shop superintendent, foreman, and machinist. The work will be found a means of advancement to any progressive man. It is encyclopedic in scope, thorough and practical in its treatment on technical subjects, simple and clear in its descriptive matter, and without unnecessary technicalities or formulæ. The articles are as order as may be and yet give a reasonably clear and explicit statement of the subject, and are written by men who have had ample practical experience in the matters of which they write. It tells you all you want to know about engineering and tells it so simply, so clearly, so concisely, that one cannot help but understand. As a work of reference it is without a peer. \$6.00 per volume. For complete set of five volumes, price . . \$25.00

WHAT IS SAID OF THIS SET OF BOOKS:

[&]quot;This new Encyclopedia is a commendable work."—Engineering News.

[&]quot;This work is a great help to men engaged in mechanical occupations and those persons having need of a ready reference work."—Southern Machinery.

THE WHOLE FIELD OF MECHANICAL MOVEMENTS COVERED BY MR. HISCOX'S TWO BOOKS

We publish two books by Gardner D. Hiscox that will keep you from "inventing" things that have been done before, and suggest ways of doing things that you have not thought of before. Many a man spends time and money, pondering over some mechanical problem, only to learn, after he has solved the problem, that the same thing has been accomplished and put in practice by others long before. Time and money spent in an effort to accomplish what has already been accomplished are time and money LOST. The whole field of mechanics, every known mechanical movement, and practically every device is covered by these two books. If the thing you want has been invented, it is illustrated in them. If it hasn't been invented, then you'll find in them the nearest things to what you want, some movements or devices that will apply in your case, perhaps; or which will give you a key from which to work. No book or set of books ever published is of more real value to the Inventor, Draftsman, or practical Mechanic than the two volumes described below.

MECHANICAL MOVEMENTS, POWERS, AND DEVICES. By GARDNER D. Hiscox.

This is a collection of 1,890 engravings of different mechanical motions and appliances, accompanied by appropriate text, making it a book of great value to the inventor, the draftsman, and to all readers with mechanical tastes. The book is divided into eighteen sections or chapters, in which the subject-matter is classified under the following heads: Mechanical Powers; Transmission of Power, Measurement of Power, Steam Power, Air Power Appliances; Electric Power and Construction; Navigation and Roads; Gearing; Motion and Devices; Controlling Motion; Horological; Mining; Mill and Factory Appliances; Construction and Devices; Drafting Devices; Miscellaneous Devices, etc. 12th edition. 400 octavo pages. Price . \$2.50

MECHANICAL APPLIANCES, MECHANICAL MOVEMENTS AND NOVELTIES OF CONSTRUCTION. By GARDNER D. HISCOX.

This is a supplementary volume to the one upon mechanical movements. Unlike the first volume, which is more elementary in character, this volume contains illustrations and descriptions of many combinations of motions and of mechanical devices and appliances found in different lines of machinery, each device being shown by a line drawing with a description showing its working parts and the method of operation. From the multitude of devices described and illustrated might be mentioned, in passing, such items as conveyors and elevators. Prony brakes, thermometers, various types of boilers, solar engines, oil-fuel burners, condensers, evaporators. Corliss and other valve gears, governors, gas engines, water motors of various descriptions, air ships, motors and dynamos, automobile and motor bicycles, railway lock signals, car couplers, link and gear motions, ball bearings, breech block mechanism for heavy guns, and a large accumulation of others of equal importance. 1,000 specially made engravings, 396 octavo pages. 3rd revised edition. Price engravings. 396 octavo pages. 3rd revised edition. Price

MACHINE-SHOP ARITHMETIC. By COLVIN-CHENEY.

This is an arithmetic of the things you have to do with daily. It tells you plainly about: how to find areas in figures; how to find surface or volume of balls or spheres; handy ways for calculating; about compound gearing; cutting screw threads on any lathe; drilling for taps; speeds of drills; taps, emery wheels, grindstones, milling cutters, etc.; all about the Metric system with conversion tables; properties of metals; strength of bolts and nuts; decimal equivalent of an inch. All sorts of machine-shop figuring and 1.001 other things, any one of which ought to be worth more than the price of this book to you, and it saves you the trouble of bothering the boss. 6th edition. 131 pages. Price

MODERN MACHINE-SHOP CONSTRUCTION, EQUIPMENT AND MANAGE-MENT. By OSCAR E. PERRIGO.

The only work published that describes the Modern Shop or Manufaccuring Plant from the time the grass is growing on the site intended for it until the finished product is shipped. Just the book needed by those contemplating the erection of modern shop buildings, the rebuilding and reorganization of old ones, or the introduction of Modern Shop Methods, time and cost systems. It is a book written and illustrated by a practical shop man for practical shop men who are too busy to read theories and want facts. It is the most complete all-round book of its kind ever published. 400 large quarto pages. 225 original and specially-made illustrations. Price . \$5.00

MACHINE-SHOP TOOLS AND SHOP PRACTICE. By W. H. VANDERVOORT.

THE MODERN MACHINIST. By JOHN T. USHER.

This is a book showing, by plain description and by profuse engravings made expressly for the work, all that is best, most advanced, and of the highest efficiency in modern

machine-shop practice, tools, and implements, showing the way by which and through which, as Mr. Maxim says. "American machinists have become and are the finest mechanics in the world." Indicating as it does, in every line, the familiarty of the author with every detail of daily experience in the shop it cannot fail to be of service to any man practically connected with the shaping or finishing of metals.

MODERN MILLING MACHINES: THEIR DESIGN, CONSTRUCTION AND OPERATION. By JOSEPH G. HORNER.

This book describes and illustrates the Milling Machine and its work in such a plain, clear, and forceful manner, and illustrates the subject so clearly and completely that the up-to-date machinist, student, or mechanical engineer cannot afford to do without the valuable information which it contains. It describes not only the early machines of this class, but notes their gradual development into the splendid machines of the present day, giving the design and construction of the various types, forms, and special features produced by prominent manufacturers. American and foreign. Milling cutters in all their development and modernized forms are illustrated and described, and the operations they are capable of producing upon different classes of work are carefully described in detail, and the speeds and feeds necessary are discussed, and valuable and useful data given for determining these usually perplexing problems. The book is the most comprehensive work published on the subject. 304 pages. 300 illustrations. Price

"SHOP KINKS." By Robert Grimshaw.

A book of 400 pages and 222 illustrations, being entirely different from any other book on machine-shop practice. Departing from conventional style, the author avoids universal or common shop usage and limits his work to showing special ways of doing things better, more cheaply and more rapidly than usual. As a result the advanced methods of representative establishments of the world are placed at the disposal of the reader. This book shows the proprietor where large savings are possible, and how products may be improved. To the employee it holds out suggestions that, properly applied, will hasten his advancement. No shop can afford to be without it. It bristles with valuable wrinkles and helpful suggestions. It will benefit all, from apprentice to proprietor. Every machinist, at any age, should study its pages. Fifth edition. Price

THREADS AND THREAD CUTTING. By Colvin and Stabel.

TOOLS FOR MACHINISTS AND WOOD WORKERS, INCLUDING INSTRU-MENTS OF MEASUREMENT. By Joseph G. Horner.

The principles upon which cutting tools for wood, metal, and other substances are made are identical, whether used by the machinist, the carpenter, or by any other skilled mechanic in; their daily work, and the object of this book is to give a correct and practical description of these tools as they are commonly designed, constructed; and used. 340 pages, fully illustrated. Price \$3.50

MANUAL TRAINING

ECONOMICS OF MANUAL TRAINING. By Louis Rouillion.

MARINE ENGINEERING

MARINE ENGINES AND BOILERS, THEIR DESIGN AND CONSTRUCTION. By Dr. G. Bauer, Leslie S. Robertson, and S. Bryan Donkin.

By DR. G. BAUER, LESLIE S. KOBERTSON, and S. BRYAN DONKIN.

In the words of Dr. Bauer, the present work owes its origin to an oft felt want of a Condensed Treatise embodying the Theoretical and Practical Rules used in Designing Marine Engines and boilers. The need of such a work has been felt by most engineers engaged in the construction and working of Marine Engines, not only by the younger men, but also by those of greater experience. The fact that the original German work was written by the chief engineer of the famous Vulcan Works, Stettin, is in itself a guarantee that this book is in all respects thoroughly up-to-date, and that it embodies all the information which is necessary for the design and construction of the highest types of marine engines and boilers. It may be said that the motive power which Dr. Bauer has placed in the fast German liners that have been turned out of late years from the Stettin Works represent the very best practice in marine engineering of the present day.

MODERN SUBMARINE CHART.

ERN SUBMARINE CHARI.

A cross-section view, showing clearly and distinctly all the interior of a Submarine of the latest type. You get more information from this chart about the construction and operation of a submarine than in any other way. No details omitted—everything is accurate and to scale. It is absolutely correct in every detail, having been approved by naval engineers. All the machinery and devices fitted in a modern Submarine Boat are shown, and to make the engraving more readily understood all the features are shown in operative form, with Officers and Men in the act of performing the duties assigned to them in service conditions. THIS CHART IS REALLY AN ENCYCLOPEDIA OF A SUBMARINE. It is educational and worth many times its cost. Mailed in a tube for

MINING

ORE DEPOSITS, WITH A CHAPTER ON HINTS TO PROSPECTORS. By J. P. Johnson.

This book gives a condensed account of the ore deposits at present known in South Africa. It is also intended as a guide to the prospector. Only an elementary knowledge of geology and some mining experience are necessary in order to understand this work. With these qualifications, it will materially assist one in his search for metalliferous mineral occurrences and, so far as simple ores are concerned, should enable one to form some idea of the possibilities of any he may find.

Among the chapters given are: Titaniferous and Chromiferous Iron Oxides—Nickel—Copper—Cobalt—Tin—Molybdenum—Tungsten—Lead—Mercury—Antimony—Iron—Hints to Prospectors. \$2.00

PRACTICAL COAL MINING. By T. H. COCKIN.

An important work, containing 428 pages and 213 illustrations, complete with practical details, which will intuitively impart to the reader not only a general knowledge of the principles of coal mining, but also considerable insight into allied subjects. The treatise is positively up to date in every instance, and should be in the hands of every colliery engineer, geologist, mine operator, superintendent, foreman, and all others who are interested in or connected with the industry. 2nd Edition. \$3.50

PATTERN MAKING

PRACTICAL PATTERN MAKING. By F. W. BARROWS.

This book, now in its second edition, is a comprehensive and entirely practical treatise on the subject of pattern making, illustrating pattern work in both wood and metal, and with definite instructions on the use of plaster of paris in the trade. It gives specific and detailed descriptions of the materials used by pattern makers and describes the tools; both those for the bench and the more interesting machine tools; having complete chapters on the Lathe, the Circular Saw and the Band Saw. It gives many examples of pattern work, each one fully illustrated and explained with much detail. These examples, in their great variety, offer much that will be found of interest to all pattern makers, and especially to the younger ones, who are seeking information on the more advanced branches of their trade.

In this second edition of the work will be found much that is new, even to those who have long practised this exacting trade. In the description of patterns as adapted to the Moulding Machine many difficulties which have long prevented the rapid and economical production of castings are overcome; and this great, new branch of the trade is given much space. Stripping plate and stool plate work and the less expensive vibrator, or rapping plate work, are all explained in detail.

Plain, everyday rules for lessening the cost of patterns, with a complete system of cost keeping, a detailed method of marking, applicable to all branches of the trade, with complete information showing what the pattern is, its specific title, its cost, date of production, material of which it is made, the number of pieces and coreboxes, and its location in the pattern safe, all condensed into a most complete card record, with cross index.

The book closes with an original and practical method for the inventory and valua-tion of patterns. Containing nearly 350 pages and 170 illustrations. Price . \$3.00

PERFUMERY

PERFUMES AND THEIR PREPARATION. By G. W. Askinson, Perfumer.

PLUMBING

MECHANICAL DRAWING FOR PLUMBERS. By R. M. STARBUCK.

A concise, comprehensive and practical treatise on the subject of mechanical drawing in its various modern applications to the work of all who are in any way connected with the plumbing trade. Nothing will so help the plumber in estimating and in explaining work to customers and workmen as a knowledge of drawing, and to the workman it is of inestimable value if he is to rise above his position to positions of greater responsibility. Among the chapters contained are: 1. Value to plumber of knowledge of drawing; tools required and their use; common views needed in mechanical drawing. 2. Perspective versus mechanical drawing in showing plumbing construction. 3. Correct and incorrect methods in plumbing drawing; plan and elevation explained. 4. Floor and cellar plans and elevation; scale drawings; use of triangles. 5. Use of triangles; drawing of fittings, traps, etc. 6. Drawing plumbing elevations and fittings. 7. Instructions in drawing plumbing elevations. 8. The drawing of plumbing fixtures; scale drawings. 9. Drawings of fixtures and fittings. 10. Inking of drawings; drawing of threads. 14. Plumbing elevations from architect's plans. 15. Elevations of separate parts of the plumbing connections. 18. Architect's plans. 15. Elevations of residence. 19. Plumbing elevations of residence (continued); plumbing plans for cottage. 20. Plumbing elevations; roof connections. 21. Plans and plumbing elevations of oresidence. 22. Plumbing elevations of the plumbing system; use of scales. 23. Use of architect's scales. 24. Special features in the illustrations of country plumbing. 25. Drawing of wought from pings, valves, radiators, coils, etc. 26. Drawing of piping to illustrate heating systems. 150 illustrations.

MODERN PLUMBING ILLUSTRATED. By R. M. STARBUCK.

This book represents the highest standard of plumbing work. It has been adopted and used as a reference book by the United States Government, in its sanitary work in Cuba, Porto Rico, and the Philippines, and by the principal Boards of Health of the United States and Canada.

Cuba, Porto Rico, and the Philippines, and by the principal Boards of Health of the United States and Canada.

It gives connections, sizes and working data for all fixtures and groups of fixtures. It is helpful to the master plumber in demonstrating to his customers and in figuring work. It gives the mechanic and student quick and easy access to the best modern plumbing practice. Suggestions for estimating plumbing construction are contained in its pages. This book represents, in a word, the latest and best up-to-date practice, and should be in the hands of every architect, sanitary engineer and plumber who wishes to keep himself up to the minute on this important feature of construction. Contains following chapters, each illustrated with a full-page place: Kitchen sink, laundry tubs, vegetable wash sink; lavatories, pantry sinks, contents of marble slabs; bath tub, foot and sitz bath, shower bath; water closets, venting of water closets; low-down water closets, water closets party sinks, contents of marble slabs; bath tub, foot and sitz bath, shower bath; water closets, venting of water closets; low-down water closets, water closets, attended to the state of refrigerators, bar sinks, sods fountain sinks; horse stall, frost-proof water closets; connections for S traps, venting; connections for drum traps; soil pipe connections; supporting of soil pipe; main trap and fresh air inlet; floor drains and cellar drains, subsoil drainage; water closets and floor connections; local venting; connections for bath rooms, continued; examples of poor practice; roughing work ready for test; testing of plumbing system; method of continuous venting; continuous venting for two-floors; continuous venting for bath rooms; plumbing for publi

STANDARD PRACTICAL PLUMBING. By R. M. STARBUCK.

RECIPE BOOK

HENLEY'S TWENTIETH CENTURY BOOK OF RECIPES, FORMULAS AND PROCESSES. Edited by Gardner D. Hiscox.

The most valuable Techno-chemical Formulæ Book published, including over 10,000 selected scientific, chemical, technological, and practical recipes and processes.

This is the most complete Book of Formulas ever published, giving thousands of recipes for the manufacture of valuable articles for everyday use. Hints, Helps, Practical Ideas, and Secret Processes are revealed within its pages. It covers every branch of the useful arts and tells thousands of ways of making money, and is just the book everyone should have at his command.

book everyone should have at his command.

Modern in its treatment of every subject that properly falls within its scope, the book may truthfully be said to present the very latest formulas to be found in the arts and industries, and to retain those processes which long experience has proven worthy of a permanent record. To present here even a limited number of the subjects which find a place in this valuable work would be difficult. Suffice to say that in its pages will be found matter of intense interest and immeasurably practical value to the scientific amateur and to him who wishes to obtain a knowledge of the many processes used in the arts, trades and manufactures, a knowledge which will render his pursuits more instructive and remunerative. Serving as a reference book to the small and large manufacturer and supplying intelligent seekers with the information necessary to conduct a process, the work will be found of inestimable worth to the Metallurgist, the Photographer, the Perfumer, the Painter, the Nanufacturer of Glues, Pastes, Cements, and Muclages, the Compounder of Alloys, the Cook, the Physician, the Druggist, the Electrician, the Brewer, the Engineer, the Foundryman, the Machinist, the Potter, the Tanner, the Confectioner, the Chipodist, the Manicure, the Manufacturer of Chemical Novelties and Toilet Preparations, the Dyer, the Electroplater, the Enameler, the Engraver, the Provisioner, the Glass Worker, the Optician, the Farmer, the Dairyman, the Paper Maker, the link Manufacturer, the Optician, the Farmer, the Dairyman, the Paper Maker, the link Manufacturer, the Optician, the Farmer, the Dairyman, the Paper Maker, the link Manufacturer, the Optician, the Farmer, the Dairyman, the Paper Maker, the link Manufacturer, the Optician, the Farmer, the Dairyman, the Paper Maker, the link Manufacturer, the Optician and Soap Maker, the Veterinary Surgeon, and the Technologist in general.

A mine of information, and up-to-date in every respect. A book which will prove of

A mine of information, and up-to-date in every respect. A book which will prove of value to EVERYONE, as it covers every branch of the Useful Arts. Every home needs this book; every office, every factory, every store, every public and private enterprise—EVERYWHERE—should have a copy. 800 pages. Price . . . \$8.00 (See page 32 for full description of book.)

WHAT IS SAID OF THIS BOOK:

"Your Twentieth Century Book of Recipes, Formulas and Processes duly received. I am glad to have a copy of it, and if I could not replace it, money couldn't buy it. It is the best thing of the sort I ever saw." (Signed) M. E. TRUX.

"There are few persons who would not be able to find in the book some single formula that would repay several times the cost of the book."—Merchants' Record and Show Window.

RUBBER

RUBBER HAND STAMPS AND THE MANIPULATION OF INDIA RUBBER. By T. O'CONOR SLOANE.

This book gives full details on all points, treating in a concise and simple manner the elements of nearly everything it is necessary to understand for a commencement in any branch of the India Rubber Manufacture. The making of all kinds of Rubber Hand Stamps, Small Articles of India Rubber, U. S. Government Composition, Dating Hand Stamps, the Manipulation of Sheet Rubber, Toy Balloons, India Rubber Solutions, Cements, Blackings, Renovating Varnish, and Treatment for India Rubber Shoes, etc.; the Hektograph Stamp Inks, and Miscellaneous Notes, with a Short Account of the Discovery, Collection and Manufacture of India Rubber are set forth in a manner designed to be readily understood, the explanations being plain and simple. Including a chapter on Rubber Tire Making and Vulcanizing; also a chapter on the uses of rubber in Surgery and Dentistry. Third revised and enlarged edition. 175 pages. Illustrated.

<u>SAWS</u>

SAW FILING AND MANAGEMENT OF SAWS. By ROBERT GRIMSHAW.

A practical hand-book on filing, gumming, swaging, hammering, and the brazing of band saws, the speed, work, and power to run circular saws, etc. A handy book for those who have charge of saws, or for those mechanics who do their own filing, as it deals with the proper shape and pitches of saw teeth of all kinds and gives many useful hints and rules for gumming, setting, and filing, and is a practical aid to those who use saws for any purpose. Complete tables of proper shape, pitch and saw teeth as well as sizes and number of teeth of various saws are included. Third edition, revised and enlarged. Illustrated. Price

STEAM ENGINEERING

AMERICAN STATIONARY ENGINEERING. By W. E. CRANE.

This book begins at the boiler room and takes in the whole power plant. A plain talk on every-day work about engines, boilers, and their accessories. It is not intended to be scientific or mathematical. All formulas are in simple form so that any one understanding plain arithmetic can readily understand any of them. The author has made this the most practical book in print; has given the results of his years of experience, and has included about all that has to do with an engine room or a power plant. You are not left to guess at a single point. You are shown clearly what to expect under the various conditions; how to secure the best results; ways of preventing "shut downs" and repairs; in short, all that goes to make up the requirements of a good engineer, capable of taking charge of a plant. It's plain enough for practical men and yet of value to those high in the profession.

EMINENT ENGINEERS. By Dwight Goddard.

Everyone who appreciates the effect of such great inventions as the Steam Engine, Steamboat, Locomotive, Sewing Machine, Steel Working, and other fundamental discoveries, is interested in knowing a little about the men who made them and their achievements.

ENGINE RUNNER'S CATECHISM. By ROBERT GRIMSHAW.

A practical treatise for the stationary engineer, telling how to erect, adjust and run the principal steam engines in use in the United States. Describing the principal features of various special and well-known makes of engines: Temper Cut-off, Shipping and Receiving Foundations. Erecting and Starting. Valve Setting, Care and Use, Emergencies, Erecting and Adjusting Special Engines.

ENGINE TESTS AND BOILER EFFICIENCIES. By J. BUCHETTI.

HORSEPOWER CHART.

Shows the horsepower of any stationary engine without calculation. No matter what the cylinder diameter of stroke, the steam pressure or cut off, the revolutions, or whether condensing or non-condensing, it's all there. Easy to use, accurate, and saves time and calculations. Especially useful to engineers and designers. 50 cents

MODERN STEAM ENGINEERING IN THEORY AND PRACTICE. By GARDNER D. HISCOX.

This is a complete and practical work issued for Stationary Engineers and Firemen, dealing with the care and management of boilers, engines, pumps, superheated steam, refrigerating machinery, dynamos, motors, elevators, air compressors, and all other branches with which the modern engineer must be familiar. Nearly 200 questions with their answers on steam and electrical engineering, likely to be asked by the Examining Board, are included.

Among the chapters are: Historical; steam and its properties; appliances for the generation of steam; types of boilers; chimney and its work; heat economy of the feed water; steam pumps and their work; incrustation and its work; steam above atmospheric pressure; flow of steam from nozzles; superheated steam and its work; adiabatic expansion of steam; indicator and its work; steam engine proportions; slide valve engines and valve motion; Corliss engine and its valve gear; compound engine

and its theory; triple and multiple expansion engine; steam turbine; refrigeration; elevators and their management; cost of power; steam engine troubles; electric power and electric plants. 487 pages. 405 engravings. 3d Edition. Price . \$3.00

STEAM ENGINE CATECHISM. By Robert Grimshaw.

This unique volume of 413 pages is not only a catechism on the question and answer principle, but it contains formulas and worked-out answers for all the Steam problems that appertain to the operation and management of the Steam Engine. Illustrations of various valves and valve gear with their principles of operation are given. Thirty-four Tables that are indispensable to every engineer and fireman that wishes to be progressive and is ambitious to become master of his calling are within its pages. It is a most valuable instructor in the service of Steam Engineering. Leading engineers have recommended it as a valuable educator for the beginner as well as a reference book for the engineer. It is thoroughly indexed for every detail. Every essential question on the Steam Engine with its answer is contained in this valuable work. Sixteenth edition. Price

STEAM ENGINEER'S ARITHMETIC. By Colvin-Cheney.

A practical pocket-book for the steam engineer. Shows how to work the problems of the engine room and shows "why." Tells how to figure horsepower of engines and boilers; area of boilers; has tables of areas and circumferences; steam tables; has a dictionary of engineering terms. Puts you on to all of the little kinks in figuring whatever there is to figure around a power plant. Tells you about the heat unit; absolute zero; adiabatic expansion; duty of engines; factor of safety; and 1,001 other things; and everything is plain and simple—not the hardest way to figure, but the easiest. Second Edition.

STEAM HEATING AND VENTILATION

PRACTICAL STEAM, HOT-WATER HEATING AND VENTILATION. By A. G. King.

A. G. King.

This book is the standard and latest work published on the subject and has been propared for the use of all engaged in the business of steam, hot water heating, and ventilation. It is an original and exhaustive work. Tells how to get heating contracts, how to install heating and ventilating apparatus, the best business methods to be used, with "Tricks of the Trade" for shop use. Rules and data for estimating radiation and cost and such tables and information as make it an indispensable work for everyone interested in steam, hot water heating, and ventilation. It describes all the principal systems of steam, hot water heating, and ventilation. It describes all the principal systems of steam, hot water, vacuum, vapor, and vacuum-vapor heating, together with the new accelerated systems of hot water circulation, including chapters on up-to-date methods of ventilation and the fan or blower system of heating and ventilation. Containing chapters on: I. Introduction. II. Heat. III. Evolution of artificial heating apparatus. IV. Boller surface and settings. V. The chimney flue. VI. Pipe and fittings. VII. Valves, various kinds. VIII. Forms of radiating surfaces. IX. Locating of radiating surfaces. X. Estimating radiation. XI. Steam heating apparatus. XII. Exhaust-steam heating. XIII. Hot-water heating. XIV. Pressure systems of hot-water work. XV. Hot-water appliances. XVII. Greenhouse heating. XIX. Radiator and pipe connections. XX. Ventilation. XXI. Mechanical ventilation and hot-blast heating. XXVII. Steam appliances. XXIII. District heating. XXIV. Pipe and boller covering. XXV. Temperature regulation and heat control. XXVI. Business methods. XXVII. Miscellaneous. XXVIII. Rules, tables and useful information. 367 pages. 300 detailed engravings. Second Edition—Revised. Price

STEAM PIPES

STEAM PIPES: THEIR DESIGN AND CONSTRUCTION. By WM. H. BOOTH.

The work is well illustrated in regard to pipe joints, expansion offsets, flexible joints, and self-contained sliding joints for taking up the expansion of long pipes. In fact, the chapters on the flow of steam and expansion of pipes are most valuable to all steam fitters and users. The pressure strength of pipes are most valuable to all steam fitters and users. The pressure strength of pipes and method of hanging them are well treated and illustrated. Valves and by-passes are fully illustrated and described, as are also fiange joints and their proper proportions, exhaust heads and separators. One of the most valuable chapters is that on superheated steam and the saving of steam by insulation with the various kinds of felting and other materials with comparison tables of the loss of heat in thermal units from naked and felted, steam pipes. Contains 187 pages. Price \$2.00

STEEL

STEEL: ITS SELECTION, ANNEALING, HARDENING AND TEMPERING. By E. R. Markham.

This work was formerly known as "The American Steel Worker," but on the publication of the new, revised edition, the publishers deemed it advisable to change its title to a more suitable one. It is the standard work on Hardening, Tempering, and Annealing Steel of all kinds.

This book tells how to select, and how to work, temper, harden, and anneal steel for everything on earth. It doesn't tell how to temper one class of tools and then leave



STEEL

ITS SELECTION, ANNEALING, HARDENING AND TEMPERING

By E. R. MARKHAM

168 Specially Prepared
Illustrations

400 Pages

PRICE \$2.50

THIS work was formally known as "THE AMERICAN STREI, WORKER" but on the publication of the present edition, the publishers deemed it advisable to change the title to a more comprehensive one, viz: "Steel, Its Selection, Annealing, Hardening and Tempering".

This book tells how to select and to know the steel best suited to various purposes; gives reasons for the different steels; how to heat in the making of everything in the way of tools made from steel; how to proceed in the making of taps, reamers, drills and milling cutters; how to harden dies and punches from the largest to the smallest; about the tempering of springs, from watch springs up; about saws, chisels, and other wood-working tools; about pack and case hardening; how to anneal; about heating apparatus, the kinds to use for the best results, and how to make such heating apparatus right at home if it becomes necessary; gives formulas for mixtures for baths for different purposes, and gives good reasons why each is best adapted to its special work. In fact, there isn't'a thing that a steel worker would want to know that isn't included within its pages.

Mr. Markham has been selecting, annealing, hardening, tempering and studying steel for nearly thirty years and is still at it. There's a reason for every failure you have—and a remedy. You'll find them both in this book; and it will be mightly handy to have a copy to look over when something goes wrong and you want to get it going right without any delay.

There are new Sections on High Speed Steels, High Carbon Steel, Electric and Salt Bath Furnaces and Ovens. This makes the book more valuable than ever. A copy ought to be in the hands of every wide awake mechanic and in every shop library in the country—and it will be when its value is fully realized. Its pages are full of practical information that you cannot find elsewhere.

AMONG SOME OF THE SUBJECTS TREATED ARE

The Workman—Steel—Methods of Heating—Heating Tool Steel—Forging—Annealing—Hardening Batha—Baths for Hardening—Hardening Steel—Drawing the Temper after Hardening—Examples of Hardening—Pack Hardening—Case Hardening—Spring Tempering—Making Tools of Machine Steel —Special Steels—Steel for Various Tools—Cases of Trouble—Welding—High Speed Steels—High Carbon Steel—Electric and Salt Bath Furnaces and Ovens.

WHAT IS SAID OF THIS BOOK

"We are glad to note the appearance of this excellent book. No tool maker or steel worker can make a mistake in buying a copy of this publication."—American Machinist.

"Contains 400 pages of solid information."-American Blacksmith.

"Every Machine Shop Superintendent and Tool Room Foreman ought to possess a copy of this valuable book, and engineers in charge can save their firms money by circulating it in their workshops where fine steel tools are made."—The Canadian Engineer.

the treatment of another kind of tool to your imagination and judgment, but it gives careful instructions for every detail of every tool, whether it be a tap, a reamer or just a screw-driver. It tells about the tempering of small watch springs, the hardening of cutlery, and the annealing of dies. In fact there isn't a thing that a steel worker would want to know that isn't included. It is the standard book on selecting, hardening, and tempering all grades of steel. Among the chapter headings might be mentioned the following subjects: Introduction; the workman; steel; methods of heating; heating tool steel; forging; annealing; hardening baths; baths for hardening; hardening; teel; drawing the temper after hardening; examples of hardening; pack hardening; case hardening; spring tempering; making tools of machine steel; special steels; steel for various tools; causes of trouble; high speed steels, etc. 400 pages. Very fully illustrated. Fourth Edition. Price

HARDENING, TEMPERING, ANNEALING, AND FORGING OF STEEL. By J. V. Woodworte.

A new work treating in a clear, concise manner all modern processes for the heating, annealing, forging, welding, hardening, and tempering of steel, making it a book of great practical value to the metal-working mechanic in general, with special directions for the successful hardening and tempering of all steel tools used in the arts, including milling cutters, taps, thread dies, reamers, both solid and shell, hollow mills, punches and dies, and all kinds of sheet metal working tools shear blades, saws, fine cutlery, and metal cutting tools of all description, as well as for all implements of steel both large and small. In this work the simplest and most satisfactory hardening and tempering processes are given.

The uses to which the leading brands of steel may be adapted are concisely presented, and their treatment for working under different conditions explained, also the special methods for the hardening and tempering of special brands.

A chapter devoted to the different processes for Case-hardening is also included, and special reference made to the adoption of machinery steel for tools of various kinds. Fourth Edition. 288 pages. 201 illustrations. Price \$3.50

TRACTORS

THE MODERN GAS TRACTOR. By VICTOR W. PAGE.

A complete treatise describing all types and sizes of gasoline, kerosene and oil tractors. Considers design and construction exhaustively, gives complete instructions for care, operation and repair, outlines all practical applications on the road and in the field. The best and latest work on farm tractors and tractor power plants. A work needed by farmers, students, blacksmiths, mechanics, salesmen, implement dealers, designers and engineers. 500 pages. Nearly 300 illustrations and folding plates. Price \$2.00

TURBINES

MARINE STEAM TURBINES. By Dr. G. BAUER and O. LASCHE. Assisted by E. Ludwig and H. Vogel. Translated from the German and edited by M. G. S. Swallow.

This work forms a supplementary volume to the book entitled "Marine Engines and Bollers." The authors of this book, Dr. G. Bauer and O. Lasche, may be regarded as the leading authorities on turbine construction.

The book is essentially practical and discusses turbines in which the full expansion of steam passes through a number of separate turbines arranged for driving two or more shafts, as in the Parsons system, and turbines in which the complete expansion of steam from inlet to exhaust pressure occurs in a turbine on one shaft, as in the case of the Curtis machines. It will enable a designer to carry out all the ordinary calculation necessary for the construction of steam turbines, hence it fills a want which is hardly met by larger and more theoretical works.

met by larger and more theoretical works.


Numerous tables, curves and diagrams will be found, which explain with remarkable lucidity the reason why turbine blades are designed as they are, the course which steam takes through turbines of various types, the thermodynamics of steam turbine calculation, the influence of vacuum on steam consumption of steam turbines, etc. In a word, the very information which a designer and builder of steam turbines most requires. The book is divided into parts as follows: 1. Introduction. 2. General remarks on the design of a turbine installation. 3. The calculation of steam turbines. 4. Turbine design. 5. Shafting and propellers. 6. Condensing plant. 7. Arrangement of turbines. 8. General remarks on the arrangement of steam turbines in steamers. 9. Turbine-driven auxiliaries. 10. Tables. Large octavo. 214 pages. Fully illustrated and containing 18 tables. Including an entropy chart. Price, net . \$3.50

WATCHMAKING

WATCHMAKERS' HANDBOOK. By CLAUDIUS SAUNIER.

This famous work has now reached its seventh edition, and there is no work issued that can compare to it for clearness and completeness. It contains 498 pages and is intended as a workshop companion for those engaged in Watchmaking and allied Mechanical Arts. Nearly 250 engravings and fourteen plates are included. Price. \$3.00





THE MODERN GAS TRACTOR

By VICTOR W. PAGÉ, M. E.

Author of "The Modern Gasoline Automobile," Etc.

A COMPLETE TREATISE DESCRIBING ALL TYPES AND SIZES OF GASOLINE, KEROSENE AND OIL TRACTORS. CONSIDERS DESIGN AND CONSTRUCTION EXHAUSTIVELY, GIVES COMPLETE INSTRUCTIONS FOR CARE, OPERATION AND REPAIR, OUTLINES ALL PRACTICAL APPLICATIONS ON THE ROAD AND IN THE FIELD. THE BEST AND LATEST WORK ON FARM TRACTORS AND TRACTOR POWER PLANTS.

480 PAGES — THREE FOLDING PLATES — 204 ILLUSTRATIONS

PRICE - - \$2.00


A modern exposition in the language of the field showing and describing every recent improvement in tractors and auxiliary appliances. All money making farms use power. Learn how to apply it now.

. This work is written by a recognized authority on self-propelled vehicles and internal combustion motors. Everything is explained so simply that anyone of average intelligence may obtain a comprehensive knowledge of gas tractor operation, maintenance and repair. Tells how they are constructed and explains fully the reasons for varying designs. Contains special chapters on driving the tractor on field and road, what to expect from tractors in various kinds of work, cost of operation and moneymaking hints on repairs. It describes all ignition systems, all types of gasoline and kerosene vaporizers and carburetors, latest forms of power plants and installation, clutches, speed changing and reversing gears and all frame parts and their functions. Tells how to tell brake horsepower from draw bar or horse equivalent power, how to make adjustments to power plants, change speed gearing and other parts. Describes tools for tractor repair and gives plans for tractor sheds so they can be used in winter for stationary power or workshops where all repairs may be made. Outlines control systems of leading types and shows simple hitches for working various implements in combination. Describes fully tractors for small farms and orchards as well as types of the largest capacity. All illustrations are plainly marked with all important parts indicated so they may be easily identified. Drawings are simple but in correct proportion. Every illustration has been specially made for this book.

ALL FARMERS, STUDENTS, BLACKSMITHS, MECHANICS, SALESMEN, IM-PLEMENT DEALERS, DESIGNERS AND ENGINEERS NEED THIS WORK

Written in language understood by all. No technical terms.

COVERS EVERY PHASE OF 1914 TRACTOR ENGINEERING PRACTICE AND IS SUPERIOR TO ANY TREATISE HERETOFORE PUBLISHED



NEW REVISED EDITION

Henley's Twentieth Century Book of RECIPES, FORMULAS AND PROCESSES

Edited by GARDNER D. HISCOX, M. E.

Price \$3.00 Handsome Cloth Binding \$4.00 Half Merocce Binding 800 Large Octave (6 x 9½) PAGES

Contains over 10,000 Selected Processes, Formulas and Practical Recipes, Including hundreds of so-called Trade Secrets for every business

HOW TO MAKE MONEY

This new book of processes and formulas is the latest and greatest compilation of the kind ever published. It is a standard work—an authority—a "first aid"—and a "court of last resort" on "What to Make and How to Make It."

It contains more than 10,000 practical recipes and formulas for everyday use in business, at home or in the factory. Everything you want to make—Antiseptics, Waterproofing, Lubricants, Rust Preventives, Dyes, Filters, Cleaning Preparations, Enameling, Beverages, Inks, Adhesives, Polishes, Disinfectants, Flavorings, Cosmetics, Ceramics, etc., etc. Photography is treated in all of its various branches, as are also Plating, Painting, Leather Work, etc. Tests for Food Adulterants are fully covered; how to make fly paper; to color flowers artifically; to estimate weight of ice by measurement; to make materials fireproof; to work with metals—aluminum, brass, etc.; to make anything and everything, from A to Z.

There is not a home, office, factory, or place of business of any kind that

There is not a home, office, factory, or place of business of any kind that does not actually need this book. It is a money saver and a money maker; it appeals to the young as well as to the old. Great business enterprises all owe their success to the manufacture or sale of some simple invention or compound—usually the result of an experiment at home. With this latest book of practical formulas the boy of to-day has a far better opportunity than his father—and the mother and sisters can develop an industry of their own that will produce a comfortable income.

We live in the most progressive country on the face of the earth. We owe it to ourselves to advance—to learn—to progress. We can't afford to stand still. Then learn more, so you can earn more. Profit by the knowledge that has made others successful. Now is the time—you can't learn younger. Get this book at once.

Copies of this book sent prepaid to any address on receipt of price.

THE NORMAN W. HENLEY PUBLISHING CO.,

132 NASSAU STREET. - NEW YORK.

GASOLINE ENGINE TROUBLE CHART

A Chart 25 x 38 inches JUST ISSUED

Simplifies all Engine Troubles

No Details Omitted

Every Motorist should procure this chart

shows
all parts of
a typical
four-cylinder
gasoline
Engine
of the fourcycle type

25c.


25c. Price

This is reduced from the large size chart, 25 x 38 inches.—Price 25 cents

JUST PUBLISHED

LUBRICATION OF THE MOTOR CAR CHASSIS

By VICTOR W. PAGÉ



Simplifies All Lubrication Problems
Tells When To Oil and What Kind To Use To Secure Best Results

Size 24 x 38 inches. PRICE 25 CENTS

JUST PUBLISHED

How to Run and Install Two and Four-Cycle Marine Gasoline Engines

By C. VON CULIN

100 Pages

Price 25 Cents

Fully Illustrated



1915 REVISED AND ENLARGED EDITION

The object of the author of this book is to furnish a pocket instructor for the beginner or the busy man who uses a marine engine for pleasure or profit, but who does not have the time or inclination for a more complete technical book. The instructions given are ample to enable any person to properly install, care for and operate his own marine engine.

Among Some of the Subjects Treated Are:

Avoid Trouble
Back-Firing
Badly Plooded Engine
Batteries
Adjusting Carbureter
Carbureter Trouble
Care of Engine
Crank Case Explosions
Cylinder Pressure
Dynamo or Magneto
Exbaust
Extra Spark Plugs
Failure to Start
Four-Cycle Engine
Gas Engine

Gaskets
Grinding in Valves, Cycle
Hard to Turn Over
Horse Power
Ignition
Imperfect Exhaust
Jump Spark Coil
Jump Spark Engine
Jump Spark Plug
Jump Spark Plug
Jump Spark Plug
Jump Spark Timer
Make and Break Coil
Make and Break Engine
Misfire, Four-Cycle
Misfire, Make and Break
Misfire on Slow Speed
(Four-Cycle)

Ruhmkorff Coil
Spark Coils
Spark Plug
Spark Plug
Spark Plugs
Testing Jump Spark
Three-Port Two-Cycle
Engine
Timing the Spark
Troubles
Two-Cycle Engine
Two-Cycle Engine
Two-Cycle Engine
Valves
Weak Batteries
Wiring
Worn Thread

The Norman W. Henley Publishing Co.

· 132 Nassau Street, New York



Gas, Gasoline AND Oil Engines

By GARDNER D. HISCOX, M. E.

Enlarged and Brought Up to Date By VICTOR W. PAGÉ, M. E.,
Author of "The Modern Gasoline Automobile," Etc.

640 PAGES—WITH FOLDING PLATES—435 ILLUSTRATIONS

PRICE \$2.50 NET

The 1915 Revised, Enlarged and Entirely New Edition of this Standard Work, Considers Exhaustively All Types of Stationary, Marine, Motor Vehicles and Aerial Power Plants

The mechanic, gas engine operator or salesman must have a practical knowledge of the gas engine in order to increase his value to his employer. This work written primarily for this large class, contains matter of vital interest. It shows all the latest developments, such as the Diesel engine in the stationary power field, the Knight sliding sleeve automobile motor and the Gnome rotating cylinder aeroplane motor. It details all the practical ignition systems and methods, including the hot tube and hot bulb for stationary engines and all forms of high and low tension electrical ignition groups. It shows high and low tension magnetos, describes battery forms, induction coil construction and all kinds of wiring diagrams for stationary, marine or auto motors. It defines all the liquid fuels and their properties, shows how to adjust and use all types of gasoline and kerosene carburators. All leading producer gas plants are described and illustrated. Full instructions are given for valve and spark timing, all kinds of valves and operating mechanisms are discussed. Practical instructions are given for making all kinds of engine power tests and latest forms of testing apparatus are described. The rules regulating gas, gasoline and oil engine installation are given in full, also a complete chapter on engine management. The application of the gasoline engine to the automobile, motorcycle, aeroplane, motors boat, gas tractor, and in farm use is fully described. The requirements of motors for these uses, their peculiarities constructional details and actual installation are also considered. Many practical rules and easily worked out formulæ relating to engine power determination, design of parts, etc., are given that can be used by those without technical knowledge.

NOT TOO TECHNICAL FOR THE STUDENT—NOT TOO ELEMENTARY FOR THE ENGINEER.

A PRACTICAL WORK FOR PRACTICAL MEN

The Norman W. Henley Publishing Co.
132 Nassau Street, New York

JUST PUBLISHED

The Gasoline Engine on the Farm

Its Operation, Repair and Uses

By XENO W. PUTNAM

527 Pages

179 Engravings

Price \$2.00

This is a practical treatise on the Gasoline and Kerosene Engine intended for the man who wants to know just how to manage his engine and how to apply it to all kinds of farm work to the best advantage.



There is so much of value in this book, that it is impossible to adequately describe it in such small space. Suffice to say that it is the kind of a book every farmer will appreciate and every farm home ought to have. Includes selecting the most suitable engine for farm work, its most convenient and efficient installation, with chapters on troubles, their remedies, and how to avoid them. The care and management of the farm tractor in plowing, harrowing, harvesting and road grading are fully covered; also plain directions are given for handling the tractor on the road. Special attention is given to relieving farm life of its drudgery by applying power to the disagreeable small tasks which must otherwise be done by hand. Many homemade contrivances for cutting wood, supplying kitchen, garden, and barn with water, loading, hauling and unloading bay, delivering grain to the bins or the

feed trough are included; also full directions for making the engine milk the cows, churn, wash, sweep the house and clean the windows, etc. Very fully illustrated with drawings of working parts and cuts showing Stationary, Portable, and Tractor Engines doing all kinds of farm work.

WHAT IS SAID OF THIS BOOK:

A valuable book and one to be largely read .- Farm and Ranch.

The book is well worth the price to anyone using a gasoline engine on his farm.- West Virginia Farmer and Grange Advocate.

The Norman W. Henley Publishing Co.

132 Nassau Street, New York

JUST PUBLISHED!



MOTORCYCLES, SIDE CARS AND CYCLECARS

Their Construction, Management and Repair

By VICTOR W. PAGÉ, M. E. Author of "The Modern Gasoline Automobile," Etc., Etc.

Contains over 350 specially made illustrations showing the most valuable series of drawings pertaining to motorcycle design and construction ever published.

550 Pages

PRICE \$1.50

5 Folding Plates

The only complete work published for the Motorcyclist and Cyclecarist. Describes fully all leading types of Machines, their Design, Construction, Maintenance, Operation and Repair.

This treatise traces the motorcycle from its earliest forms to the approved models of the present day. It outlines fully the operation of two and four cycle power plants and all ignition, carburction and lubrication systems in detail. Describes all representative types of free engine clutches, variable speed gears and power transmission systems, clives complete instructions for operating and repairing all types. Considers fully electric self-starting and lighting systems, all types of spring frames and spring forks and shows leading control methods.

The prospective purchaser and novice rider will find the descriptions of various engines and auxiliary systems easy to understand; the repair hints, suggestions for locating troubles and operating instructions invaluable.

The Dealer, Mechanic and Expert Rider will find this treatise a work of reference without an equal.

For those desiring technical information a complete series of tables and many formulæ to assist in designing are included. The work tells how to figure power needed to climb grades, overcome air resistance and attain high speeds. It shows how to select gear ratios for various weights and powers, how to figure braking efficiency required, gives sizes of beits and chains to transmit power safely and shows how to design sprockets, belt pulleys, etc. This work also includes complete formulæ for figuring horso-power, shows how dynamometer tests are made, defines relative efficiency of air and water cooled engines, plain and anti-friction bearings and much other data of a practical, helpful engineering nature. Remember that you get this information in addition to the practical description and instructions which alone are worth several times the price of the book.

THE CHAPTERS ON CYCLECARS GIVE ALL THE INFORMATION NEEDS TO UNDERSTAND THE CONSTRUCTION AND OPERATION OF THIS LATEST DEVELOPMENT IN THE FIELD OF SELF-PROPELLED VEHICLES.

The Norman W. Henley Publishing Co.

132 Nassau Street, New York.

		•		
	·			
		·		
				•
				·
			ı	
•				
•		•		
		·		i

.

		•		
			·	
				٠
•				
-				

• .

i . • .



book may be kept FOURTEEN DAYS

A fine of TWO CENTS will be charged for each day the book is kept overtime.

	ļ	ļ	
	į		
		 -	ļ
	1	1	
	1		
DEM CO-291-8			
DEM CO. 251-10			· '

